











SECTION PD

PREPARATION	2	Side Bearing Preload	24
PROPELLER SHAFT	5	Tooth Contact	27
On-Vehicle Service	6	ASSEMBLY	28
Removal and Installation	7	Extension Tube and Differential Side	
Inspection	7	Shaft	28
Disassembly	7	Differential Case	29
Assembly	8	Final Drive Housing	30
ON-VEHICLE SERVICE	10		
Front oil Seal Replacement		<div>Model H233B</div>	
(Front final drive: R180A)	10	REAR FINAL DRIVE	35
Front Oil Seal Replacement		DISASSEMBLY	36
(Rear final drive: H233B)	10	Pre-inspection	36
REMOVAL AND INSTALLATION		Differential Carrier	37
(Front final drive – R180A)	12	Differential Case	39
Removal	12	INSPECTION	41
Installation	12	Ring Gear and Drive Pinion	41
REMOVAL AND INSTALLATION		Differential Case Assembly	41
(Rear final drive – H233B)	13	Bearing	41
Removal	13	LIMITED SLIP DIFFERENTIAL	42
Installation	13	Preparation for Disassembly	42
		Disassembly	43
<div>Model R180A</div>		Inspection	43
FRONT FINAL DRIVE	14	Adjustment	44
DISASSEMBLY	15	Assembly	46
Pre-inspection	15	ADJUSTMENT	48
Final Drive Housing	15	Drive Pinion Height	48
Differential Case	18	Tooth Contact	51
Extension Tube and Differential Side Shaft ..	19	ASSEMBLY	52
INSPECTION	20	Differential Carrier	52
Ring Gear and Drive Pinion	20		
Differential Case Assembly	20	SERVICE DATA AND SPECIFICATIONS	
Bearing	20	(S.D.S.)	56
ADJUSTMENT	21	Propeller Shaft	56
Drive Pinion Height	21	Final Drive	57

PREPARATION









SPECIAL SERVICE TOOLS

*: Special tool or commercial equivalent

Tool number Tool name	Description	Unit application	
		R180A	H233B
ST31211000 Height gauge	 Selecting pinion height adjusting washer	X	—
ST31212000 Dummy shaft	 Selecting pinion height adjusting washer	X	—
ST31852000 Stopper	 Selecting pinion height adjusting washer	X	—
ST3125S000 Drive pinion height setting gauge set ① ST31251000 Drive pinion height gauge ② ST31181001 Dummy shaft	 ①  ② Selecting pinion height adjusting washer	—	X
ST32501000 Weight block	 Selecting side bearing adjusting shim	X	—
KV38101900 Master gauge [20.0 mm (0.787 in)]	 Selecting side bearing adjusting shim	X	—
ST0501S000 Engine stand ① ST05011000 Engine stand ② ST05012000 Base	 ① ② Mounting differential attachment	X	X
KV38100800 Differential attachment	 Mounting final drive	X	—
ST06340000 Differential attachment	 Mounting final drive	—	X










PREPARATION

*: Special tool or commercial equivalent

Tool number Tool name	Description	Unit application	
		R180A	H233B
ST32580000 Diff. side bearing adjusting nut wrench		—	X
KV381052S0 Rear axle shaft dummy ① KV38105210 Torque wrench side ② KV38105220 Vice side		—	X
ST33290001* Side bearing outer race puller		X	—
ST38060002* Drive pinion flange wrench		X	—
KV38104700* Drive pinion flange wrench		—	X
ST3090S000* Drive pinion rear inner race puller set ① ST30031000 Puller ② ST30901000* Base		X	X
ST3306S001 Diff. side bearing puller set ① ST33051001* Body ② ST33061000* Adapter		X	X
ST33230000* Diff. side bearing drift		X	—


PREPARATION

*: Special tool or commercial equivalent


Tool number Tool name	Description	Unit application	
		R180A	H233B
ST33190000* Diff. side bearing drift	 <p>A: 52 mm (2.05 in) dia. B: 34 mm (1.34 in) dia.</p>	—	X
ST33081000* Side bearing puller adapter	 <p>A: 43 mm (1.69 in) dia. B: 33.5 mm (1.319 in) dia.</p>	—	X
ST30611000* Drift		X	X
ST30621000* Drift	 <p>A: 79 mm (3.11 in) dia. B: 59 mm (2.32 in) dia.</p>	X	X
ST30701000* Drift	 <p>A: 61.5 mm (2.421 in) dia. B: 41 mm (1.61 in) dia.</p>	X	—
ST30613000* Drift	 <p>A: 71.5 mm (2.815 in) dia. B: 47.5 mm (1.870 in) dia.</p>	—	X
KV381025S0* Oil seal fitting tool ① ST30720000 Drift bar ② KV38102510 Drift	 <p>A: 77 mm (3.03 in) dia. B: 55 mm (2.17 in) dia. C: 71 mm (2.80 in) dia. D: 65 mm (2.56 in) dia.</p>	X	X
ST33720000 Diff. side retainer guide		X	—
ST33270000 Side oil seal drift	 <p>A: 62 mm (2.44 in) dia. B: 28 mm (1.10 in) dia.</p>	X	—

PROPELLER SHAFT


Front propeller shaft (Model 2F71H)



Rear propeller shaft (Models 2S71H & 2S80B)



PROPELLER SHAFT




On-Vehicle Service

PROPELLER SHAFT VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.


1. Raise rear wheels.
2. Measure propeller shaft runout at points indicated below by rotating final drive companion flange by hand.



Front propeller shaft

Unit: mm (in)


Propeller shaft model	2F71H
Measuring point A	126 (4.96)



Rear propeller shaft

Unit: mm (in)

Propeller shaft model	2S71H	2S80B
	H233B	
Measuring point		
A	300	280 (11.02)
B	473	475 (18.70)
C	300	280 (11.02)



3. If runout exceeds specifications, disconnect propeller shaft at final drive companion flange; then rotate companion flange 180 degrees and reconnect propeller shaft.


Runout limit: 0.6 mm (0.024 in)

4. Check runout again. If runout still exceeds specifications, replace propeller shaft assembly.
5. Perform road test.

APPEARANCE CHECKING


- Inspect propeller shaft tube surface for dents or cracks. If damaged, replace shaft assembly.
- If center is noisy or damaged, replace center bearing.

PROPELLER SHAFT




Removal and Installation

- Put match marks on flanges and separate propeller shaft from final drive.



- Draw out propeller shaft from transmission and plug up rear end of transmission rear extension housing.




Inspection

- Inspect propeller shaft runout. If runout exceeds specifications, replace propeller shaft assembly.

Runout limit:


0.6 mm (0.024 in)



- Inspect journal axial play. If the play exceeds specifications, replace propeller shaft assembly.

Journal axial play:

0.2 mm (0.008 in) or less




Disassembly

JOURNAL


1. Put match marks on shaft and flange or yoke.

PROPELLER SHAFT


Disassembly (Cont'd)



2. Remove snap ring.




3. Remove pushed out journal bearing by lightly tapping yoke with a hammer, taking care not to damage journal and yoke hole.



4. Remove bearing at opposite side in above operation.

Put marks on disassembled parts so that they can be reinstalled in their original positions from which they were removed.




Assembly

JOURNAL

1. Assemble journal bearing. Apply recommended multi-purpose grease on bearing inner surface.

When assembling, be careful that needle bearing does not fall down.




2. Select snap rings that will provide specified play in axial direction of journal, and install them (Refer to S.D.S.).


Select snap rings with a difference in thickness at both sides within 0.06 mm (0.0024 in).

PROPELLER SHAFT

Assembly (Cont'd)




3. Adjust thrust clearance between bearing and snap ring to zero by tapping yoke.



4. Check to see that journal moves smoothly and check for axial play.


Axial play: Less than 0.02 mm (0.0008 in)




Front Oil Seal Replacement (Front final drive: R180A)

1. Remove front propeller shaft.
2. Loosen drive pinion nut.


Tool number: ST38060002



3. Remove companion flange.




4. Remove front oil seal.



5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Press front oil seal into carrier.
6. Install companion flange and drive pinion nut.
7. Install propeller shaft.

Tool number:
ST30720000



Front Oil Seal Replacement (Rear final drive: H233B)


1. Remove rear propeller shaft.
2. Loosen drive pinion nut.

Tool number:
KV38104700


ON-VEHICLE SERVICE

Front Oil Seal Replacement (Cont'd)

3. Remove companion flange.




4. Remove front oil seal.



5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Press front oil seal into carrier.
6. Install companion flange and drive pinion nut in.
7. Install rear propeller shaft.


Tool number:

KV381025S0




REMOVAL AND INSTALLATION (Front final drive — R180A)

Except KA24E (LWD)



KA24E (LWD)





Removal

1. Remove front propeller shaft.
2. Remove drive shaft. Refer to FA section.
3. Remove engine mounting bolts and raise up engine.
4. Remove front final drive together with differential mounting member.

Installation

1. Install front final drive assembly together with differential mounting member.



2. Tighten the front final drive securing bolts and nuts following the procedures below to prevent drive train vibration.
 - (1) Temporarily tighten nut **(A)**.
 - (2) Temporarily tighten nut **(B)**.
 - (3) Tighten bolts **(C)** to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
 - (4) Tighten bolts **(D)** to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
 - (5) Tighten nut **(A)** to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
 - (6) Tighten nut **(B)** to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
 - (7) Tighten nuts **(E)** to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).
3. Install drive shaft. Refer to FA section.
4. Install front propeller shaft.

REMOVAL AND INSTALLATION (Rear final drive — H233B)

Removal


- Remove propeller shaft.

Insert plug into transfer or transmission after removing propeller shaft.

- Remove axle shaft. Refer to RA section.

CAUTION:


- **Be careful not to damage spline, sleeve yoke and front oil seal when removing propeller shaft.**




Installation

- Fill final drive with recommended gear oil.

- ☆ : Adjustment is required
 * : Using locking agent [Locktite (stud lock) or equivalent]
 [T] : N·m (kg-m, ft-lb)
 ⊗ : Always replace after every disassembly





Pre-inspection

Before disassembling final drive, perform the following inspection.


- Total preload
 - Remove the extension tube and the side flange. This measurement must be performed with the extension tube and the differential flange removed.
- 1) Turn drive pinion in both directions several times to set bearing rollers.
 - 2) Check total preload with Tool.

Tool number:

ST3127S000

Total preload:


1.2 - 2.3 N·m (12 - 23 kg-cm, 8.7 - 20.0 in-lb)



- Ring gear to drive pinion backlash
Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash:

0.13 - 0.18 mm (0.0051 - 0.0071 in)




- Ring gear runout
Check runout of ring gear with a dial indicator.

Runout limit:

0.05 mm (0.0020 in)

- Tooth contact
Check tooth contact (Refer to Adjustment).



Final Drive Housing


1. Using three spacers [20 mm (0.79 in)], mount final drive assembly on Tool.

Tool number:


KV38100800

DISASSEMBLY (R180A)


Final Drive Housing (Cont'd)



2. Remove extension tube and differential side shaft assembly.




3. Remove differential side flange.




4. Mark side retainers for identification. Remove side retainers.

Be careful not to confuse right and left side retainers and shims.



5. Extract differential case from final drive housing.



6. Remove side outer races.

Tool number:


ST33290001

Be careful to keep the side bearing outer races together with their respective inner cones — do not mix them up.

7. Remove side oil seal.


DISASSEMBLY (R180A)

Final Drive Housing (Cont'd)




8. Loosen drive pinion nut.

Tool number:
ST38060002




9. Remove companion flange with puller.




10. Take out drive pinion together with pinion rear bearing inner cone, drive pinion bearing spacer and pinion bearing adjusting washer.

11. Remove front oil seal and pinion front bearing inner cone.



12. Remove pinion front and rear bearing outer races with brass drift.



13. Remove pinion rear bearing inner cone and drive pinion adjusting washer.

Assembly:
ST30905000
Tool number:
ST30031000

Differential Case

1. Remove side bearing inner cones.

To prevent damage to bearing, engage puller jaws in grooves.


Assembly:

ST33065001



Tool number:

(A) ST33051001

(B) ST33061000




Be careful not to confuse the right and left hand parts.



2. Loosen ring gear bolts in a criss-cross fashion.


3. Tap ring gear off differential case with a soft hammer.

Tap evenly all around to keep ring gear from binding.




4. Separate L.H. and R.H. differential cases.

Put match marks on both L.H. and R.H. differential cases.




Extension Tube and Differential Side Shaft


1. Remove differential side shaft assembly from extension tube.



2. Cut rear axle bearing collar with cold chisel. Be careful not to damage differential side shaft.




3. Install differential side shaft into extension tube and secure with bolts. Remove extension tube retainer from differential side shaft.



4. Remove grease seal.


Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping. If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).



Differential Case Assembly

Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft and thrust washers.




Bearing

1. Thoroughly clean bearing.
2. Check bearings for wear, scratches, pitting or flaking. Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.

ADJUSTMENT (R180A)

To avoid confusion while calculating bearing shims, it is absolutely necessary to stay with the metric system. If you measure anything in inches, the results **MUST** be converted to the metric system.




Drive Pinion Height

1. First prepare Tools for pinion height adjustment.

- ① Height gauge (ST31211000)
- ② Dummy shaft (ST31212000)
- ③ Collar
- ④ Feeler gauge
- ⑤ Dummy shaft spacer (ST31851000)
- ⑥ Stopper (ST31852000)
- ⑦ Preload gauge (ST3127S000)

- Use a collar which has the specifications shown at left.




2. To simplify the job, make a chart, like the one below, to organize your calculations.

LETTERS	HUNDREDTHS OF A MILLIMETER
H: Head number	
D': Figure marked on dummy shaft	
S: Figure marked on height gauge	
N: Measuring clearance	

3. Write the following numbers down in the chart.



H: Head number



ADJUSTMENT (R180A)


Drive Pinion Height (Cont'd)

D': Figure marked on dummy shaft.



S: Figure marked on height gauge.



W: Thickness of drive pinion height adjusting washer which is 3.09 mm (0.1217 in).



4. Set Tool (dummy shaft) as shown at left and tighten drive pinion nut carefully to correct preload of 1.0 to 1.3 N·m (10 to 13 kg·cm, 8.7 to 11.3 in·lb).

Tool number:

- Ⓐ Dummy shaft (ST31212000)
- Ⓑ Collar
- Ⓒ Dummy shaft spacer (ST31851000)
- Ⓓ Stopper (ST31852000)



5. Attach Tool (height gauge) to gear carrier, and measure the clearance between the height gauge and the dummy shaft face.

Tool number

- Ⓐ Height gauge (ST31211000)
- Ⓑ Dummy shaft (ST31212000)

ADJUSTMENT (R180A)

Drive Pinion Height (Cont'd)

6. Substitute these values into the equation to calculate the thickness of the washer.

If values signifying H, D' and S are not given, regard them as zero and calculate.

T (Thickness of washer)

$$= W + N - [(H - D' - S) \times 0.01] - 0.20$$

Example:

$$W = 3.09$$

$$N = 0.33$$

$$H = +2$$

$$D' = -1$$

$$S = 0$$

$$T = W + N - [(H - D' - S) \times 0.01] - 0.20$$

(1)	H	2
	-D'	-(-1)
		<hr/> +3
(2)	-S	- 0
		<hr/> +3
(3)		+3
		<hr/> x0.01
		+0.03
(4)	W	3.09
	+N	+0.33
		<hr/> 3.42
(5)		-[+0.03]
		<hr/> 3.39
(6)		-0.20
		<hr/> 3.19

7. Select the proper washer (Refer to S.D.S.)

If you cannot find the desired thickness of washer, use washer with thickness closest to the calculated value.

Example:


Calculated value ... T = 3.19 mm

Used washer ... T = 3.18 mm


Side Bearing Preload

1. To simplify the job, make a chart like the one below to organize your calculations.


LETTERS	HUNDREDTHS OF A MILLIMETER
A – Left housing	
B – Right housing	
C – Differential case	
D – Differential case	
E – Left side bearing	
F – Right side bearing	
G ₁ – Left side retainer	
G ₂ – Right side retainer	



2. Write the following numbers down in the chart.
A & B: Figures marked on final drive housing.




C & D: Figures marked on differential case.



G₁ & G₂: Figures marked on side retainer.


ADJUSTMENT (R180A)

Side Bearing Preload (Cont'd)



3. Measure how far under the standard thickness [20 mm (0.79 in)] the side bearings are.
It will require tools shown below.


- ① Weight Block (ST32501000)
- ② Master Gauge (KV38101900)
- ③ Base Plate
- ④ Dial Indicator



4. Place the outer race of the opposite side bearing to the measured.
5. Place a weight block on the outer race, and a master gauge on the block.


Tool number:

- Ⓐ ST32501000
- Ⓑ KV38101900




6. Adjust dial indicator scale to zero.
7. Carefully slide master gauge and weight block out from under dial indicator.
8. Lubricate side bearing and place the bearing outer race and inner cone to be measured on the opposite side outer race.

If the bearing assembly is placed on the base plate, the bearing width cannot be accurately determined due to its cage being in contact with the base plate.



9. Place weight block (ST32501000) on side bearing.
10. Slide dial indicator on weight block.



11. Turn weight block a few times to ensure that bearing is properly seated.
12. Read dial indicator.
- Normal indication:
0.10 - 0.30 mm (0.0039 - 0.0118 in)
 - If the needle fluctuates erratically then bearing is either dirty or defective and should be cleaned or replaced.

ADJUSTMENT (R180A)

Side Bearing Preload (Cont'd)

13. Measure both bearing in the same way and write the left side bearing measurement next to "E" and the right side bearing measurement next to "F".

14. Substitute these values into the equation to calculate the thickness of the shim.

If values signifying A, B, C, D, G₁ and G₂ are not given, regard them as zero and calculate.

Left side:

$$T_1 = (A + C + G_1 - D) \times 0.01 + 0.76 - E$$

Right side:

$$T_2 = (B + D + G_2) \times 0.01 + 0.76 - F$$

Example

A = 5	E = 0.11
B = 5	F = 0.15
C = 3	G ₁ = 4
D = 3	G ₂ = 1

Left side:

$$\begin{aligned} T_1 &= (A + C + G_1 - D) \times 0.01 + 0.76 - E \\ &= (5 + 3 + 4 - 3) \times 0.01 + 0.76 - 0.11 \end{aligned}$$

(1)	A	5
	+ C	+ 3
		8
	+ G ₁	+ 4
		12
	- D	- 3
		9
(2)		9
		x0.01
		0.09
(3)		0.09
		+ 0.76
		0.85
(4)		0.85
	- E	- 0.11
		0.74

$$\therefore T_1 = 0.74 \text{ mm}$$

Right side:

$$\begin{aligned} T_2 &= (B + D + G_2) \times 0.01 + 0.76 - F \\ &= (5 + 3 + 1) \times 0.01 + 0.76 - 0.15 \end{aligned}$$

(1)	B	5
	+ D	+ 3
		8
	+ G ₂	+ 1
		9
(2)		9
		x0.01
		0.09
(3)		0.09
		+ 0.76
		0.85
(4)		0.85
		- 0.15
		0.70

$$\therefore T_2 = 0.70 \text{ mm}$$


15. Select the proper shims (Refer to S.D.S.).

If you cannot find the desired thickness of shims, use shims with the total thickness closest to the calculated value.


Tooth Contact

Gear tooth contact pattern check is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear sets which are not positioned properly in relation to one another may be noisy, or have short life span or both. With a pattern check, the most desirable contact for low noise level and long life can be assured.






1. Thoroughly clean ring gear and drive pinion teeth.
2. Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.




3. Hold companion flange steady by hand and rotate the ring gear in both directions.


Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.




To correct, increase thickness of pinion height adjusting washer in order to bring drive pinion close to ring gear.



To correct, reduce thickness of pinion height adjusting washer in order to make drive pinion go away from ring gear.



Correct tooth contact



When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent.


Extension Tube and Differential Side Shaft

1. Measure rear axle bearing end play.


Rear axle bearing end play (A-B):

0.1 mm (0.0039 in) or less


The end play can be adjusted with bearing adjusting shim
(Refer to S.D.S.)




2. Install oil seal.



3. Install the spacer, grease seal, extension tube retainer, adjusting shim, shim and shim collar onto the differential side shaft.
4. Install differential side shaft assembly into extension tube.





Differential Case


1. Measure clearance between side gear thrust washer and differential case.

Clearance between side gear thrust washer and differential case (A – B):


0.10 - 0.20 mm (0.0039 - 0.0079 in)

The clearance can be adjusted with side gear thrust washer (Refer to S.D.S.).

2. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see the turn properly.




3. Install L.H. and R.H. differential cases.



4. Place differential case on ring gear.

5. Apply locking agent [Locktite (stud lock) or equivalent] to ring gear bolts, and install them.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.



6. Press-fit side bearing inner cones on differential case with Tool.

Tool number:

(A) ST33230000

(B) ST33061000



Final Drive Housing

1. Press-fit front and rear bearing outer races with Tools.

Tool number:

- (A) ST30611000
- (B) ST30621000
- (C) ST30701000

2. Select pinion bearing adjusting washer and drive pinion bearing spacer, referring to Adjustment.




3. Install drive pinion height adjusting washer in drive pinion, and press-fit rear bearing inner cone in it, using press and Tool.

Assembly:


ST30905000

Tool number:

ST30901000



4. Place pinion front bearing inner cone in final drive housing.




5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.

Tool number:


ST30720000

ASSEMBLY (R180A)


Final Drive Housing (Cont'd)



6. Place drive pinion bearing spacer, pinion bearing adjusting washer and drive in final drive housing.



7. Insert companion flange into drive pinion by tapping the companion flange with a soft hammer.




8. Tighten pinion nut to the specified torque.

The threaded portion of drive pinion and pinion nut should be free from oil or grease.

Tool number:

ST38060002



9. Turn drive pinion in both directions several revolutions, and measure pinion bearing preload.

Tool number:


ST3127S000

Pinion bearing preload:

1.1 - 1.7 N·m

(11 - 17 kg-cm, 9.5 - 14.8 in-lb)

When pinion bearing preload is outside the specifications, replace pinion bearing adjusting washer and spacer with a different thickness.



10. Select side retainer adjusting washer.

Refer to Adjustment.

11. Press-fit side bearing outer race into side retainer.

Tool number:

(A) ST30611000


(B) ST30621000

DISASSEMBLY (H233B)

Differential Case (Cont'd)


4. Separate differential case.

Put match marks on both L.H. and R.H. differential cases.




Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping.
If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).



Differential Case Assembly

Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft, and thrust washers.



Bearing

1. Thoroughly clean bearing.
2. Check bearings for wear, scratches, pitting or flaking. Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.

LIMITED SLIP DIFFERENTIAL (H233B)


No. of discs and plates (One side)

Model	H233B
Friction disc	5
Friction plate	6
Spring disc	1
Spring plate	1

Differential case couple bolt

64 - 69 N·m (6.5 - 7.0 kg-m, 40 - 47 ft-lb)


Lock strap



EPD005

CAUTION:

Do not run engine when one rear wheel is off the ground.



Preparation for Disassembly CHECKING DIFFERENTIAL TORQUE

Measure differential torque with Tool.

If it is not within the specifications, inspect components of limited slip differential.

Differential torque:

353 - 392 N·m

(36 - 40 kg-m, 260 - 289 ft-lb)


Assembly:

KV38105250

Tool number:

A KV38105210

B KV38105220



Disassembly

1. Spread out lock straps.
2. Remove couple bolts using a press.

Tool number: ST33081000


3. Separate differential case A and B.
Draw out component parts (discs and plates, etc.)

Put marks on gears and pressure rings so that they can be re-installed in their original positions from which they were removed.

Inspection


CONTACT SURFACES

1. Clean the disassembled parts in suitable solvent and blow dry with compressed air.
2. If following surfaces are found with burrs or scratches smooth with oil stone.
 - ① Differential case B
 - ② Differential case A
 - ③ Side gear
 - ④ Pinion mate gear
 - ⑤ Pinion mate shaft
 - ⑥ Friction plate guide



DISC AND PLATE

1. Clean the discs and plates in suitable solvent and blow dry with compressed air.
2. Inspect discs and plates for wear, nicks and burrs.



3. To make sure that friction disc or plate is not distorted, place it on a surface plate and rotate it by hand with indicating finger of dial gauge resting against disc or plate surface.

Check the warpage.


Allowable warpage:

0.05 - 0.15 mm (0.0020 - 0.0059 in)

If it exceeds limit, replace with a new plate to eliminate possibility of clutch slippage or sticking.

LIMITED SLIP DIFFERENTIAL (H233B)

Inspection (Cont'd)



4. Measure frictional surfaces and projected portions of friction disc, friction plate and spring plate.
- If any part has worn beyond the wear limit, replace it with a new one that is the same thickness as the projected portion.

Wear limit:

0.1 mm (0.004 in) or less

Adjustment

FRICION DISC AND FRICTION PLATE END PLAY

End play of friction disc and friction plate can be calculated by using the following equation and should be adjusted within the following range.


Adjustment can be made by selecting friction disc having two different thicknesses.

End play E:

0.05 - 0.15 mm (0.0020 - 0.0059 in)

$$E = A - (B + C)$$

- A: Length of differential case contact surface to differential case inner bottom.
- B: Total thickness of friction discs, friction plates, spring disc and spring plate in differential case on one side.
- C: Length of differential case contact surface to back side of side gear.




1. Measure values of "A".

Standard length A:

49.50 - 49.55 mm (1.9488 - 1.9508 in)

LIMITED SLIP DIFFERENTIAL (H233B)

Adjustment (Cont'd)




2. Measure thickness of each disc and plate.

Total thickness "B":
19.24 - 20.26 mm (0.7575 - 0.7976 in)


No. of discs and plates (One side):

Friction disc	5
Friction plate	6
Spring disc	1
Spring plate	1



3. Measure values of "C".
 - (1) Attach a dial indicator to the base plate.
 - (2) Place differential case B on the base plate, and install a master gauge on case B.

Then adjust the dial indicator scale to zero with its tip on the master gauge.



- (3) Install pinion mate gears, side gears and pinion mate shaft in differential case B.
- (4) Set dial indicator's tip on the side gear, and read the indication.

Example:

$$\begin{aligned}
 E &= A - D \\
 &= A - (B + C) \\
 &= 0.05 \text{ to } 0.15 \text{ mm} \rightarrow \text{Specified range}
 \end{aligned}$$

$$A = 49.52 \text{ mm}$$

$$B = 19.45 \text{ mm}$$

$$C = 29.7 \text{ mm}$$

$$D = B + C$$

$$B \dots 19.45$$

$$+ C \dots 29.7$$

$$\hline 49.15$$

$$E = A - D$$


$$A \dots 49.52$$

$$- D \dots 49.15$$

$$\hline 0.37$$

From the above equation, end play of 0.37 mm exceeds the specified range of 0.05 to 0.15 mm.
 Select suitable discs and plates to adjust correctly. (Refer to S.D.S.)

LIMITED SLIP DIFFERENTIAL (H233B)




Assembly

Prior to assembling discs and plates, properly lubricate them by dipping them in limited slip differential oil.


1. Alternately position specified number of friction plates and friction discs on rear of side gear.

Always position a friction plate first on rear of side gear.




2. Install spring disc.

Align the twelve angular holes in spring disc with the hexagonal area of the side gear.




3. Install spring plate.



4. Install friction plate guides.

Correctly align the raised portions of friction plates, and apply grease to inner surfaces of friction plate guides to prevent them from falling.




5. Install differential case B over side gear, discs, plates and friction plate guide assembly.


- Install differential case B while supporting friction plate guides with your middle finger inserted through oil hole in differential case.
- Be careful not to detach spring disc from the hexagonal part of the side gear.

LIMITED SLIP DIFFERENTIAL (H233B)

Assembly (Cont'd)




6. Install pinion mate gears and pinion shaft to differential case B.




7. Install side gear to pinion mate gears.
8. Install each disc and plate.

Use same procedures as outlined in steps 1. through 4. above.



9. Install differential case A.

Position differential cases A and B by correctly aligning marks stamped on cases.



10. Tighten differential case bolts.

[T]: 64 - 69 N·m (6.5 - 7.0 kg-m, 47 - 51 ft-lb)

11. Place ring gear on differential case and install new lock straps and bolts.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.


Then bend up lock straps to lock the bolts in place.

12. Install side bearing inner cone.

13. Check differential torque.

ADJUSTMENT (H233B)

To avoid confusion while calculating bearing shims, it is absolutely necessary to stay with the metric system. If you measure anything in inches, the results **MUST** be converted to the metric system.



Drive Pinion Height


1. First prepare Tools for pinion height adjustment.

Assembly ① ②:
ST3125500

- ① Height Gauge (ST31251000)
- ② Dummy Shaft (ST31181001)
- ③ Spacer [thickness: 2.50 mm (0.0984 in)]
- ④ Feeler Gauge


2. To simplify the job, make a chart, like the one below, to organize your calculations.

LETTERS	HUNDREDTHS OF A MILLIMETER
H: Head number	
D': Figure marked on dummy shaft	
S: Figure marked on height gauge	
N: Measuring clearance	



3. Write the following numbers down in the chart.
H: Head number



D': Figure marked on dummy shaft




ADJUSTMENT (H233B)

Drive Pinion Height (Cont'd)

S: Figure marked on height gauge



4. Place pinion rear bearing inner race and Tools on gear carrier.



5. Attach Tool (Height gauge) to gear carrier, and measure the clearance between the height gauge tip and the dummy shaft face.

ADJUSTMENT (H233B)

Drive Pinion Height (Cont'd)

6. Substitute these values into the equation to calculate the thickness of the washer.

If values signifying H, D' and S are not given, regard them as zero and calculate.

$$T \text{ (Thickness of washer)} = N - [(H - D' - S) \times 0.01] + 3.05$$

Example:

$$N = 0.30$$

$$H = 2$$

$$D' = -1$$

$$S = 0$$

$$\begin{aligned} T &= N - [(H - D' - S) \times 0.01] + 3.05 \\ &= 0.30 - [(2 - (-1) - 0) \times 0.01] + 3.05 \end{aligned}$$

(1)	H.....	2
	-D'	-(-1)
		<hr/>
		3

	-S	-0
		<hr/>
		3

(2)		3
		<hr/>
		x 0.01
		0.03

(3)	N	0.30
		<hr/>
		-0.03
		0.27

(4)		0.27
		<hr/>
		+ 3.05
		3.32

$$\therefore T = 3.32$$

7. Select the proper washer (Refer to S.D.S.).

If you cannot find the desired thickness of washer, use washer with thickness closest to the calculated value.

Example:


Calculated value ... T = 3.32 mm

Used washer ... T = 3.33 mm


Tooth Contact

Gear tooth contact pattern check is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear sets which are not positioned properly in relation to one another may be noisy, or have short life span or both. With a pattern check, the most desirable contact for low noise level and long life can be assured.




1. Thoroughly clear ring gear and drive pinion teeth.
2. Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.



3. Hold companion flange steady by hand and rotate the ring gear in both directions.

Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.




When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent.

Differential Carrier

1. Press-fit front and rear bearing outer races with Tools.

Tool number:


- (A) ST30611000
- (B) ST30621000
- (C) ST30613000




2. Select drive pinion height adjusting washer, referring to Adjustment.
3. Install drive pinion adjusting washer in drive pinion, and press-fit pinion rear bearing inner cone in it with press and Tool.

Tool number:

ST30901000




4. Place pinion front bearing inner cone in gear carrier.



5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.


Tool number:

- (A) ST30720000
- (B) KV38102510




ASSEMBLY (H233B)


Differential Carrier (Cont'd)



6. Install drive pinion bearing spacer, pinion bearing adjusting shim and drive pinion in gear carrier.



7. Insert companion flange into drive pinion by tapping the companion flange with a soft hammer.




8. Tighten pinion nut to specified torque.

The threaded portion of drive pinion and pinion nut should be free from oil or grease.

Tool number:

KV38104700



9. Turn drive pinion in both directions several times, and measure pinion bearing preload.


Tool number:

ST3127S000

Pinion bearing preload:

167 - 255 N·m


(17 - 26 kg-cm, 15 - 23 in-lb)



10. Install differential case assembly with side bearing outer races into gear carrier.


ASSEMBLY (H233B)

Differential Carrier (Cont'd)




11. Position side bearing on gear carrier with threads properly engaged; screw in adjusters lightly at this stage of assembly.

Tool number:
ST32580000




12. Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.

- Do not tighten at this point to allow further tightening of side bearing adjusters.



13. Tighten both right and left side bearing adjusters alternately and measure ring gear backlash and total preload at the same time. Adjust right and left side bearing adjusters by tightening them alternately so that proper ring gear backlash and total preload can be obtained.

Ring gear-to-drive pinion backlash:
0.15 - 0.20 mm (0.0059 - 0.0079 in)



- When checking preload, turn drive pinion in both directions several times to set bearing rollers.

Tool number:
ST3127S000


The total pinion bearing preload value with the differential case assembly should be in accordance with the same value measured without the differential case assembly. (See point 9). The relationship between both is:

Pinion bearing preload


With differential case assembly		Without differential case assembly	
kg-cm	N·m	kg-cm	N·m
14	1.4	17 - 23	1.7 - 2.3
15	1.5	18 - 24	1.8 - 2.4
16	1.6	19 - 25	1.9 - 2.5
17	1.7	20 - 26	2.0 - 2.6

ASSEMBLY (H233B)


Differential Carrier (Cont'd)



14. Tighten side bearing cap bolts.

: 83 - 103 N·m (8.5 - 10.5 kg-m, 62 - 76 ft-lb)

15. Install side lock finger in place to prevent rotation during operation.



16. Check runout of ring gear with a dial indicator.

Runout limit:

0.08 mm (0.0031 in)

- If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.
- If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.

17. Check tooth contact (Refer to Adjustment).

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Propeller Shaft

GENERAL SPECIFICATIONS

Unit: mm (in)


Portion	Front	Rear	
Propeller shaft model	2F71H	2S71H	2S80B
Number of joints	2		
Coupling method with transmission	Flange type	Sleeve type	
Types of journal bearings	Solid type (disassembly type)		
Shaft length (Spider to spider) mm (in)	542 (21.34)	965	950 (37.40)
Shaft outer diameter mm (in)	65 (2.56)	75	65 (2.56)

INSPECTION AND ADJUSTMENT

Front propeller shaft

Unit: mm (in)

Propeller shaft model	2F71H
Journal axial play limit	0.02 (0.0008)
Propeller shaft runout limit	0.6 (0.024)
Measuring point A	126 (4.96)




SPD996

Rear propeller shaft

Unit: mm (in)

Propeller shaft model	2S71H	2S80B
Journal axial play limit	0.02 (0.0008)	
Propeller shaft runout limit	0.6 (0.024)	
Measuring point		
A	300	280 (11.02)
B	473	475 (18.70)
C	300	280 (11.02)



NPD004

Available snap rings

2F71H models

Unit: mm (in)

Thickness mm (in)	ID color	Part number
1.99 (0.0783)	White	37146-01G00
2.02 (0.0795)	Yellow	37147-01G00
2.05 (0.0807)	Red	37148-01G00
2.08 (0.0819)	Green	37149-01G00
2.11 (0.0831)	Blue	37150-01G00
2.14 (0.0843)	Light brown	37151-01G00
2.17 (0.0854)	Pink	37152-01G00
2.20 (0.0866)	No paint	37153-01G00

2S71H/2S80B models

Thickness mm (in)	ID color	Part number
1.99 (0.0783)	White	37146-C9400
2.02 (0.0795)	Yellow	37147-C9400
2.05 (0.0807)	Red	37148-C9400
2.08 (0.0819)	Green	37149-C9400
2.11 (0.0831)	Blue	37150-C9400
2.14 (0.0843)	Light Brown	37151-C9400
2.17 (0.0854)	Pink	37152-C9400
2.20 (0.0866)	No paint	37153-C9400

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Final Drive

GENERAL SPECIFICATIONS

Front final drive	R180A
	4-pinion
Oil capacity (Approx.) ℓ (Imp pt)	1.3 (2-1/4)
Rear final drive	H233B
	L.S.D.*
Oil capacity (Approx.) ℓ (Imp pt)	2.8 (4-7/8)
Gear ratio	4.625
Number of teeth	
Ring gear	37
Drive pinion	8

* Limited Slip Differential

INSPECTION AND ADJUSTMENT (R180A)

Ring gear runout

Ring gear runout limit mm (in)	0.05 (0.0020)
--------------------------------	---------------

Axle bearing adjustment

Axle bearing end play mm (in)	0 - 0.1 (0 - 0.004)
Available axle bearing adjusting shims	
Thickness mm (in)	Part number
0.10 (0.0039)	38233-01G11
0.20 (0.0079)	38233-01G12
0.30 (0.0118)	38233-01G13
0.40 (0.0157)	38233-01G14

Side gear adjustment

Side gear backlash (Clearance between side gear to differential case) mm (in)	0.10 - 0.20 (0.0039 - 0.0079)
Available side gear thrust washers	
Thickness mm (in)	Part number
0.75 (0.0295)	38424-W2010
0.78 (0.0307)	38424-W2011
0.81 (0.0319)	38424-W2012
0.84 (0.0331)	38424-W2013
0.87 (0.0343)	38424-W2014
0.90 (0.0354)	38424-W2015
0.93 (0.0366)	38424-W2016
0.96 (0.0378)	38424-W2017

Drive pinion height adjustment

Available pinion height adjusting washers

Thickness mm (in)	Part number
3.09 (0.1217)	38154-P6017
3.12 (0.1228)	38154-P6018
3.15 (0.1240)	38154-P6019
3.18 (0.1252)	38154-P6020
3.21 (0.1264)	38154-P6021
3.24 (0.1276)	38154-P6022
3.27 (0.1287)	38154-P6023
3.30 (0.1299)	38154-P6024
3.33 (0.1311)	38154-P6025
3.36 (0.1323)	38154-P6026
3.39 (0.1335)	38154-P6027
3.42 (0.1346)	38154-P6028
3.45 (0.1358)	38154-P6029
3.48 (0.1370)	38154-P6030
3.51 (0.1382)	38154-P6031
3.54 (0.1394)	38154-P6032
3.57 (0.1406)	38154-P6033
3.60 (0.1417)	38154-P6034
3.63 (0.1429)	38154-P6035
3.66 (0.1441)	38154-P6036

Drive pinion preload adjustment

Drive pinion bearing preload adjusting method	Adjusting washer and spacer
Drive pinion preload N·m (kg-cm, in-lb)	
With front oil seal	1.1 - 1.7 (11 - 17, 9.5 - 14.8)

Available drive pinion preload adjusting washers

Thickness mm (in)	Part number
6.59 (0.2594)	38127-01G00
6.57 (0.2587)	38127-01G01
6.55 (0.2579)	38127-01G02
6.53 (0.2571)	38127-01G03
6.51 (0.2563)	38127-01G04
6.49 (0.2555)	38127-01G05
6.47 (0.2547)	38127-01G06
6.45 (0.2539)	38127-01G07
6.43 (0.2531)	38127-01G08
6.41 (0.2524)	38127-01G09
6.39 (0.2516)	38127-01G10
6.37 (0.2508)	38127-01G11
6.35 (0.2500)	38127-01G12
6.33 (0.2492)	38127-01G13
6.31 (0.2484)	38127-01G14

Available drive pinion preload adjusting spacers

Length mm (in)	Part number
52.20 (2.0551)	38130-G2300
52.40 (2.0630)	38131-G2301
52.60 (2.0709)	38132-G2302
52.80 (2.0787)	38133-G2303
53.00 (2.0866)	38134-G2304
53.20 (2.0945)	38135-G2305

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Final Drive (Cont'd)

Side bearing adjustment

Differential carrier assembly turning resistance N (kg, lb)	34.3 - 39.2 (3.5 - 4.0, 7.7 - 8.8)
Side bearing adjusting method	Adjusting shim
Available side retainer adjusting shims	
Thickness mm (in)	Part number
0.20 (0.0079)	38453-01G00
0.25 (0.0098)	38453-01G01
0.30 (0.0118)	38453-01G02
0.40 (0.0157)	38453-01G03
0.50 (0.0197)	38453-01G04

Total preload adjustment

Total preload N·m (kg-cm, in-lb)	1.2 - 2.3 (12 - 23, 8.7 - 20.0)
Ring gear backlash mm (in)	0.13 - 0.18 (0.0051 - 0.0071)

INSPECTION AND ADJUSTMENT (H233B)

Ring gear runout

Ring gear runout limit mm (in)	0.08 (0.0031)
--------------------------------	---------------

Differential torque adjustment

Differential torque N·m (kg-m, ft-lb)	353 - 392 (36 - 40, 260 - 289)
Number of discs and plates	
Friction disc	5
Friction plate	6
Spring disc	1
Spring plate	1
Wear limit of plate and disc mm (in)	0.1 (0.004)
Allowable warpage of friction disc and plate mm (in)	0.05 - 0.15 (0.0020 - 0.0059)

Available discs and plates

Part name	Thickness mm (in)	Part number
Friction disc	1.48 - 1.52 (0.0583 - 0.0598)	38433-C6000
	1.58 - 1.62 (0.0622 - 0.0638)	38433-C6001
Friction plate	1.48 - 1.52 (0.0583 - 0.0598)	38432-C6000
Spring disc	1.48 - 1.52 (0.0583 - 0.0598)	38436-C6000
Spring plate	1.48 - 1.52 (0.0583 - 0.0598)	38435-C6010

Drive pinion height adjustment

Available pinion height adjusting washers

Thickness mm (in)	Part number
2.58 (0.1016)	38151-01J00
2.61 (0.1028)	38151-01J01
2.64 (0.1039)	38151-01J02
2.67 (0.1051)	38151-01J03
2.70 (0.1063)	38151-01J04
2.73 (0.1075)	38151-01J05
2.76 (0.1087)	38151-01J06
2.79 (0.1098)	38151-01J07
2.82 (0.1110)	38151-01J08
2.85 (0.1122)	38151-01J09
2.88 (0.1134)	38151-01J10
2.91 (0.1146)	38151-01J11
2.94 (0.1157)	38151-01J12
2.97 (0.1169)	38151-01J13
3.00 (0.1181)	38151-01J14
3.03 (0.1193)	38151-01J15
3.06 (0.1205)	38151-01J16
3.09 (0.1217)	38151-01J17
3.12 (0.1228)	38151-01J18
3.15 (0.1240)	38151-01J19
3.18 (0.1252)	38151-01J60
3.21 (0.1264)	38151-01J61
3.24 (0.1276)	38151-01J62
3.27 (0.1287)	38151-01J63
3.30 (0.1299)	38151-01J64
3.33 (0.1311)	38151-01J65
3.36 (0.1323)	38151-01J66
3.39 (0.1335)	38151-01J67
3.42 (0.1346)	38151-01J68
3.45 (0.1358)	38151-01J69
3.48 (0.1370)	38151-01J70
3.51 (0.1382)	38151-01J71
3.54 (0.1394)	38151-01J72
3.57 (0.1406)	38151-01J73
3.60 (0.1417)	38151-01J74
3.63 (0.1429)	38151-01J75
3.66 (0.1441)	38151-01J76

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Final Drive (Cont'd)

Drive pinion preload adjustment

Drive pinion bearing preload adjusting method	Adjusting shim and spacer
Drive pinion preload N·m (kg-cm, in-lb)	1.4 - 1.7 (14 - 17, 12 - 15)
Without front oil seal	1.2 - 1.5 (12 - 15, 10 - 13)

Available drive pinion preload adjusting shims

Thickness mm (in)	Part number
2.31 (0.0909)	38125-82100
2.33 (0.0917)	38126-82100
2.35 (0.0925)	38127-82100
2.37 (0.0933)	38128-82100
2.39 (0.0941)	38129-82100
2.41 (0.0949)	38130-82100
2.43 (0.0957)	38131-82100
2.45 (0.0965)	38132-82100
2.47 (0.0972)	38133-82100
2.49 (0.0980)	38134-82100
2.51 (0.0988)	38135-82100
2.53 (0.0996)	38136-82100
2.55 (0.1004)	38137-82100
2.57 (0.1012)	38138-82100
2.59 (0.1020)	38139-82100

Available drive pinion preload adjusting spacers

Length mm (in)	Part number
4.50 (0.1772)	38165-76000
4.75 (0.1870)	38166-76000
5.00 (0.1969)	38167-76000
5.25 (0.2067)	38166-01J00
5.50 (0.2165)	38166-01J10

Total preload adjustment

Total preload N·m (kg-cm, in-lb)	1.7 - 2.5 (17 - 25, 15 - 22)
Ring gear backlash mm (in)	0.15 - 0.20 (0.0059 - 0.0079)
Side bearing adjusting method	Side adjuster