

# MKS Type i-Baratron DA01A Digital DeviceNet Capacitance Manometer



*Copyright © 2016 by MKS Instruments, Inc.*

*All rights reserved. No part of this work may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or by any information storage or retrieval system, except as may be expressly permitted in writing by MKS Instruments, Inc.*

*Printed in the United States of America*

Baratron® is a registered trademark of MKS Instruments, Inc., Andover, MA

DeviceNet™ is a trademark of Open DeviceNet Vendor Association, Coral Springs, FL

SEMI® is a registered trademark of Semiconductor Equipment and Materials International, Mountain View, CA

Swagelok® and VCR® are registered trademarks of Swagelok Co., Solon, OH

Inconel® is a registered trademark of Inco Alloys International, Huntington, WV

## Table of Contents

Pressure Transducer Safety Information.....	1
Symbols Used in This Instruction Manual.....	1
Symbols Found on the Unit .....	2
Safety Procedures and Precautions .....	3
Sicherheitshinweise für den Druckmeßumformer .....	5
In dieser Betriebsanleitung vorkommende Symbole .....	5
Erklärung der am Gerät angebrachten Symbole .....	6
Sicherheitsvorschriften und Vorsichtsmaßnahmen.....	7
Informations relatives à la sécurité pour le transducteur de pression .....	9
Symboles utilisés dans ce manuel d'utilisation .....	9
Symboles apparaissant sur l'unité .....	10
Mesures de sécurité et précautions .....	11
Medidas de seguridad del transductor de presión .....	13
Símbolos usados en este manual de instrucciones .....	13
Símbolos hallados en la unidad.....	14
Procedimientos y precauciones de seguridad.....	15
Chapter One: General Information .....	17
Introduction.....	17
DeviceNet Transducer Object Model .....	18
Definitions .....	19
References.....	20
How This Manual is Organized .....	20
Customer Support .....	21
Chapter Two: Installation .....	23
Unpacking the Type DA01A Unit .....	23
Unpacking Checklist.....	23
Interface Cables .....	23
Generic Shielded Cable Guidelines .....	24
Product Location and Requirements.....	25

Operating Environmental Requirements.....	25
Safety Conditions.....	25
Power Requirements .....	25
Setup .....	26
Dimensions .....	26
Fittings .....	27
Interface Connectors .....	27
LED Indicators.....	27
Zero Pushbutton .....	28
Mounting Instructions.....	28
Electrical Information .....	29
Grounding .....	29
Connectors .....	29
Startup.....	30
Power-Up.....	30
Warm Up Time .....	31
Zero Adjustment .....	31
System Status.....	31
Reporting the Pressure Value.....	32
Suggested Pressures for Reading and Control .....	32
Adjusting the Zero .....	33
Coarse Zero Adjustments.....	33
Zero with Offset Adjustments.....	33
Adjusting the Analog and Digital Zero.....	34
Zero Adjustments Modes.....	35
Chapter Three: Overview.....	39
General Information.....	39
Sensor.....	39
Signal Conditioner/Electronics .....	39
Pressure Measurement .....	40
Top Panel Components .....	42
Digital Communications Connector .....	42
OneTouch Coarse Zero Push Button .....	42

---

Analog Interface Connector.....	42
DeviceNet Status LEDs .....	42
Module Status LED .....	42
Network Status LED.....	43
Data Rate and Node Address Switches.....	43
Fault Conditions.....	45
Minor Faults.....	45
Major Faults.....	45
Trip Points.....	46
Trip Point Hysteresis .....	46
Trip Point Settling Time .....	46
Labels.....	47
Band Label.....	47
Serial Number Label.....	47
Chapter Four: Operation .....	49
General Information.....	49
Operating Modes.....	49
DeviceNet Messaging Protocol.....	49
Message Formats .....	50
CAN Identifier Field.....	50
CAN Data Field .....	52
Objects .....	55
Identity Object .....	57
Identity Object Instance Attributes .....	57
Identity Object Supported Services .....	58
DeviceNet Object.....	59
DeviceNet Object Class Attribute.....	59
DeviceNet Object Instance Attributes .....	59
DeviceNet Object Supported Services.....	61
Assembly Object.....	62
Assembly Object Instances.....	62
Assembly Object Instance Attribute .....	63
Assembly Object Supported Service .....	63

Connection Object .....	64
Connection Object Instances.....	64
Explicit Messaging Instance Attributes .....	65
I/O Poll Messaging Instance Attributes .....	66
Connection Object Supported Services .....	68
S-Analog Sensor Object.....	69
Customer Supported Attributes.....	69
Pressure Units Support.....	74
Specific Services.....	74
Device Configuration Object .....	75
Device Configuration Object Instance Attributes.....	75
Device Configuration Object Supported Services .....	75
S-Device Supervisor Object.....	76
Class Specific Attributes.....	76
S-Device Supervisor Object Supported Services.....	86
Chapter Five: Maintenance and Troubleshooting .....	87
General Information.....	87
Maintenance.....	87
Zero Adjustment .....	87
Troubleshooting .....	88
Appendix A: Product Specifications.....	89
Digital Communication Specifications .....	89
Electrical Specifications.....	90
Environmental Specifications .....	91
Performance Specifications .....	92
Physical Specifications .....	93
Appendix B: Model Code Explanation.....	95
Appendix C: Command Summary .....	99
Attribute Summary.....	99
Supported Service Summary.....	107
Reset .....	109
Recover .....	109

---

Abort .....	109
Get Attribute Single .....	110
Set Attribute Single.....	110
Restore Default .....	111
Allocate Master/Slave.....	111
Release Master/Slave.....	112
Lock .....	112
Unlock.....	113
Perform Coarse Zero Offset (0x32) .....	113
Appendix D: Example Messages .....	115
General Information.....	115
Explicit Messaging .....	115
Example 1: Sending an Explicit Request Message.....	116
Example 2: Interpreting a Successful Explicit Message Response.....	118
Example 3: Interpreting an Explicit Message Error Response .....	120
I/O Poll Messaging .....	122
Example 1: Sending an I/O Poll Request Message.....	122
Example 2: Interpreting an I/O Poll Response Message.....	123
Index .....	125

## List of Figures

Figure 1: DeviceNet Transducer Object Model.....	18
Figure 2: Top View Dimensions of the DA01A Transducer .....	26
Figure 3: Side View Dimensions of the DA01A Transducer .....	26
Figure 17: Push-Button Zero with No Offset.....	35
Figure 18: Zeroing using “Calibrate at nonzero” method.....	36
Figure 5: Analog and Digital Pressure Calculation.....	41
Figure 6: Top Panel Components.....	42
Figure 7: Data Rate Rotary Switch .....	44
Figure 8: Node Address Rotary Switches .....	44
Figure 9: Band Label .....	47
Figure 10: Serial Number Label.....	47
Figure 11: Explicit Request Message.....	116
Figure 12: Explicit Request Message Components .....	117
Figure 13: Successful Explicit Message Response .....	118
Figure 14: Successful Explicit Message Response Components .....	119
Figure 15: Explicit Message Error Response.....	120
Figure 16: Explicit Message Error Response Components.....	121
Figure 17: I/O Poll Request Message .....	122
Figure 18: I/O Poll Request Message Components .....	123
Figure 19: Successful I/O Poll Response Message .....	123
Figure 20: Successful I/O Poll Response Message Components.....	124



## List of Tables

Table 1: Definition of Symbols Found on the Unit .....	2
Tabelle 2: Bedeutung der am Gerät angebrachten Symbole.....	6
Tableau 3: Définition des symboles apparaissant sur l'unité .....	10
Tabla 4: Definición de los símbolos hallados en la unidad.....	14
Table 5: Definitions .....	19
Table 6: References.....	20
Table 7: Interface Cables .....	24
Table 8: Power Supply Requirements.....	25
Table 9: Digital Communications Connector Pinout.....	29
Table 10: Analog Interface Connector Pinout .....	30
Table 11: Warm Up Time .....	31
Table 12: Lowest Suggested Pressures for Reading and Control .....	32
Table 13: Highest Pressures Suggested for Proper Zero Adjustment.....	34
Table 14: Module Status LED Indicators .....	43
Table 15: Network Status LED Indicators.....	43
Table 16: Fault Conditions.....	45
Table 17: CAN Identifier Field.....	52
Table 18: CAN Data Field.....	53
Table 19: Object Classes in the DA01A Transducer .....	56
Table 20: Identity Object Instance Attributes .....	57
Table 21: Identity Object Supported Services .....	58
Table 22: DeviceNet Object Class Attribute.....	59
Table 23: DeviceNet Object Instance Attributes .....	59
Table 24: DeviceNet Object Supported Services.....	61
Table 25: Assembly Object Instances.....	62
Table 26: Assembly Object Instance Attribute .....	63
Table 27: Assembly Object Supported Service .....	63
Table 28: Connection Object Instances .....	64
Table 29: Explicit Messaging Instance Attributes .....	65
Table 30: I/O Poll Messaging Instance Attributes .....	66
Table 31: Poll Response Setup of the Produced_Connection_Path.....	67




Table 32: Poll Response Assembly Instance 2 .....	68
Table 33: Poll Response Assembly Instance 5 .....	68
Table 34: Connection Object Supported Services .....	68
Table 35: S-Analog Sensor Class Specific Attributes.....	69
Table 36: Attribute ID # 03 Data Type .....	70
Table 37: Status Attribute Values .....	71
Table 38: S-Analog Sensor Pressure Units Support .....	74
Table 39: S-Analog Sensor Object Specific Services.....	74
Table 40: Device Configuration Object Instance Attributes.....	75
Table 41: Device Configuration Object Supported Services .....	75
Table 42: S-Device Supervisor Class Specific Attributes.....	76
Table 43: Device Status Attribute Values.....	78
Table 44: Exception Status Bit Map .....	79
Table 45: Exception Detail Alarm Bytes .....	80
Table 46: Exception Detail Warning Bytes .....	80
Table 47: Exception Detail Alarm Map.....	83
Table 48: Calibration Date Format .....	85
Table 49: S-Device Supervisor Object Supported Services.....	86
Table 50: Troubleshooting Chart .....	88
Table 51: Attribute Summary .....	99
Table 52: Supported Service Summary .....	107
Table 53: Get Attribute Single Parameters .....	110
Table 54: Set Attribute Single Parameters .....	110
Table 55: Restore Default Service Parameters.....	111
Table 56: Allocate Master/Slave Parameters .....	111
Table 57: Allocation Choice Byte Contents .....	112
Table 58: Release Master/Slave Parameter.....	112
Table 59: Release Choice Byte Contents .....	112
Table 60: Unlock Service Parameters.....	113
Table 61: Method to Issue the Coarse_Zero_Offset Service Request .....	113

## Pressure Transducer Safety Information

### Symbols Used in This Instruction Manual

Definitions of WARNING, CAUTION, and NOTE messages used throughout the manual.

---















<b>Warning</b>		<b>The WARNING sign denotes a hazard to personnel. It calls attention to a procedure, practice, condition, or the like, which, if not correctly performed or adhered to, could result in injury to personnel.</b>
<b>Caution</b>		<b>The CAUTION sign denotes a hazard to equipment. It calls attention to an operating procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of all or part of the product.</b>
<b>Note</b>		<b>The NOTE sign denotes important information. It calls attention to a procedure, practice, condition, or the like, which is essential to highlight.</b>

---

## **Symbols Found on the Unit**

The following table describes symbols that may be found on the unit.

**Table 1: Definition of Symbols Found on the Unit**

 On (Supply) IEC 417, No.5007	 Off (Supply) IEC 417, No.5008	 Earth (ground) IEC 417, No.5017	 Protective earth (ground) IEC 417, No.5019
 Frame or chassis IEC 417, No.5020	 Equipotentiality IEC 417, No.5021	 Direct current IEC 417, No.5031	 Alternating current IEC 417, No.5032
 Both direct and alternating current IEC 417, No.5033-a	 Class II equipment IEC 417, No.5172-a	 Three phase alternating current IEC 617-2 No.020206	
 Caution, refer to accompanying documents ISO 3864, No.B.3.1	 Caution, risk of electric shock ISO 3864, No.B.3.6	 Caution, hot surface IEC 417, No.5041	

## **Safety Procedures and Precautions**

**Observe the following general safety precautions during all phases of operation of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of intended use of the instrument and may impair the protection provided by the equipment. MKS Instruments, Inc. assumes no liability for the customer's failure to comply with these requirements.**

### **DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT**

Do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to an MKS Calibration and Service Center for service and repair to ensure that all safety features are maintained.

### **SERVICE BY QUALIFIED PERSONNEL ONLY**

Operating personnel must not attempt component replacement and internal adjustments. Any service must be made by qualified service personnel only.

### **USE CAUTION WHEN OPERATING WITH HAZARDOUS MATERIALS**

If hazardous materials are used, users must take responsibility to observe the proper safety precautions, completely purge the instrument when necessary, and ensure that the material used is compatible with the materials in this product, including any sealing materials.

### **PURGE THE INSTRUMENT**

After installing the unit, or before removing it from a system, purge the unit completely with a clean, dry gas to eliminate all traces of the previously used flow material.

### **USE PROPER PROCEDURES WHEN PURGING**

This instrument must be purged under a ventilation hood, and gloves must be worn for protection.

### **DO NOT OPERATE IN AN EXPLOSIVE ENVIRONMENT**

To avoid explosion, do not operate this product in an explosive environment unless it has been specifically certified for such operation.

### **USE PROPER FITTINGS AND TIGHTENING PROCEDURES**

All instrument fittings must be consistent with instrument specifications, and compatible with the intended use of the instrument. Assemble and tighten fittings according to manufacturer's directions.

### **CHECK FOR LEAK-TIGHT FITTINGS**

Carefully check all vacuum component connections to ensure leak-tight installation.

**OPERATE AT SAFE INLET PRESSURES**

Never operate at pressures higher than the rated maximum pressure (refer to the product specifications for the maximum allowable pressure).

**INSTALL A SUITABLE BURST DISC**

When operating from a pressurized gas source, install a suitable burst disc in the vacuum system to prevent system explosion should the system pressure rise.

**KEEP THE UNIT FREE OF CONTAMINANTS**

Do not allow contaminants to enter the unit before or during use. Contamination such as dust, dirt, lint, glass chips, and metal chips may permanently damage the unit or contaminate the process.

**ALLOW PROPER WARM UP TIME FOR TEMPERATURE-CONTROLLED UNITS**

Temperature-controlled units will only meet specifications when sufficient time is allowed for the unit to meet, and stabilize at, the designed operating temperature. Do not zero or calibrate the unit until the warm up is complete.

## Sicherheitshinweise für den Druckmeßumformer

### In dieser Betriebsanleitung vorkommende Symbole

Bedeutung der mit WARNUNG!, VORSICHT! und HINWEIS gekennzeichneten Absätze in dieser Betriebsanleitung.

**Warnung!**



---

Das Symbol **WARNUNG!** weist auf eine Gefahr für das Bedienpersonal hin. Es macht auf einen Arbeitsablauf, eine Arbeitsweise, einen Zustand oder eine sonstige Gegebenheit aufmerksam, deren unsachgemäße Ausführung bzw. ungenügende Berücksichtigung zu Verletzungen führen kann.

---

**Vorsicht!**



---

Das Symbol **VORSICHT!** weist auf eine Gefahr für das Gerät hin. Es macht auf einen Bedienungsablauf, eine Arbeitsweise oder eine sonstige Gegebenheit aufmerksam, deren unsachgemäße Ausführung bzw. ungenügende Berücksichtigung zu einer Beschädigung oder Zerstörung des Gerätes oder von Teilen des Gerätes führen kann.

---

**Hinweis**



---















Das Symbol **HINWEIS** macht auf wichtige Informationen bezüglich eines Arbeitsablaufs, einer Arbeitsweise, eines Zustands oder einer sonstige Gegebenheit aufmerksam.

---

## Erklärung der am Gerät angebrachten Symbole

Nachstehender Tabelle sind die Bedeutungen der Symbole zu entnehmen, die am Gerät angebracht sein können.

**Tabelle 2: Bedeutung der am Gerät angebrachten Symbole**

			
Ein (Energie) IEC 417, No.5007	Aus (Energie) IEC 417, No.5008	Erdanschluß IEC 417, No.5017	Schutzleiteranschluß IEC 417, No.5019
			
Masseanschluß IEC 417, No.5020	Aquipotential- anschluß IEC 417, No.5021	Gleichstrom IEC 417, No.5031	Wechselstrom IEC 417, No.5032
			
Gleich- oder Wechselstrom IEC 417, No.5033-a	Durchgängige doppelte oder verstärkte Isolierung IEC 417, No.5172-a	Dreileiter- Wechselstrom (Drehstrom) IEC 617-2, No.020206	
			
Warnung vor einer Gefahrenstelle (Achtung, Dokumen- tation beachten) ISO 3864, No.B.3.1	Warnung vor gefährlicher elektrischer Spannung ISO 3864, No.B.3.6	Höhere Temperatur an leicht zugänglichen Teilen IEC 417, No.5041	



## **Sicherheitsvorschriften und Vorsichtsmaßnahmen**

**Folgende allgemeine Sicherheitsvorschriften sind während allen Betriebsphasen dieses Gerätes zu befolgen. Eine Mißachtung der Sicherheitsvorschriften und sonstiger Warnhinweise in dieser Betriebsanleitung verletzt die für dieses Gerät und seine Bedienung geltenden Sicherheitsstandards, und kann die Schutzvorrichtungen an diesem Gerät wirkungslos machen. MKS Instruments, Inc. haftet nicht für Mißachtung dieser Sicherheitsvorschriften seitens des Kunden.**

### **Niemals Teile austauschen oder Änderungen am Gerät vornehmen!**

Ersetzen Sie keine Teile mit baugleichen oder ähnlichen Teilen, und nehmen Sie keine eigenmächtigen Änderungen am Gerät vor. Schicken Sie das Gerät zwecks Wartung und Reparatur an den MKS-Kalibrierungs- und -Kundendienst ein. Nur so wird sichergestellt, daß alle Schutzvorrichtungen voll funktionsfähig bleiben.

### **Wartung nur durch qualifizierte Fachleute!**

Das Auswechseln von Komponenten und das Vornehmen von internen Einstellungen darf nur von qualifizierten Fachleuten durchgeführt werden, niemals vom Bedienpersonal.

### **Vorsicht beim Arbeiten mit gefährlichen Stoffen!**

Wenn gefährliche Stoffe verwendet werden, muß der Bediener die entsprechenden Sicherheitsvorschriften genauestens einhalten, das Gerät, falls erforderlich, vollständig spülen, sowie sicherstellen, daß der Gefahrstoff die am Gerät verwendeten Materialien, insbesondere Dichtungen, nicht angreift.

### **Spülen des Gerätes mit Gas!**

Nach dem Installieren oder vor dem Ausbau aus einem System muß das Gerät unter Einsatz eines reinen Trockengases vollständig gespült werden, um alle Rückstände des Vorgängermediums zu entfernen.

### **Anweisungen zum Spülen des Gerätes**

Das Gerät darf nur unter einer Ablufthaube gespült werden. Schutzhandschuhe sind zu tragen.

### **Gerät nicht zusammen mit explosiven Stoffen, Gasen oder Dämpfen benutzen!**

Um der Gefahr einer Explosion vorzubeugen, darf dieses Gerät niemals zusammen mit (oder in der Nähe von) explosiven Stoffen aller Art eingesetzt werden, sofern es nicht ausdrücklich für diesen Zweck zugelassen ist.

**Anweisungen zum Installieren der Armaturen!**

Alle Anschlußstücke und Armaturenteile müssen mit der Gerätespezifikation übereinstimmen, und mit dem geplanten Einsatz des Gerätes kompatibel sein. Der Einbau, insbesondere das Anziehen und Abdichten, muß gemäß den Anweisungen des Herstellers vorgenommen werden.

**Verbindungen auf Undichtigkeiten prüfen!**

Überprüfen Sie sorgfältig alle Verbindungen der Vakuumkomponenten auf undichte Stellen.

**Gerät nur unter zulässigen Anschlußdrücken betreiben!**

Betreiben Sie das Gerät niemals unter Drücken, die den maximal zulässigen Druck (siehe Produktspezifikationen) übersteigen.

**Geeignete Berstscheibe installieren!**

Wenn mit einer unter Druck stehenden Gasquelle gearbeitet wird, sollte eine geeignete Berstscheibe in das Vakuumsystem installiert werden, um eine Explosionsgefahr aufgrund von steigendem Systemdruck zu vermeiden.

**Verunreinigungen im Gerät vermeiden!**

Stellen Sie sicher, daß Verunreinigungen jeglicher Art weder vor dem Einsatz noch während des Betriebs in das Instrumenteninnere gelangen können. Staub- und Schmutzpartikel, Glassplitter oder Metallspäne können das Gerät dauerhaft beschädigen oder Prozeß und Meßwerte verfälschen.

**Bei Geräten mit Temperaturkontrolle korrekte Anwärmzeit einhalten!**

Temperaturkontrollierte Geräte arbeiten nur dann gemäß ihrer Spezifikation, wenn genügend Zeit zum Erreichen und Stabilisieren der Betriebstemperatur eingeräumt wird. Kalibrierungen und Nulleinstellungen sollten daher nur nach Abschluß des Anwärmvorgangs durchgeführt werden.

## Informations relatives à la sécurité pour le transducteur de pression

### Symboles utilisés dans ce manuel d'utilisation

Définitions des indications AVERTISSEMENT, ATTENTION, et REMARQUE utilisées dans ce manuel.

---

#### Avertissement



L'indication **AVERTISSEMENT** signale un danger pour le personnel. Elle attire l'attention sur une procédure, une pratique, une condition, ou toute autre situation présentant un risque d'accident pour le personnel, en cas d'exécution incorrecte ou de non respect des consignes.

---

#### Attention



L'indication **ATTENTION** signale un danger pour l'appareil. Elle attire l'attention sur une procédure d'exploitation, une pratique, ou toute autre situation, présentant un risque d'endommagement ou de destruction d'une partie ou de la totalité de l'appareil, en cas d'exécution incorrecte ou de non respect des consignes.

---

#### Remarque

















L'indication **REMARQUE** signale une information importante. Elle attire l'attention sur une procédure, une pratique, une condition, ou toute autre situation, présentant un intérêt particulier.

---

**Symboles apparaissant sur l'unité**

Le tableau suivant décrit les symboles pouvant apparaître sur l'unité.

**Tableau 3: Définition des symboles apparaissant sur l'unité**

			
Marche (sous tension) IEC 417, No.5007	Arrêt (hors tension) IEC 417, No.5008	Terre (masse) IEC 417, No.5017	Terre de protection (masse) IEC 417, No.5019
			
Masse IEC 417, No.5020	Equipotentialité IEC 417, No.5021	Courant continu IEC 417, No.5031	Courant alternatif IEC 417, No.5032
			
Courant continu et alternatif IEC 417, No.5033-a	Matériel de classe II IEC 417, No.5172-a	Courant alternatif triphasé IEC 617-2, No.020206	
			
Attention : se reporter à la documentation ISO 3864, No.B.3.1	Attention : risque de choc électrique ISO 3864, No.B.3.6	Attention : surface brûlante IEC 417, No.5041	

## **Mesures de sécurité et précautions**

**Prendre les précautions générales de sécurité suivantes pendant toutes les phases d'exploitation de cet appareil. Le non respect des ces précautions ou des avertissements contenus dans ce manuel constitue une violation des normes de sécurité relatives à l'utilisation de l'appareil et peut diminuer la protection fournie par l'appareil. MKS Instruments, Inc. n'assume aucune responsabilité concernant le non respect des consignes par les clients.**

### **PAS DE SUBSTITUTION DE PIÈCES OU DE MODIFICATION DE L'APPAREIL**

Ne pas installer des pièces de substitution ou effectuer des modifications non autorisées sur l'appareil. Renvoyer l'appareil à un centre de service et de calibrage MKS pour tout dépannage ou réparation afin de garantir le l'intégrité des dispositifs de sécurité.

### **DÉPANNAGE UNIQUEMENT PAR DU PERSONNEL QUALIFIÉ**

Le personnel d'exploitation ne doit pas essayer de remplacer des composants ou de faire des réglages internes. Tout dépannage doit être uniquement effectué par du personnel qualifié.

### **PRÉCAUTION EN CAS D'UTILISATION AVEC DES PRODUITS DANGEREUX**

Si des produits dangereux sont utilisés, l'utilisateur est responsable de la prise des mesures de précaution appropriées, de la purge complète de l'appareil quand cela est nécessaire, et de la garantie que les produits utilisés sont compatibles avec les composants de cet appareil, y compris les matériaux d'étanchéité.

### **PURGE DE L'APPAREIL**

Après l'installation de l'unité, ou avant son enlèvement d'un système, purger l'unité complètement avec un gaz propre et sec afin d'éliminer toute trace du produit de flux utilisé précédemment.

### **UTILISATION DES PROCÉDURES APPROPRIÉES POUR LA PURGE**

Cet appareil doit être purgé sous une hotte de ventilation, et il faut porter des gants de protection.

### **PAS D'EXPLOITATION DANS UN ENVIRONNEMENT EXPLOSIF**

Pour éviter toute explosion, ne pas utiliser cet appareil dans un environnement explosif, sauf en cas d'homologation spécifique pour une telle exploitation.

### **UTILISATION D'ÉQUIPEMENTS APPROPRIÉS ET PROCÉDURES DE SERRAGE**

Tous les équipements de l'appareil doivent être cohérents avec ses spécifications, et compatibles avec l'utilisation prévue de l'appareil. Assembler et serrer les équipements conformément aux directives du fabricant.

**VÉRIFICATION DE L'ÉTANCHÉITÉ DES CONNEXIONS**

Vérifier attentivement toutes les connexions des composants pour le vide afin de garantir l'étanchéité de l'installation.

**EXPLOITATION AVEC DES PRESSIONS D'ENTRÉE NON DANGEREUSES**

Ne jamais utiliser des pressions supérieures à la pression nominale maximum (se reporter aux spécifications de l'unité pour la pression maximum admissible).

**INSTALLATION D'UN DISQUE D'ÉCHAPPEMENT ADAPTÉ**

En cas d'exploitation avec une source de gaz pressurisé, installer un disque d'échappement adapté dans le système à vide, afin d'éviter une explosion du système en cas d'augmentation de la pression.

**MAINTIEN DE L'UNITÉ À L'ABRI DES CONTAMINATIONS**

Ne pas laisser des produits contaminants pénétrer dans l'unité avant ou pendant l'utilisation. Des produits contaminants tels que des poussières et des fragments de tissu, de glace et de métal peuvent endommager l'unité d'une manière permanente ou contaminer le processus.

**RESPECT DU TEMPS D'ÉCHAUFFEMENT APPROPRIÉ POUR LES UNITÉS À TEMPÉRATURE CONTRÔLÉE**




Les unités à température contrôlée atteignent leurs spécifications uniquement quand on leur laisse un temps suffisant pour atteindre d'une manière stable la température d'exploitation. Ne pas remettre à zéro ou calibrer l'unité tant que l'échauffement n'est pas terminé.

## Medidas de seguridad del transductor de presión

### Símbolos usados en este manual de instrucciones

Definiciones de los mensajes de advertencia, precaución y de las notas usados en el manual.

---















<b>Advertencia</b>		<b>El símbolo de advertencia indica la posibilidad de que se produzcan daños personales. Pone de relieve un procedimiento, práctica, estado, etc. que en caso de no realizarse u observarse correctamente puede causar daños personales.</b>
<b>Precaución</b>		<b>El símbolo de precaución indica la posibilidad de producir daños al equipo. Pone de relieve un procedimiento operativo, práctica, estado, etc. que en caso de no realizarse u observarse correctamente puede causar daños o la destrucción total o parcial del equipo.</b>
<b>Nota</b>		<b>El símbolo de notas indica información de importancia. Este símbolo pone de relieve un procedimiento, práctica o condición cuyo conocimiento es esencial destacar.</b>

---

## Símbolos hallados en la unidad

La tabla siguiente contiene los símbolos que puede hallar en la unidad.

**Tabla 4: Definición de los símbolos hallados en la unidad**

			
Encendido (alimentación eléctrica) IEC 417, N° 5007	Apagado (alimentación eléctrica) IEC 417, N° 5008	Puesta a tierra IEC 417, N° 5017	Protección a tierra IEC 417, N° 5019
			
Caja o chasis IEC 417, N° 5020	Equipotencialidad IEC 417, N° 5021	Corriente continua IEC 417, N° 5031	Corriente alterna IEC 417, N° 5032
			
Corriente continua y alterna IEC 417, N° 5033-a	Equipo de clase II IEC 417, N° 5172-a	Corriente alterna trifásica IEC 617-2, N° 020206	
			
Precaución. Consulte los documentos adjuntos ISO 3864, N° B.3.1	Precaución. Riesgo de descarga eléctrica ISO 3864, N° B.3.6	Precaución. Superficie caliente IEC 417, N° 5041	



## **Procedimientos y precauciones de seguridad**

Las precauciones generales de seguridad descritas a continuación deben observarse durante todas las etapas de funcionamiento del instrumento. La falta de cumplimiento de dichas precauciones o de las advertencias específicas a las que se hace referencia en el manual, constituye una violación de las normas de seguridad establecidas para el uso previsto del instrumento y podría anular la protección proporcionada por el equipo. Si el cliente no cumple dichas precauciones y advertencias, MKS Instruments, Inc. no asume responsabilidad legal alguna.

### **NO UTILICE PIEZAS NO ORIGINALES O MODIFIQUE EL INSTRUMENTO**

No instale piezas que no sean originales ni modifique el instrumento sin autorización. Para asegurar el correcto funcionamiento de todos los dispositivos de seguridad, envíe el instrumento al Centro de servicio y calibración de MKS toda vez que sea necesario repararlo o efectuar tareas de mantenimiento.

### **LAS REPARACIONES DEBEN SER EFECTUADAS ÚNICAMENTE POR TÉCNICOS AUTORIZADOS**

Los operarios no deben intentar reemplazar los componentes o realizar tareas de ajuste en el interior del instrumento. Las tareas de mantenimiento o reparación deben ser realizadas únicamente por personal autorizado.

### **TENGA CUIDADO CUANDO TRABAJE CON MATERIALES TÓXICOS**

Cuando se utilicen materiales tóxicos, es responsabilidad de los operarios tomar las medidas de seguridad correspondientes, purgar totalmente el instrumento cuando sea necesario y comprobar que el material utilizado sea compatible con los materiales del instrumento e inclusive, con todos los materiales de sellado.

### **PURGUE EL INSTRUMENTO**

Una vez instalada la unidad o antes de retirarla del sistema, purgue completamente la unidad con gas limpio y seco para eliminar todo resto de la sustancia líquida empleada anteriormente.

### **USE PROCEDIMIENTOS ADECUADOS PARA REALIZAR LA PURGA**

El instrumento debe purgarse debajo de una campana de ventilación y deben utilizarse guantes protectores.

### **NO HAGA FUNCIONAR EL INSTRUMENTO EN AmbientES CON RIESGO DE EXPLOSIÓN**

Para evitar que se produzcan explosiones, no haga funcionar este instrumento en un Ambiente con riesgo de explosiones, excepto cuando el mismo haya sido certificado específicamente para tal uso.

**USE ACCESORIOS ADECUADOS Y REALICE CORRECTAMENTE LOS PROCEDIMIENTOS DE AJUSTE**

Todos los accesorios del instrumento deben cumplir las especificaciones del mismo y ser compatibles con el uso que se debe dar al instrumento. Arme y ajuste los accesorios de acuerdo con las instrucciones del fabricante.

**COMPRUEBE QUE LAS CONEXIONES SEAN A PRUEBA DE FUGAS**

Inspeccione cuidadosamente las conexiones de los componentes de vacío para comprobar que hayan sido instalados a prueba de fugas.

**HAGA FUNCIONAR EL INSTRUMENTO CON PRESIONES DE ENTRADA SEGURAS**

No haga funcionar nunca el instrumento con presiones superiores a la máxima presión nominal (en las especificaciones del instrumento hallará la presión máxima permitida).

**INSTALE UNA CÁPSULA DE SEGURIDAD ADECUADA**

Cuando el instrumento funcione con una fuente de gas presurizado, instale una cápsula de seguridad adecuada en el sistema de vacío para evitar que se produzcan explosiones cuando suba la presión del sistema.

**MANTENGA LA UNIDAD LIBRE DE CONTAMINANTES**

No permita el ingreso de contaminantes en la unidad antes o durante su uso. Los productos contaminantes tales como polvo, suciedad, pelusa, lascas de vidrio o virutas de metal pueden dañar irreparablemente la unidad o contaminar el proceso.

**CALIENTE ADECUADAMENTE LAS UNIDADES CONTROLADAS POR MEDIO DE TEMPERATURA**

Las unidades controladas por medio de temperatura funcionarán de acuerdo con las especificaciones sólo cuando se las caliente durante el tiempo suficiente para permitir que lleguen y se estabilicen a la temperatura de operación indicada. No calibre la unidad y no la ponga en cero hasta que finalice el procedimiento de calentamiento.

# Chapter One: General Information

## Introduction


The MKS Baratron® Type DA01A Absolute Pressure Transducer with a DeviceNet™ Digital Interface is part of the MKS family of general purpose pressure transducers designed to provide accurate, reliable, and repeatable pressure measurements in the range from 1K Torr to as low as 100 mTorr Full Scale (FS) in a RoHS (Restriction of Hazardous Substances)-compliant package. The DA01A is designed specifically to meet the needs of vacuum process systems where environmental and process conditions are particularly demanding.

Temperature control of the DA01A (45° C, 80° C, and 100° C) transducers minimizes the effects of ambient or process temperature variations typically encountered in process line environments. The DA01A (45° C) controls its temperature at 45° C nominal for better thermal stability of zero. The DA01A (80° C and 100° C) transducers run at these temperatures to minimize contamination from the process. There is also DA01A option that is unheated for less demanding applications

The DA01A unit exposes only Inconel® to the process, permitting use with corrosive or dirty gases and eliminating contamination of the process with transducer materials. Measurements are independent of gas composition. Using the latest single-sided, dual-electrode Inconel transducer design, coupled with a low impedance, fixed-frequency bridge signal conditioner, this instrument is capable of withstanding high overpressure conditions (45 psia) with minimal or no shifts in output over their range. The advanced bridge signal conditioning technology provides high accuracy and operation which is extremely temperature-stable at operating pressure.

The transducer provides a digital pressure signal through the DeviceNet communications interface, or as an analog signal through a 9-pin Type DE-9S Interface connector for direct measurement. Output is linear and proportional to pressure. The operational settings of the DA01A unit are controlled using DeviceNet communications, which support 125, 250, and 500 Kb data rates. A non-volatile storage device stores the user settings.

---

**Note**  Use this manual in conjunction with the Open DeviceNet Vendor Association (ODVA) “DeviceNet Specification,” Volume I and Volume II [1, 2]; and the SEMI® Standards Device Models [3, 4, 5] to obtain a complete functional description of your device. Refer to Table 6, page 20, for a list of the documents referenced throughout this manual.

---

Protection from RF interference and noisy electrical environments is increased by the use of a metal case and internal design elements as well as surge and ESD suppression networks and RFI filtering on all inputs and outputs.


The unit is available with a variety of fittings.

Ambient and Temperature Regulated Models are available:

The DA01A (Ambient) measures pressure at ambient temperatures of 0° to 50° C (32° to 122° F).  
The DA01A (45° C) measures pressure at ambient temperatures of 15° to 40° C (59° to 104° F).  
The DA01A (80° C and 100° C) measure pressure at ambient temperatures of 15° to 50° C (59° to 122° F).

## DeviceNet Transducer Object Model

The operating information for the DeviceNet digital interface is arranged as a collection of objects (Figure 1). Specific attributes within each object control specific network or instrument features and are referenced by a unique ID number. The object models and attributes for the DA01A transducer are described in detail in *Chapter Four: Operation*, page 49.



**Figure 1: DeviceNet Transducer Object Model**

## Definitions

**Table 5: Definitions**

<b>Term</b>	<b>Description</b>
Attribute	All elementary data types are defined in [1]
ARRAY	A listing or grouping of elements of the same data type
BOOL	Boolean, which can take either a 0 or 1 value
CAN	Control Area Network, which is a specification of physical layer signaling and media access control in DeviceNet
Class Code	Definition of the Object Class toward which a request message is directed, specified as either a 8-bit or 16-bit integer
Common Service	A service, defined in [2], that can be used in multiple objects—each has a fixed set of parameters that are defined in [1]
DATE	Date information ( <i>not the ODVA definition of DATE</i> )—a structure of (1) a year of type UINT, (2) a month of type USINT, and (3) a day of type USINT (Table 48, page 85)
Full Scale (FS) Range	Defined 100% value of an attribute in its assigned units
INT	Signed 16-bit integer value between -32,768 and +32,767
Instance ID	Definition of a particular instance within an Object Class
LSB	Least Significant Bit
MSB	Most Significant Bit
Network Access	Definition of how an attribute can be accessed over the network: R = Read Only; RW = Read/Write
ODVA	Open DeviceNet Vendors Association
REAL	32-bit floating point value conforming to IEEE 754 basic single floating point format
Service Data	Carries “request specific” data
Service Type	R = Request; N = Notification; M = Mandatory
SINT	Signed 8-bit integer value
SHORT-STRING	ASCII character string with 1 byte per character—a 1 byte length precedes the string
STRUCT	Contains more than one attribute type
UINT	Unsigned 16-bit integer value between 0 and 65,535
UDINT	Unsigned (double) 32-bit integer value
ULINT	Unsigned (long) 64-bit integer value
USINT	Unsigned 8-bit integer value between 0 and 255
WORD	16-bit string

## References

Table 6 lists the documents referenced throughout this manual.

**Table 6: References**

Reference Number	Document
[1]	“DeviceNet Specification, Volume I: DeviceNet Communication Model and Protocol,” Open DeviceNet Vendors Association, Inc. Release 2.0.
[2]	“DeviceNet Specification, Volume II: DeviceNet Profiles and Object Library,” Open DeviceNet Vendors Association, Inc. Release 2.0.
[3]	“Sensor/Actuator Network Common Device Model,” SEMI Standards Document E54.1-0997.
[4]	“Sensor/Actuator Network Communication Standard for DeviceNet,” SEMI Standards Document E54.4-0997.
[5]	“Sensor/Actuator Network Specific Device Model for Capacitance Manometer Devices,” SEMI Standards Draft Document #2696.

## How This Manual is Organized

This manual is designed to provide instructions on setting up, installing, and operating a Type DA01A unit with a DeviceNet digital interface.

**Before installing your Type DA01A unit in a system and/or operating it, carefully read and familiarize yourself with all precautionary notes in the *Safety Messages and Procedures* section at the front of this manual. In addition, observe and obey all WARNING and CAUTION notes provided throughout the manual.**

- Chapter One    *General Information*, (this chapter) introduces the product and describes organization of the manual.
- Chapter Two    *Installation*, explains environmental requirements and describes mounting the instrument in your system.
- Chapter Three    *Overview*, gives a brief description of the instrument and its functionality.
- Chapter Four    *Operation*, describes the protocol, object models, attributes, and services required to operate the unit with DeviceNet digital communications.
- Chapter Five    *Maintenance and Troubleshooting*, lists maintenance required to keep the unit in good working condition and provides a checklist reference for unit malfunction.
- Appendix A    *Product Specifications*, lists the instrument specifications.
- Appendix B    *Model Code Explanation*, describes the model code used to order the instrument.
- Appendix C    *Command Summary*, lists the attributes and supported services for your device and defines the supported service parameters.
- Appendix D    *Example Messages*, describes how DeviceNet messages are generated and interpreted.

## **Customer Support**

Standard maintenance and repair services are available at all of our regional MKS Calibration and Service Centers, listed on the back cover. In addition, MKS accepts the instruments of other manufacturers for recalibration using the Primary and Transfer Standard calibration equipment located at all of our regional service centers. Should any difficulties arise in the use of your Type DA01A instrument, or to obtain information about companion products MKS offers, contact any authorized MKS Calibration and Service Center. If it is necessary to return the instrument to MKS, please obtain an RMA (Return Material Authorization) Number from the MKS Calibration and Service Center (listed on the inside of the back cover of this manual) before shipping. The RMA Number expedites handling and ensures proper servicing of your instrument.

---

**Warning**

**All returns to MKS Instruments must be free of harmful, corrosive, radioactive, or toxic materials.**

---

This page intentionally left blank.




## Chapter Two: Installation

### Unpacking the Type DA01A Unit

MKS carefully packed the Type DA01A unit to reach you in perfect operating order. Upon receiving the unit, however, you should check for defects, cracks, broken connectors, etc., to be certain damage did not occur during shipment.

---

**Note**  Do *not* discard any packing materials until you completed your inspection and are sure the unit arrived safely.

---

If you find any damage, notify your carrier and MKS immediately. If it is necessary to return the unit to MKS, obtain an RMA (Return Material Authorization) Number from the MKS Service Center (listed on the back cover of this manual) before shipping

### Unpacking Checklist

#### *Standard Equipment:*

- Type DA01A Unit
- Type DA01A Instruction Manual (this book)

#### *Optional Equipment:*


- Interface Cables (described below)

### Interface Cables

*As of July 20, 2009, most products shipped to the European Community must comply with the EMC Directive 2004/108/EEC, which covers radio frequency emissions and immunity tests. In addition, as of January 1, 1997, some products shipped to the European Community must also comply with the Product Safety Directive 92/59/EEC and Low Voltage Directive 73/23/EEC, which cover general safety practices for design and workmanship. MKS products that meet these requirements are identified by application of the CE Mark.*

To ensure compliance with EMC Directive 2004/108/EEC, an overall metal braided shielded cable, properly grounded at both ends, is required during use. No additional installation requirements are necessary to ensure compliance with Directives 92/59/EEC and 73/23/EEC.

---

**Note**  An overall metal braided, shielded cable, properly grounded at both ends, is required during use to meet CE specifications and is recommended if the environment contains high EMI/RFI noise.

---

A ferrite collar is available (Fair-Rite part number 0443167251) and is recommended for use in high RF environments. The collar is formed from two half-shells that snap together. The collar should be attached to the DeviceNet cable as close as possible to the DA01A unit.

You can purchase interface cables to all MKS companion products from MKS (Table 7) or, optionally, you can make cables that meet the appropriate cable specifications. For cables connecting to non-MKS products, you can purchase normal shielding or braided shielded cable assemblies from MKS in a nominal 10' (3 m) length, terminating in flying leads (pigtail) fashion at both ends.

**Table 7: Interface Cables**

To Connect the DA01A Unit's analog output to...	Use the MKS Cable...
PR4000, 651 or 660	CBCT27-1-10

### Generic Shielded Cable Guidelines

Follow the guidelines listed below if you choose to manufacture your own cables.

1. The cable must have an overall metal *braided* shield, covering all wires. Neither aluminum foil nor spiral shielding are as effective; using either may nullify regulatory compliance.
2. The connectors must have a metal case that has direct contact to the cable's shield on the whole circumference of the cable. The inductance of a flying lead or wire from the shield to the connector will seriously degrade the shield's effectiveness. The shield should be grounded to the connector before its internal wires exit.
3. With very few exceptions, the connector(s) must make good contact to the device's case (ground). "Good contact" is about 0.01 ohms and the ground should surround all wires. Contact to ground at just one point may not suffice.
4. For shielded cables with flying leads at one or both ends, it is important at each such end to ground the shield *before* the wires exit. Make this ground with absolute minimum length. (A ¼ inch piece of #22 wire may be undesirably long since it has approximately 5 nH of inductance, equivalent to 31 ohms at 1000 MHz). After picking up the braid's ground, keep the wires and braid flat against the case.

With very few exceptions, grounded metal covers are not required over terminal strips. If one is required, it will be stated in the Declaration of Conformity or in the instruction manual.

5. In selecting the appropriate type and wire size for cables, consider:
  - A. Voltage ratings.
  - B. Cumulative  $I^2R$  heating of all the conductors (keep them safely cool).
  - C. IR drop of the conductors, so that adequate power or signal voltage gets to the device.
  - D. Capacitance and inductance of cables that are handling fast signals (such as data lines or stepper motor drive cables).
  - E. Some cables may need internal shielding from specific wires to others. Please see the instruction manual for details regarding this matter.

## **Product Location and Requirements**

The DA01A unit meets the following criteria:

- POLLUTION DEGREE 2 in accordance with IEC 664
- Transient overvoltages according to INSTALLATION CATEGORY II

### **Operating Environmental Requirements**

- Ambient Operating Temperature: 0° to 50° C (32° to 122° F)—DA01A (Ambient)  
15° to 40° C (59° to 104° F)—DA01A (45° C)  
15° to 50° C (59° to 122° F)—DA01A (80° C)  
15° to 50° C (59° to 122° F)—DA01A (100° C)
- Ventilation requirements include sufficient air circulation

### **Safety Conditions**

The DA01A poses no safety risk under the following environmental conditions:

- Altitude: up to 6500 ft (2000 m)
- Maximum relative humidity: 80% for temperatures up to 31 °C,  
decreasing linearly to 50% at 40° C

### **Power Requirements**


The power for a DA01A should be delivered through the DeviceNet network. Power supply requirements are shown in the following table.


**Table 8: Power Supply Requirements**

	<b>DA01A (Ambient)</b>	<b>DA01A (45° C)</b>	<b>DA01A (80° and 100° C)</b>
<b>Voltage</b>	+11 to +25 VDC *	+11 to +25 VDC *	+11 to +25 VDC *
<b>Current at Warm Up</b>	200 mAmps (max)	700 mAmps (max)	1.0 Amps (max)
<b>Isolation</b>	500 [1] V	500 [1] V	500 [1] V
* Communicate within +11 to +25 VDC range. Operation within performance specifications from +18 to +25 VDC.			


## Setup

### Dimensions

**Note**  All dimensions are listed in inches with millimeters referenced in parentheses. Tolerances are  $\pm .03$  [.76 mm] unless specified otherwise.



**Figure 2: Top View Dimensions of the DA01A Transducer**



**Figure 3: Side View Dimensions of the DA01A Transducer**


## Fittings

The DA01A unit is available with the following fittings:

- ½” diameter (12.7 mm) tubulation
- Swagelok® 8-VCR® (female)
- Mini-CF (rotatable)
- NW-16-KF

## Functions and Controls

**Figure 4. *i*-Baratron® Top Panel Controls and Functions**



## Interface Connectors

The DeviceNet Interface Connector is used to connect the *i*-Baratron Capacitance Diaphragm Gauge to mains power and to the host network. It is a 5-pin male bayonet-style connector, and is located on the top surface of the product. Its pin assignments and communications protocols are listed in Section 9.1 on page 29.

This product has a second electrical connector on its top surface. This connector is a 9-pin female D-subminiature type, and it carries only the 0 – 10 VDC analog output signal. Its pin assignments are shown on page 30.

## LED Indicators

The *i*-Baratron has two (2) dual-color LED indicator lamps on its top surface. These are the Module Status LED and Network Status LED. The Network Status LED is intended to show the

status of communications from the *i*-Baratron to the network host. At startup, this LED will be blinking green, but as soon as the *i*-Baratron and network host communicate successfully, this LED changes to a solid green (i.e. not blinking). A red LED indicates that there is no signal from the network to the *i*-Baratron product.

The second LED is the Module Status LED. This LED indicates the health and operational status of the *i*-Baratron product. Upon startup, this LED is a blinking green. It changes to a solid green output when the *i*-Baratron product is working correctly and is ready for operation. A red LED indicates that there is a fatal error somewhere within the *i*-Baratron product.

## Zero Pushbutton

The zero pushbutton is used to zero the analog and digital outputs of the *i*-Baratron Capacitance Diaphragm Gauge. It can be used for this function at any pressure less than 20% of the gauge's full-scale measurement range. See pages 32-33 for a description of how the zero pushbutton should be used.

## Mounting Instructions

Mount the transducer with the inlet port pointing (vertically) downward. The transducer port can easily carry the weight of the transducer.

Although the unit can be mounted in any orientation, mounting it as suggested allows any foreign matter entering the pressure port to fall away from the diaphragm.

Isolate the unit from vibration as much as possible. When not subject to gas damping at low pressure, the diaphragm may become susceptible to resonance. The low range transducers ( $\leq 1$  Torr) are most sensitive and you should isolate them from any vibration that exists. Remember to isolate the vibration through the cable as well as through the port.

For pressure ranges less than 1 Torr, the unit should be mounted in the orientation specified in the mode code. (Refer to *Appendix B: Model Code Explanation*, page 95.)

Mount the unit vertically if the model code has the form:

↓  
DA01XXXXXXXXX **V** XXX

Mount the unit horizontally if the model code has the form:

↓  
DA01XXXXXXXXX **H** XXX

Contact MKS if you require assistance.

## **Electrical Information**

### **Grounding**

Ensure that your DA01A unit, powered from the DeviceNet network, is grounded in accordance with the requirements in the ODVA “DeviceNet Specification,” Volume I [1].

### **Connectors**

The DA01A transducer has one 5-pin micro-style digital communications connector and one 9-pin Type DE-9S analog interface connector on its top panel (Figure 2, page 26).

### **Caution**



**To prevent damage from electrostatic discharge (ESD) to the sensitive connector pins, the pins must be covered with an ESD protective cover when not in use.**

### *Digital Communications Connector*

The 5-pin male micro-style connector (with anti-rotation features) accepts the power input from the DeviceNet network and provides the interface for digital communications. This connector meets the requirements in the ODVA “DeviceNet Specification,” Volume I [1].

**Table 9: Digital Communications Connector Pinout**

<b>Pin Number</b>	<b>Assignment</b>
1	Drain
2	V+
3	V-
4	CAN_H
5	CAN_L

### *Analog Interface Connector*

The 9-pin female Type DE-9S interface connector provides the pressure output signal for direct measurement from the transducer.

**Table 10: Analog Interface Connector Pinout**

Pin Number	Assignment
1	Pressure Output
2	Reserved
3	Reserved
4	Reserved
5	Reserved
6	Reserved
7	Reserved
8	Signal Common (Pressure Output Return)
9	Reserved

#### Note



1. The 9-pin Type DE-9S analog interface connector is a new style connector, that differs from those used on other MKS Baratron transducers.
2. The “Reserved” pin assignment refers to a pin with an internal connection that may be assigned a function in the future.
3. The “No Connection” pin assignment refers to a pin with no internal connection.

## **Startup**

### **Power-Up**

At power-up, the DA01A transducer performs communications link checks and internal diagnostic checks of the EEPROM and RAM. The results of these checks are indicated by the color (green or red) and condition (solid or flashing) of the status LEDs on top of the unit (Figure 2, page 26). Refer to *DeviceNet Status LEDs*, page 42, for more information on the status LEDs.

When you apply power to your device, the following LED sequence occurs:

1. The Module Status LED flashes one time from GREEN to RED for approximately 0.25 seconds each and then turns GREEN.
2. The Network Status LED flashes one time from GREEN to RED for approximately 0.25 seconds each and then turns OFF.
3. The Module Status LED flashes from GREEN to RED for approximately 2 seconds while the device is initializing. The Network Status LED remains OFF.



4. The Module Status LED illuminates solid GREEN when the initialization is complete. The Network Status LED remains OFF until the device establishes communication with other devices on the network.

**Note**

If the power up LED sequence does not function properly, contact MKS for assistance.

**Warm Up Time**

After installation and power-up, allow the DA01A to warm up, as specified below. Ensure your device is fully stabilized and then check the transducer zero to verify the proper output.

**Table 11: Warm Up Time**

DA01A (Ambient)	DA01A (45° C)	DA01A (80° and 100° C)
½ hour all ranges	2 hours ranges 1 Torr and higher 4 hours ranges less than 1 Torr	2 hours ranges 1 Torr and higher 4 hours ranges less than 1 Torr

**Zero Adjustment**

All pressure transducers require initial and periodic zero adjustments. Prior to initial operation and during periodic maintenance you must check the transducer zero to verify the proper output. Refer to *Adjusting the Zero*, page 33, for more information.

**System Status**

Complete instructions for reporting the system status are described in detail in *S-Device Supervisor Object*, page 76. Specifically, the system status can be reported with the following attributes in the S-Device Supervisor Object:

- Exception Status (Attribute ID #0C)  
This attribute identifies whether or not any alarm or warning conditions exist. Alarms and warnings are identified as device-common, device-specific, or manufacturer-specific. Refer to *Exception Status*, page 79.
- Exception Detail Alarm (Attribute ID #0D)  
This attribute identifies the specific alarm condition(s) detected by your device. Refer to Table 47, page 83.
- Exception Detail Warning (Attribute ID #0E)  
This attribute identifies the specific warning condition(s) detected by your device. Refer to Table 47, page 83.

Refer to *Fault Conditions*, page 45, for additional information.

## Reporting the Pressure Value

The system pressure can be reported at any time using the appropriate digital communication commands. The data will be reported as either an INT or REAL value dependent upon device settings. (e.g. Data Type attribute in the S-Analog Sensor Object)

- **Explicit Request**  
S-Analog Sensor Object Attribute ID #06 (see page 69) reports the actual, corrected pressure value from -5 to 110% full scale in the specified units.
- **Polled Request**  
Assembly Object Instance ID #02 or Instance #05 report the device exception status as well as the corrected pressure value as either a scaled INT or REAL value, respectively. See Assembly Object, page 58.

## Suggested Pressures for Reading and Control

Table 12 lists the lowest suggested pressures for reading and control with the DA01A transducer.

**Table 12: Lowest Suggested Pressures for Reading and Control**

Full Scale Range (Torr)	Lowest Suggested Pressure for Reading (Torr)	Lowest Suggested Pressure for Control (Torr)
0.1	$5 \times 10^{-5}$	$5 \times 10^{-4}$
1	$5 \times 10^{-4}$	$5 \times 10^{-3}$
10	$5 \times 10^{-3}$	$5 \times 10^{-2}$
100	$5 \times 10^{-2}$	$5 \times 10^{-1}$
1000	$5 \times 10^{-1}$	$5 \times 10^0$

### *Lowest Suggested Pressures Available for Reading*

The pressures listed in the middle column of Table 12 reflect reliable and practical pressures for different range transducers. Lower readings may be obtained in environments that have stable temperature and air flow. Temperature controlled transducers can obtain repeatable pressure measurements down to  $1 \times 10^{-5}$  Torr.

### *Lowest Suggested Pressures to Use for Control with Analog Output*

The pressures listed in the last column of Table 12 are for reference and represent the pressure reading of the transducer at 50 mV signal output. A DC signal of at least 50 mV is the recommended minimum signal level to use when integrating any transducer into complex processing systems.

## **Adjusting the Zero**

The DA01A unit uses a digital zero in the calculation of the reported pressure value. Figure 5, page 39, illustrates where the digital zero is incorporated into the calculation of the pressure value.

The transducer's calibrated, analog pressure signal is measured from pin 1 on the Type DE-9S interface connector, with pin 8 as the common. (Table 10, page 30).

### **Coarse Zero Adjustments**

Digital and analog signals can be zeroed either by manually pressing the OneTouch Push Button Zero or by issuing a DeviceNet service (Service ID 0x32, the Coarse Zero Adjustment service).

The range of this adjustment is limited to approximately  $-4$  to  $+20\%$  of full scale and the assumed target is zero pressure or vacuum. The DA01A must be evacuated to a pressure below its resolution before the OneTouch Zero Push Button or Coarse Zero Adjust Service is executed. See Table 13.

### **Zero with Offset Adjustments**

The DA01A provides 2 additional methods of zeroing the digital and analog signals. These methods are called the "Output Offset" adjustment and the "Calibrate at Nonzero" adjustment, see page 113. The first method applies a user defined offset value to the reported readings. The value added, called the "Target Offset" is added to the output affecting both the digital and analog readings.

The second method of zeroing with an offset can be used when a known non-zero pressure is achieved. The known pressure is input as the "Zero Offset".

#### **Note**



---

The Target Offset pressure must still be within the zeroing limit of  $-4$  to  $+20\%$  of full scale

---

Zeroing will be performed and the offset value will be adjusted so that the current digital and analog pressure reading is set to the Zero Offset value.

If an unsuccessful response to the Zero with Offset adjustment is received, either issue the Coarse Zero Adjustment service (0x32) without offset adjustments or press the One Touch Coarse Zero Push Button.

For best results, the transducer should be under vacuum while warming up. Table 13 lists the recommended pressure levels required for proper zero adjustment.


**Table 13: Highest Pressures Suggested for Proper Zero Adjustment**

Full Scale Range (Torr)	Highest Pressure for Proper Zero Adjustment (Torr)
0.1	$< 5 \times 10^{-7}$
1	$< 5 \times 10^{-6}$
10	$< 5 \times 10^{-5}$
100	$< 5 \times 10^{-4}$
1000	$< 5 \times 10^{-3}$

### Adjusting the Analog and Digital Zero

1. Install the transducer in a system with a power supply/readout.
2. Power the transducer and allow it to warm up and stabilize.


---

**Note**  Before use, allow the DA01A (Ambient) transducer to warm up for ½ hour. Allow the DA01A (45° C, 80° C, and 100° C) to warm up for 2 hours (for ranges of 1 Torr and higher) or 4 hours (for ranges less than 1 Torr), as appropriate. Ensure the device is *fully stabilized* before you adjust the transducer zero.

---

3. Pump the unit down to a pressure below its resolution (0.01% of FS).  
For best results, pump the transducer while it is warming up. Refer to Table 13, page 34, for the recommended pressure levels for proper zero adjustment.
4. Issue the Coarse Zero Adjustment Service (0x32) to the S-Analog Sensor Object.  
Refer to page 113, for information on the required service.

---

**Note**  The Perform Fine Zero Offset (0x4B) used in the DMA/DMB is no longer available in the DA01A.

---

### Zero Adjustments Modes

The DA01A has three different modes of zero adjustments. It is important that the user become familiar with the specific application and limitations of each three modes before selecting a mode of zero adjustment. Note that each mode of zero adjustment is applied to both analog and digital pressure outputs.


#### *Mode 1. Push-Button Zero with No Offset*

**Purpose:** The unit has drifted and the output reads a non-zero value @ vacuum that needs to be offset. When pushing the button, the user wants the pressure output to read zero.

**Limit:** +/- 20% FS from the factory Zero position.

**Method:** Bring manifold pressure to vacuum level (ref to table 13 for suggested pressures for proper zero adjustment). Either push the zero push-button or perform a Coarse zero with no offset, passing attribute = 0, or not passing an attribute – see appendix C page 113).

**Notes:** Does not require connection through the Devicenet port.  
After push-button, Analog Pressure output at **100% of FS = 10V**



**Figure 4: Push-Button Zero with No Offset**

**Mode 2. Zeroing with “Calibrate at Nonzero” Service (uses Zero Offset attribute)**

**Purpose:** The user cannot achieve zero pressure. The user can achieve a known positive pressure. When pushing the button, the user wants Pout to read output equivalent to known offset zero (Target).

**Range of**

**Alignment:** +/- 5% of FS from Factory Zero position.


**Method:** Set the required offset (Zero Offset) through the Device net interface. At this target pressure, Perform a coarse zero, passing attribute = 1.

**Notes:** This feature is available only through the Device Net interface.

Example shown below:

Adjustment = .05 Fr. of FS.

After push-button, Analog Pressure output at **100% of FS = 10V**



**Figure 5: Zeroing using “Calibrate at nonzero” method**

**Mode 3. Zeroing with “Output Offset” Service (uses Target Offset attribute)**

**Purpose:** Pressure output goes into an A/D in the unipolar mode. Therefore, the user wants the pressure output to read a positive value at zero pressure.

**Limit:** +/- 5% 5% FS from the Factory Zero position.


**Method:** Set the Target (Target offset) through the Device Net interface. Now, at zero pressure, perform a coarse zero passing attribute = 2.

**Notes:** This feature is available only to customers who would use the Device net interface

Example shown below:

Adjustment = .05 Fr. of FS.

After push-button, Pressure output at **100mT = 10.5V**



using the “Output Offset” service

Figure 6: Zeroing





## Chapter Three: Overview

### **General Information**

The DA01A transducer contains a digital interface. All communication to and from the device is achieved using the DeviceNet network. Interfacing with your transducer is accomplished using the DeviceNet digital communications protocol, which gives you access to all features of the instrument.

A complete pressure transducer system requires three components to convert pressure to a linear DC voltage output:

- Sensor
- Signal Conditioner
- Power Supply

The DA01A digital transducer contains two of the required components: the sensor and signal conditioner.

The DA01A transducer power supply requirements are specified on page 25. The power is introduced to the transducer through the 5-pin micro-style connector on the top of the unit (Figure 6, page 42). The host computer for the network reports the pressure measurement.

### **Sensor**

The DA01A transducer is a direct gauge, and contains an absolute sensor. This pressure sensor utilizes a single-sided, dual-electrode/AC bridge circuit design. In this design, two capacitance electrodes are deposited upon a ceramic disc in a concentric “bull’s-eye” arrangement. The disc is positioned close to an Inconel® tensioned diaphragm to form two capacitors in an AC bridge circuit. The other side of the diaphragm is exposed to the process gas.

The diaphragm deflects with changing pressure—force per unit area—independent of the composition of the measured gas. This deflection causes a capacitance change between the diaphragm and the adjacent electrode assembly. When pressure is equal on both sides of the diaphragm, the bridge is balanced. When pressure deflects the diaphragm toward the electrode, the center capacitance changes more than the outer capacitance. This causes the bridge to become unbalanced, and an AC voltage to be generated. The output signal, which is proportional to pressure, can be provided as an analog signal (0 to 10 V) through the 9-pin Type DE-9S interface connector, or as a digital signal through the DeviceNet communications interface. The thermal enclosure reduces the effects of ambient temperature changes.

The zero and span stability are further increased in the DA01A (45° C) and DA01A (80° C) transducers because the sensor and bridge electronics are temperature controlled.

### **Signal Conditioner/Electronics**

The signal conditioner contains state-of-the-art, low impedance balanced bridge circuitry, self-compensated for thermal stability with ambient temperature changes. The output is a DC voltage that is then digitally linearized and calibrated against a pressure standard to produce both analog and digital outputs.

## **Pressure Measurement**

The digital output is read through the DeviceNet interface. The reported pressure value is based on a number of variables, many of which are user-adjustable through software commands. Figure 5, page 41, illustrates how actual pressure values are generated from the raw sensor output.

The raw pressure reading (both analog and digital) can be re-zeroed either by using the OneTouch Coarse Zero Push Button located on top of the transducer or by issuing the DeviceNet service 0x32 (the Coarse Zero Adjustment service). Analog and digital signals are automatically corrected for shifts caused by large temperature variations. The zero-corrected signals are then linearized and provided as 0 to 10 V analog signal and as a digital output that is expressed either in the user-selected unit of pressure or as a 16-bit integer.

An additional zero offset can be applied digitally to the corrected pressure value, both analog and digital, before the value is converted to the selected units.





Figure 5: Analog and Digital Pressure Calculation

## Top Panel Components

Figure 6 shows the top panel of your DA01A transducer.



**Figure 6: Top Panel Components**

### Digital Communications Connector

The 5-pin male micro-style connector accepts the power input from the DeviceNet network and provides the interface for digital communications. This connector meets the requirements in the ODVA “DeviceNet Specification,” Volume I [1]. Refer to Table 9, page 29, for the connector pinout.

### OneTouch Coarse Zero Push Button

This push button provides manual zeroing capability for the transducer’s pressure reading. The push button affects both the analog and digital zeros. Refer to *Coarse Zero Adjustments*, page 33, for more information.

### Analog Interface Connector

The 9-pin female Type DE-9S interface connector provides the pressure output signal for direct measurement from the DA01A transducer. Refer to Table 10, page 30, for the connector pinout.

### DeviceNet Status LEDs

The DA01A transducer has two standard bi-color (green/red) DeviceNet status LEDs, located on top of the unit (Figure 6, page 42). The power-up sequence of these LEDs conforms to the requirements in the ODVA “DeviceNet Specification,” Volume I [1]. Refer to *Power-Up*, page 30, for more information.

### Module Status LED

The Module Status LED indicates the status of the individual device, as defined in Table 14. If no problems are detected, the Module Status LED illuminates a solid green. The LED flashes green when the visual indicator is on. (Refer to *Visual Indicator*, page 81, for more information.) If a fault condition is detected, the Module Status LED illuminates a solid red.

**Table 14: Module Status LED Indicators**

LED State	Meaning
OFF	Power is OFF
Flashing Red/Green	Initializing
Solid Green	System functioning normally
Flashing Green	Visual Indicator ON
Solid Red	Major Unrecoverable Fault

**Network Status LED**

The Network Status LED indicates the status of the communications link, as defined in Table 15. If no problems are detected, the Network Status LED illuminates a solid green; the LED flashes green when the device is on-line but is not connected to other units. If a fault condition is detected, the Network Status LED illuminates a solid red or turns off.

**Table 15: Network Status LED Indicators**

LED State	Meaning
Solid Green	<i>Communications link is OK.</i> The device is on-line and has connections in the established state.
Flashing Green	<i>Device is on-line but has no connections in the established state.</i> The device has passed the Dup_MAC_ID test and is on-line, but has no established connections to other nodes.
Solid Red	<i>Critical link failure.</i> The device has detected an error that has rendered it incapable of communicating on the network (duplicate MAC_ID or bus-off).
OFF	<i>Not powered/not on-line.</i> The device has not completed the Dup_MAC_ID test, or the device may not be powered. Check the Module Status LED.

**Data Rate and Node Address Switches**

The data rate and node address for your device can be set through software commands using standard DeviceNet protocol over the network, or manually using the rotary switches located on the top panel of the device (Figure 6 page 42). The data rate and node address switches allow you to easily configure units without an operational network, or to network multiple units quickly.


The rotary switches support an assigned *network* position, labeled on the device as “PGM” to indicate software operation.

- If either switch is in the network (PGM) position at power-up, the data rate or address is read from the nonvolatile memory. Any changes to the values must be made over the network. Any changes in the rotary switch positions after power-up are ignored.
- If the rotary switch is *not* in the network (PGM) position at power-up, the data rate or address is read directly from the switches. Network changes will be denied and the

Attribute\_Not\_Settable General Error Code will be returned to the Set\_Attribute\_Single service request.

### *Data Rate Switch*

The 4-position rotary switch (Figure 6) is used to select the DeviceNet data rates of 125, 250, and 500 Kb. The switch positions are numbered in a clockwise direction, to correspond to the increasing data rate values.




**Data Rate**

**Figure 7: Data Rate Rotary Switch**

### *Node Address Switches*

Two 10-position rotary switches (6) are used to set the node address.



**Figure 8: Node Address Rotary Switches**

Use the switch on the left to set the most significant digit (MSD)— the factor of ten (10, 20, 30...60). Use the switch on the right to set the least significant digit (LSD)—the increments of one (1, 2, 3...9). The switch positions are numbered in a clockwise direction to correspond to the increasing address values.

## **Fault Conditions**

Your device can detect two general types of fault conditions (Table 16, page 45):

- Minor (recoverable and unrecoverable)
- Major (unrecoverable)

Fault conditions are indicated by the Module Status LED and through the Exception Status, Exception Alarm Detail, and Exception Warning Detail attributes in the S-Device Supervisor Object. (Refer to *S-Device Supervisor Object*, page 76, for more information.)

### **Minor Faults**

Minor faults occur when:

- Pressure is too high (> 105%FS) or too low (< -5% FS).
- Calibration has expired.
- Analog input value is out of range.

Minor faults are indicated in Table 47, page 83.

### **Major Faults**

A major unrecoverable fault occurs when a hardware problem with the EEPROM or a memory problem with the RAM is detected during the initial diagnostic check.

When this fault condition occurs, the Module Status LED illuminates *solid red*, in accordance with the ODVA “DeviceNet Specification,” Volume I [1].

#### **Note**



When a major unrecoverable fault occurs, the device cannot communicate on the network and operation stops. Contact MKS for assistance.

**Table 16: Fault Conditions**

<b>Fault Type</b>	<b>Module Status LED State</b>	<b>Description</b>
Minor Recoverable Fault	Solid / Flashing* Green	<i>Device remains in the Operating state.</i> The specific cause of the fault is reported in the exception status bit.
Minor Unrecoverable Fault	Solid / Flashing* Green	<i>Device remains in the Operating state.</i> The specific cause of the fault is reported in the exception detail alarm status bit.
Major Unrecoverable Fault	Solid Red	<i>Device transitions to the Critical Fault state.</i> The device will not respond to any services received over the network. All reporting associated with Publication objects are disabled.
* The Module Status LED flashes when the visual indicator is on. Refer to Table 47, page 83, for more information.		

## **Trip Points**

The DA01A transducer has two *software* trip points, which are maintained in the S-Analog Sensor Object:

- Trip Point-Alarm, Low and High
- Trip Point-Warning, Low and High

The software trip point values are adjustable using digital communication commands such that when the pressure rises above one or below the other, the corresponding trip point changes state. Refer to *S-Analog Sensor Object*, page 69, for more information.

### **Trip Point Hysteresis**

Hysteresis is built into the operation of the trip points to help compensate for the noise inherent in all systems. Without hysteresis, the noise may cause the trip points to repeatedly switch states, a condition known as “chatter.”

The default hysteresis value of 0 can be adjusted separately for each of the trip points through communication commands.

Setting the hysteresis too high creates a *deadband* around the trip point. The deadband prevents the trip point from responding to changes in the pressure signal around the trip point. Ideally, the hysteresis should be close to, but not less than, the peak-to-peak noise. This setting will provide maximum immunity from chatter while providing the best possible accuracy. It may take some trial and error efforts to determine the smallest hysteresis setting appropriate for your system.

### **Trip Point Settling Time**

The trip point settling time defines the amount of time a trip point alarm condition must exist before it is reported to the exception status attribute of the S-Device Supervisor Object. (Refer to *Exception Status*, page 79, for more information.) The trip point delay can be set from 0 to 10,000 msec—the initial value is 0.



## Labels

**Note**  The drawings in Figures **Error! Bookmark not defined.** and 10 are not drawn to scale.

### Band Label


The band label, which is wrapped around the transducer body, lists the pinouts for the unit's 5-pin micro-style digital communications connector (Table 9, page 29) and the 9-pin Type DE-9S analog interface connector (Table 10, page 30).



**Figure 9: Band Label**

### Serial Number Label

The serial number label, located on the lower enclosure, lists the unit's serial number, product model code, full scale range, input voltage, output voltage, and firmware revision level. The label also displays the CE mark signifying compliance with the European CE regulations.



**Figure 10: Serial Number Label**

The options for your transducer are identified in the model code when you order the unit. Refer to *Appendix B: Model Code Explanation*, page 95, for more information.

This page intentionally left blank.

## Chapter Four: Operation

### General Information

**Note**

---

Use this manual with the ODVA “DeviceNet Specification,” Volume I and Volume II [1, 2]; and the SEMI Standards Common and Specific Device Models [3, 4, 5] to obtain a complete functional description of your device. Refer to Table 6, page 20, for a list of the documents referenced throughout this manual.

---

This chapter defines the application-specific objects included in your transducer as well as the mapping of the system requirements to specific objects and attributes in the DeviceNet protocol. Tables defining the attributes and supported services for each Object Model are provided throughout the text.

A summary of the attributes is listed in Table 51, page 99.

A summary of the supported services is listed in Table 52, page 107.

The objects, attributes, and services described in this manual comply with the definition of an interoperable device on a semiconductor equipment sensor/actuator network proposed by SEMI [3, 4, 5].

### **Operating Modes**

The DA01A transducer has two user-accessible operating modes:

- User Mode—normal, default power up mode.
- Calibration Mode—used to access certain calibration and operating parameters.

The operation of the transducer is the same in each mode; however, access to certain attributes over the network may be restricted, depending on the active mode. Access rights to the specific attributes are defined in the various object attribute tables throughout this manual.

### **DeviceNet Messaging Protocol**

Your DA01A transducer supports explicit and I/O poll messaging connections as defined in the Predefined Master/Slave Connection Set [1] for establishing connections between devices. This communication protocol determines the format of how messages are transmitted and received over the DeviceNet network.

A brief description of the messaging protocol is provided in this chapter. Actual examples designed to illustrate how DeviceNet messages are generated and interpreted are shown in *Appendix D: Example Messages*, page 115.

**Note**

---

The DeviceNet messaging protocol is based on hexadecimal (base 16) math, rather than decimal (base 10) math. Descriptions in this chapter and the examples in *Appendix D: Example Messages*, page 115, assume a basic understanding of hexadecimal math.

---

In the actual application of DeviceNet communications, the messaging process typically is automated using an interface software program; therefore, manual calculation and interpretation of the messages is not required. Typical interface programs require only the input of specific class codes, instance IDs, attribute IDs, and any required data variable(s). Refer to the ODVA “DeviceNet Specification,” Volume I and Volume II [1, 2] for a complete description of the DeviceNet messaging protocol.

## Message Formats

### *Explicit Messaging Connections*

Explicit messaging connections utilize a direct request/response format that enables you to access any attribute data. Explicit messaging is typically used for device setup, configuration, and calibration.

Explicit messages—both requests and responses—consist of two segments:

- *CAN Identifier Field*, which defines the type of connection.
- *CAN Data Field*, which defines the particular request or response.

### *I/O Poll Messaging Connections*

I/O poll messaging connections utilize an assembly format to group and report data from multiple objects using a single communications command. These connections typically are used for quick reporting of information (run-time). Although I/O poll messaging connections typically report data faster than explicit messaging connections, they limit your access to the set of attributes (the exception status and the pressure value) listed in Tables 32 and 33, page 68. The data format in I/O poll messaging connections is pre-defined and cannot be altered.

I/O poll *request* messages consist of a single segment:

- *CAN Identifier Field*, which defines the type of connection.

I/O poll *response* messages consist of two segments:

- *CAN Identifier Field*, which defines the type of connection.
- *Poll Response*, which reports a fixed set of attribute data defined by the Predefined Master/Slave Connection Set [1].

There are two types of poll responses, each reporting a different set of data. The poll response that is returned is defined in the Device Configuration Object (page 75). The actual data for either poll response is stored in the Assembly Object (page 62).

## CAN Identifier Field

The CAN Identifier Field is a single 11-bit field that defines the components of a DeviceNet connection (Table 17, page 52). This information is required for both explicit and I/O poll messaging connections. The CAN Identifier Field consists of the following three components:

- Message ID (Group 1 or 2)
- Node Address (network address)
- Message Type ID

***Message ID***

This fixed 2-bit field indicates the type of messaging used in the device.

The identifier for Group 2 messages is fixed with bits 10 and 9 set to 1 and 0 respectively.

The identifier for Group 1 messages is fixed with bits 10 and 9 set to 0 and 1 respectively.

***Node Address***

The Node Address is a 6-bit field that identifies the network address of the device *as a hexadecimal value*. The *source* node address is the address of the device sending the message.

The *destination* node address is the address of the device receiving the message.

In a request message, the device address in the CAN Identifier Field is the destination node address. In a response message it is the source node address.

***Message Type ID***

This 3-bit field identifies the specific type of message (explicit or I/O) and whether the message string is a request or a response. The message type IDs are fixed for the Predefined Master/Slave Connection Set [1].

**Note**

---

The CAN Identifier Field is represented by a single hexadecimal value in each message string.

---

Table 17: CAN Identifier Field

10	9	8	7	6	5	4	3	2	1	0
<b>Group 2 Message ID</b> <i>Fixed 2-bit value</i>		<b>Node Address</b> <i>Hexadecimal Value—6-bits</i>						<b>Group 2 Message Type ID</b> <i>Fixed 3-bit value</i>		
1	0	Destination Node Address						1	0	0
										<i>Master's Explicit Request</i>
1	0	Source Node Address						0	1	1
										<i>Slave's Explicit Response</i>
1	0	Destination Node Address						1	0	1
										<i>Master's I/O Poll Command</i>
1	0	Destination Node Address						1	1	0
										<i>Group 2 Only Unconnected Explicit Request Messages</i>
1	0	Destination Node Address						1	1	1
										<i>Duplicate Node Address Check Messages</i>
<b>Group 1 Message ID</b> <i>Fixed 2-bit value</i>		<b>Group 1 Message Type ID</b> <i>Fixed 3-bit value</i>			<b>Node Address</b> <i>Hexadecimal Value—6-bits</i>					
0	1	1	1	1	Source Node Address					
										<i>Slave's I/O Poll Response</i>

### CAN Data Field

The CAN Data Field is a *series* of 8-bit fields that defines the specific parameters of an explicit message. This information is not required in I/O poll messages per the Predefined Master/Slave Connection Set [1].

The CAN Data Field is required in every explicit message; however, the format of the field varies depending on whether the message is a request or a response.

The CAN Data Field consists of a message header and a message body (Table 18, page 53). The message header is a single 8-bit field, consisting of three components that define the basic communication information about the explicit message. The header includes the same information regardless of whether the message is a request or a response.

The explicit message header consists of the following three components:

- Fragment Bit
- Transaction ID (XID) Bit
- Node Address

The message body is a series of up to five, 8-bit fields that defines the specific explicit message. The information included in the message body varies, depending on whether the message is a request or a response.

The explicit message body consists of the following three required and two optional components:

- Required:*
- Service Code (*request and response*)  
(consists of Request/Response bit and Service ID)
  - Class Code (*request only*)
  - Instance ID (*request only*)
- Optional:*
- Attribute ID (*request only*)
  - Service or Attribute Data (*request and response*)

**Note**

In each message string, the CAN Data Field is represented by a series of hexadecimal values.

**Table 18: CAN Data Field**

Byte	7	6	5	4	3	2	1	0
<b>0 MESSAGE HEADER</b>	<b>Fragment Bit</b> (0/1)	<b>Transaction ID (XID) Bit</b> (0/1)	<b>Node Address</b> <i>6-bit Hexadecimal Value</i>					
<b>1 MESSAGE BODY</b>	<b>Service Code</b> <i>Calculate the combined hexadecimal value of the request/response bit (bit 7) and the assigned Service ID hex value (bits 6 to 0)</i>							
	<b>Request Bit</b> (0) or <b>Response Bit</b> (1)	<b>Service ID</b> <i>Assigned hexadecimal value</i>						
<b>2</b>	<b>Class Code</b> <i>Assigned hexadecimal value</i>							
<b>3</b>	<b>Instance ID</b> <i>Assigned hexadecimal value</i>							

**Fragment Bit**

This 1-bit field indicates whether the message is complete or fragmented. A message must be fragmented if it is larger than 8 bytes. Refer to the ODVA “DeviceNet Specification,” Volume I [1] for more information.

The fragment bit values are:

- 0 = Non-fragmented
- 1 = Fragmented

***Transaction ID Bit***

The transaction ID (XID) bit is a 1-bit field that is essentially a placeholder with a fixed value of 0.

***Node Address***

The node address is a 6-bit field that identifies the network address of the device *as a hexadecimal value*. The *source* node address is the address of the device sending the message. The *destination* node address is the address of the device receiving the message.

In a request message, the device address in the CAN Data Field is the source node address. In a response message it is the destination node address.

***Request/Response Bit***

The request/response (R/R) bit (bit 7 in the service code) is a 1-bit field that specifies whether the message is a request or a response:

- 0 = Request
- 1 = Response

***Service ID***

This 7-bit field (bits 6 to 0 in the service code) identifies the service being requested. The service ID is a hexadecimal value assigned by ODVA.

Refer to Table 52, page 107, for a summary of the services supported by your device.

***Class Code***

The class code is a hexadecimal value, assigned by ODVA, which identifies a specific Object Model.

***Instance ID***

The instance ID is a hexadecimal value, assigned by ODVA, which identifies the instance within an Object Model.

***Service Data***

The service data is the specific information required for a request, or reported in a response, in the format assigned by ODVA. The data may include an attribute ID, which is a hexadecimal value assigned by ODVA, that identifies a specific parameter.



## Objects

Nine (9) Objects are supported in the DA01A. The Objects and their functions are listed by class code in Table 19, page 56.

The attributes and services associated with each Object Model are defined throughout this chapter. Descriptions are supplied for the attributes and services that are either MKS-specific or require additional specifications beyond the DeviceNet and SEMI specifications [1, 2, 3, 4, 5]. A summary of the attributes is listed in Table 51, page 99. A summary of the supported services is listed in Table 52, page 107.

For each attribute, the following information is supplied:

- Attribute ID # (hex value)
- Description
- Data Type
- User and Calibration Mode Access, which may be “read only” (R) or “read/write” (RW)
- Nonvolatile Memory, which is “Y” (yes) if stored in nonvolatile RAM or “N” (no) if not stored in nonvolatile RAM
- Data Variable(s)
- Factory Default Setting, which is set when you use the Restore\_Default service

### Note




---

Values stored in nonvolatile RAM are saved when the power is turned off. When power is restored, the device “remembers” the latest configuration, not the default setting. To restore the various attributes to their factory default settings, you must use the Restore\_Default service. Refer to *Restore Default*, page 111, for more information.

---

For each supported service, the following information is supplied:

- Service ID # (hex value)
- Service Name
- Parameter Data Type
- Service Type (request or notification)
- Description

### Note




---

The supported services and their required parameters are defined in *Supported Service Summary*, page 107.

---

**Table 19: Object Classes in the DA01A Transducer**

<b>Object Class</b>	<b>Class ID</b>	<b>Effect on Behavior</b>	<b>Refer to Page</b>
Identity	01 <sub>hex</sub>	Supports the Reset services. Upon receipt of a Reset service request of any type, the Identity Object sends a Reset service request to the S-Device Supervisor.	57
DeviceNet	03 <sub>hex</sub>	Configures port attributes (node addresses, data rate, and BOI)	59
Assembly	04 <sub>hex</sub>	Defines input/output and configuration data format.	62
Connection Class	05 <sub>hex</sub>	Contains the number of logical ports into or out of the device.	64
S-Analog Sensor	31 <sub>hex</sub>	The instance of this object provides a calibrated pressure value from a pressure transducer. The instance is using S-Analog Sensor subclass number 3, Capacitance Manometer.	69
Device Configuration	6D <sub>hex</sub>	General Device Configuration settings not available in other objects.	75
S-Device Supervisor	30 <sub>hex</sub>	Supports the Stop, Start, Reset, Abort, Recover, and Perform Diagnostic services for ALL Application Objects in the device and consolidates the Exception Conditions and Application Objects' Status.  This object behaves differently from the Identity Object in that the S-Device Supervisor object provides a single point of access to the Application Objects only. It does not affect the DeviceNet objects (Identity, DeviceNet, Connection, etc.).	76

## **Identity Object**

The Identity Object (Class Code 01<sub>hex</sub>) provides general information about the device as defined in the ODVA “DeviceNet Specification,” Volume II [2].

One instance of the Identity Object is supported with seven instance attributes (Table 20) and three DeviceNet common services (Table 21, page 58).

### **Identity Object Instance Attributes**

**Table 20: Identity Object Instance Attributes**

<b>Attribute ID # (hex)</b>	<b>Description</b>	<b>Data Type</b>	<b>User Mode Access</b>	<b>Cal Mode Access</b>	<b>Non-Volatile Memory</b>	<b>Data Variable</b>	<b>Factory Default Setting</b>
01	Vendor	UINT	R	R	N	none	36
02	Device Type*	UINT	R	R	N	none	28
03	Product Code*	UINT	R	R	Y	none	3
04	Revision*	Struct of: USINT USINT	R	R	N	none	current firmware revision
05	Status*	WORD	R	R	N	none	0
06	Serial Number*	UDINT	R	R	Y	none	0
07	Product Name*	SHORT- STRING	R	R	N	none	CM

*\* This information also is available—in a different format—in the S-Device Supervisor Object (see page 78, for more information).*

#### ***Vendor***

Attribute ID #01 reports the registered vendor supplying the device. MKS Instruments is identified as Vendor #36 (24<sub>hex</sub>).

#### ***Device Type***

Attribute ID #02 reports the type of device on the network in accordance with the ODVA “DeviceNet Specification,” Volume II [2]. The DA01A transducer is represented in the response with the value “28,” a pressure/vacuum gauge.

#### ***Product Code***

Attribute ID #03 reports the product code as “3” in accordance with the ODVA “DeviceNet Specification,” Volume II [2].

#### ***Revision***

Attribute ID #04 reports the current revision of firmware in accordance with the ODVA “DeviceNet Specification,” Volume II [2].

**Status**

Attribute ID #05 reports the current status of the device in accordance with the ODVA “DeviceNet Specification,” Volume II [2].

**Serial Number**

Attribute ID #06 reports the serial number of the device in accordance with the ODVA “DeviceNet Specification,” Volume II [2].

**Product Name**

Attribute ID #07 reports the product name in accordance with the ODVA “DeviceNet Specification,” Volume II [2]. The response returns the ASCII string “CM.”

**Identity Object Supported Services**

The Identity Object is supported by the three DeviceNet common services listed in Table 21. Refer to *Supported Service Summary*, page 107, for more information.

**Table 21: Identity Object Supported Services**

<b>Service ID # (hex)</b>	<b>Service Name</b>	<b>Parameter Data Type(s)</b>	<b>Service Type</b>	<b>Description</b>
05	Reset	USINT	Request	Places the object into its INITIALIZING state.
0E	Get_Attribute_Single	USINT	Request	Reads the object attribute.
10	Set_Attribute_Single	USINT, Attribute Data Type	Request	Modifies the object attribute.

## **DeviceNet Object**

The DeviceNet Object (Class Code 03<sub>hex</sub>) contains the attributes for defining the configuration and status of the physical DeviceNet network connections. Use this object to set or report the node address (network address), the data rate, and the bus-off interrupt. In addition, use this object to report how the messaging supported by the device is allocated.

One instance of the DeviceNet Object is supported with one class attribute (Table 22), four instance attributes (Table 23), and four DeviceNet common services (Table 24, page 61).

### **DeviceNet Object Class Attribute**

**Table 22: DeviceNet Object Class Attribute**

<b>Attribute ID # (hex)</b>	<b>Description</b>	<b>Data Type</b>	<b>User Mode Access</b>	<b>Cal Mode Access</b>	<b>Non-Volatile Memory</b>	<b>Data Variable</b>	<b>Factory Default Setting</b>
01	Revision	UINT	R	R	Y	none	002

### ***Revision***

Attribute ID #01 reports the current revision of the DeviceNet Object definition in the ODVA “DeviceNet Specification,” Volume I [1].

### **DeviceNet Object Instance Attributes**

**Table 23: DeviceNet Object Instance Attributes**

<b>Attribute ID # (hex)</b>	<b>Description</b>	<b>Data Type</b>	<b>User Mode Access</b>	<b>Cal Mode Access</b>	<b>Non-Volatile Memory</b>	<b>Data Variable</b>	<b>Factory Default Setting</b>
01	Node Address	USINT	RW*	RW*	Y	0 to 63	63
02	Data Rate	USINT	RW*	RW*	Y	0 = 125 Kb 1 = 250 Kb 2 = 500 Kb	0
03	Bus-Off Interrupt	BOOL	R	R	Y	none	1
05	Allocation Information	Struct of: USINT USINT	R	R	N	none	0, 255

*\* Attribute IDs #01 and #02 can be written only if their corresponding hardware switches (located on top of the device) are in the network (PGM) position. See Data Rate and Node Address Switches, page 43, for more information.*

### *Node Address*

The Node Address (network address) can be set with a software command using standard DeviceNet protocol over the network, or manually using the two 10-position rotary switches located on the top of the unit. Refer to *Data Rate and Node Address Switches*, page 43, for more information.

#### DeviceNet Protocol

Attribute ID #01 defines the node address (network address) of the device. Any address from 0 to 63 can be used. The unit is shipped with the address set to 63.

---

**Note**

The node address switch on the top of the device must be set to the network (PGM) position at power-up in order for changes to be made over the network. Any changes in the rotary switch positions after power-up are ignored.

---

#### Node Address Switch Adjustment

Refer to *Node Address Switches*, page 44, for complete information on adjusting these switches.

---

**Note**

In order to control the network address directly from the switches, ensure the switches are set to an actual value at power-up, and not to the network (PGM) position.

When this condition is met, any changes to the address made through the network are denied and the Attribute\_Not\_Settable General Error Code is returned to the Set\_Attribute\_Single service.

---

### *Data Rate*

The data rate can be set with a software command using standard DeviceNet protocol over the network, or manually using the 4-position rotary switch located on top of the unit. Refer to *Data Rate and Node Address Switches*, page 43, for more information.

#### DeviceNet Protocol

Attribute ID #02 defines the data rate of the device. The data rate can be set to 125, 250, or 500 Kb, where:

- 0 = 125 Kb (initial)
- 1 = 250 Kb
- 2 = 500 Kb

---

**Note**

The data rate switch on top of the device must be set to the network (PGM) position at power-up in order for changes to be made over the network. Any change in the rotary switch position after power-up is ignored.

---

### Data Rate Switch Adjustment

Refer to *Data Rate Switch*, page 44, for complete information on adjusting this switch.

**Note**

In order to control the data rate directly from the switch, ensure the switch is set to an actual value at power up, and not to the network (PGM) position.

When this condition is met, any changes to the data rate made through the network are denied and the Attribute\_Not\_Settable General Error Code is returned to the Set\_Attribute\_Single service.

### ***Bus-Off Interrupt***

Attribute ID #03 defines the bus-off interrupt for the device in accordance with the ODVA “DeviceNet Specification,” Volume I [1].

### ***Allocation Information***

Attribute ID #05 reports how the types of messages supported by the device are allocated as specified by the Predefined Master/Slave Connection Set [1].

### **DeviceNet Object Supported Services**

The DeviceNet Object is supported by the four DeviceNet common services listed in Table 24. Refer to *Supported Service Summary*, page 107, for more information.

**Table 24: DeviceNet Object Supported Services**

Service ID # (hex)	Service Name	Parameter Data Type(s)	Service Type	Description
0E	Get_Attribute_Single	USINT	Request	Reads the object attribute.
10	Set_Attribute_Single	USINT, Attribute Data Type	Request	Modifies object attribute.
4B	Allocate_Master_Slave	BYTE, USINT	Request	Allocates the Predefined Master/Slave Connection Set.
4C	Release Master Slave	BYTE	Request	Releases the Predefined Master/Slave Connection Set.

## Assembly Object

The Assembly Object (Class Code 04<sub>hex</sub>) stores data and groups attributes from multiple objects, allowing data to or from each object to be sent or received using a single *explicit* messaging command.

Two instances of the Assembly Object (Table 25) are supported with one instance attribute (Table 26, page 63) and one DeviceNet common service (Table 27, page 63).

### Assembly Object Instances

Each Assembly Object instance represents a different set of data. The format for each instance is fixed by the Predefined Master/Slave Connection Set and cannot be altered [1].

**Table 25: Assembly Object Instances**

Assembly Instance ID # (hex)	Data Type	Class Code (hex) / Object Model	Instance ID # (hex)	Attribute ID # (hex)	User Mode Access	Cal Mode Access
02	USINT	0x30 Device Supervisor	01	0x0C Exception Status	R	R
	UINT	SASO 0x31 Value (Pressure)	01	0x06 16-Bit Pressure	R	R
05	USINT	0x30 Device Supervisor	01	0x0C Exception Status	R	R
	REAL	SASO 0x31 Value (Pressure)	01	0x06 Corrected Pressure	R	R

Assembly instance ID #02 reports:

- Exception status from the S-Device Supervisor Object (refer to *Exception Status*, page 79).
- Scaled 16-bit pressure value from the S-Analog Sensor Object (refer to *Reporting the Pressure Value*, page 32).

Instance ID #05 reports:

- Exception status from the S-Device Supervisor Object (see *Exception Status*, page 79).
- Corrected pressure value in units from the S-Analog Sensor Object (refer to *Reporting the Pressure Value*, page 32).



## Assembly Object Instance Attribute

**Table 26: Assembly Object Instance Attribute**

Attribute ID # (hex)	Description	Data Type	User Mode Access	Cal Mode Access	Non-Volatile Memory	Data Variable	Factory Default Setting
03	Data	ARRAY	R	R	N	none	none

### *Data*

Attribute ID #03 reports the assembly data for the specified instance. The data returned for each instance is listed in Table 25, page 62.

## Assembly Object Supported Service

The Assembly Object is supported by the DeviceNet common service listed in Table 27. Refer to *Supported Service Summary*, page 107, for more information.

**Table 27: Assembly Object Supported Service**

Service ID # (hex)	Service Name	Parameter Data Type	Service Type	Description
0E	Get_Attribute_Single	USINT	Request	Reads the object attribute.

## Connection Object

The Connection Object (Class Code 05<sub>hex</sub>) contains the attributes for defining the messaging connections in the device. Each connection is defined by the type of messaging (explicit or I/O) it supports and how the I/O connections publish attribute data. Your transducer supports explicit and I/O poll messaging as defined in the Predefined Master/Slave Connection Set [1]. Examples of explicit and I/O poll messages are described in *Appendix D: Example Messages*, page 115.

Two instances of the Connection Object (Table 28) are supported with 15 instance attributes (Table 29, page 65, and Table 30, page 66) and three DeviceNet common services (Table 34, page 68).

### Note



1. The type of **connection** (explicit or I/O) is defined by the Allocate\_Master\_Slave service in the DeviceNet Object. (Refer to *Allocate Master/Slave*, page 111, for more information.)
2. The type of **message** is defined by the message identifier. (Refer to *CAN Identifier Field*, page 50.) When the Allocate\_Master\_Slave service is issued, the attribute data is automatically sent in the format defined by the Predefined Master/Slave Connection Set.

### Connection Object Instances

**Table 28: Connection Object Instances**

Instance ID # (hex)	Description
1	Explicit Messaging
2	I/O Poll Messaging

## Explicit Messaging Instance Attributes

**Table 29: Explicit Messaging Instance Attributes**

Attribute ID # (dec)	Attribute Name	Default Value	Description
1	state	03	Indicates the Explicit Messaging is in the <i>Established</i> state.
2	instance_type	00	Indicates this is an Explicit Messaging Connection.
3	transportClass_trigger	83 <sub>hex</sub>	Server/Transport Class 3
4	produced_connection_id	—	Refer to the Slave's Explicit Response Message in Table 17, page 52.
5	consumed_connection_id	—	Refer to the Master's Explicit Request Message in Table 17, page 52.
6	initial_comm_characteristics	21 <sub>hex</sub>	Indicates that (1) the Slave's Explicit Messaging Connection produces and consumes across Message Group 2, and (2) the Slave's Node Address appears in the CAN Identifier Fields of the Group 2 Messages that the Slave consumes and produces. Refer to Table 17, page 52.
7	produced_connection_size	3C <sub>hex</sub>	—
8	consumed_connection_size	3C <sub>hex</sub>	—
9	expected_packet_rate	09C4 <sub>hex</sub>	2500 milliseconds. Refer to [1].
12	watchdog_timeout_action	1	Auto_Delete as described in [1]. This attribute is settable to Deferred Delete as described in [1].
13	produced_connection_path_length	0	Refer to [1].
14	produced_connection_path	Empty	Refer to [1].
15	consumed_connection_path_length	0	Refer to [1].
16	consumed_connection_path	Empty	Refer to [1].
17	production_inhibit_time	0	Default is no inhibit time.
* Refer to the ODVA "DeviceNet Specification," Volume II [2], for information on User and Calibration Mode access.			

## I/O Poll Messaging Instance Attributes

Table 30: I/O Poll Messaging Instance Attributes

Attribute ID # (dec)	Attribute Name	Default Value	Description
1	state	01	Indicates the Poll Connection Object is in the <i>Configuring</i> state.
2	instance_type	01	Indicates this is an I/O Connection.
3	transportClass_trigger	83 <sub>hex</sub>	Server/Transport Class 3. Implementations can choose Transport Class 3 as the default.
4	produced_connection_id	—	See the Slave's I/O Poll Response Message in Table 17, page 52.
5	consumed_connection_id	—	See the Master's I/O Poll Command Message in Table 17, page 52.
6	initial_comm_characteristics	01	Indicates (1) the Slave's I/O Poll Connection produces across Message Group 1 and consumes across Message Group 2 and (2) the Slave's Node Address appears in the CAN Identifier Field of the Group 2 Message that the Slave consumes. Refer to Table 17, page 52.
7	produced_connection_size	3*	—
8	consumed_connection_size	0	—
9	expected_packet_rate	0	Expected packet rate must be configured.
12	watchdog_timeout_action	0	Transition to the <i>Timed Out</i> state.
13	produced_connection_path_length	6	—
14	produced_connection_path	ARRAY of hex USINTS	Default value is specified by the Poll Response Setup Attribute (ID #6) in the Device Configuration Object (see page 75). See Table 31, page 67.
15	consumed_connection_path_length	0	—

\* For INT data assembly.

(Continued on next page)

**Table 30: I/O Poll Messaging Instance Attributes (continued)**


Attribute ID # (dec)	Attribute Name	Default Value	Description
16	consumed_connection_path	Empty	No specified default. An implementation <i>must</i> choose an Application Object to reference by default and initialize this attribute accordingly.
17	production_inhibit_time	0	Default is no inhibit time.
* Refer to the ODVA “DeviceNet Specification,” Volume II [2], for information on User and Calibration Mode access.			

**Table 31: Poll Response Setup of the Produced\_Connection\_Path**

Assembly Instance	Produced_Connection_Path (hex bytes)					
2 (INT)	20	04	24	02	30	03
5 (REAL)	20	04	24	05	30	03
<i>The poll response is identified in the Device Configuration Object (page 75).</i>						

**Master Poll Request Message**



---

**Note**  The master’s poll request message does not report any data. The response returns the CAN Identifier only [1].

---

**Slave Poll Response Assembly Instance 2**


---

**Note**  There are two poll response messages from the slave. The poll response reported is defined in the Device Configuration Object (page 75). The data for each response is stored in the Assembly Object (page 62).

---

Poll assembly instance 2 reports the exception status from the S-Device Supervisor Object (refer to *Exception Status*, page 79) and the 16-bit pressure value from the S-Analog Sensor Object (refer to *Reporting the Pressure Value*, page 32) in the format shown in Table 32. Refer to Assembly Object Instance ID #02 in Table 25, page 62.

**Table 32: Poll Response Assembly Instance 2**

Data Byte	0	1	2
Description	Exception Status	16-Bit Pressure	
Class Code (hex) Object Model	0x30 Device Supervisor	0x31 S-Analog Sensor	
Instance ID # (hex)	0x01	0x01	
Attribute ID # (hex)	0x0C	0x06	
Data Type	USINT	INT	

**Poll Response Assembly Instance #5**

Poll assembly instance 5 reports the exception status from the S-Device Supervisor Object (refer to *Exception Status*, page 79) and the corrected pressure value in units from the S-Analog Sensor Object (refer to *Reporting the Pressure Value*, page 32) in the format shown in Table 33. Refer to Assembly Instance ID #05 in the Poll Response Assembly (Table 25, page 62).

**Table 33: Poll Response Assembly Instance 5**

Data Byte	0	1	2	3	4
Description	Exception Status	Corrected Pressure			
Class Code (hex) Object Model	0x30 Device Supervisor	0x31 S-Analog Sensor			
01	0x01	0x01			
Attribute ID # (hex)	0x0C	0x06			
Data Type	USINT	REAL			

**Connection Object Supported Services**

The Connection Object is supported by the three DeviceNet common services listed in Table 34. Refer to *Supported Service Summary*, page 107, for more information.

**Table 34: Connection Object Supported Services**

Service ID # (hex)	Service Name	Parameter Data Type(s)	Service Type	Description
05	Reset	USINT	Request	Places the object into its Initializing state.
0E	Get_Attribute_Single	USINT	Request	Reads the object attribute.
10	Set_Attribute_Single	USINT, Attribute Data Type	Request	Modifies the object attribute.

## **S-Analog Sensor Object**

The S-Analog Sensor Object (Class Code 31<sub>hex</sub>) contains the attributes for reporting the pressure values and for setting the variables used in the pressure calculation. The S-Analog Sensor Object also supports software alarm and warning trip points as described below.

One instance of the S-Analog Sensor Object is supported with 25 instance attributes (refer to Table 35) and three DeviceNet services (refer to Table 39, page 74). A table of pressure units support is provided in Table 38, page 74.

### **Customer Supported Attributes**

**Table 35: S-Analog Sensor Class Specific Attributes**

Attribute ID #		Description	DeviceNet Data Type	Access Rule	Non-Volatile Memory	Factory Default Setting
(dec)	(hex)					
03	0x03	Data Type	USINT	U-Set/Get	Y	0xC3 (INT)
04	0x04	Data Units	ENGUNITS	U-Set/Get	Y	0x1001 (Counts)
05	0x05	Reading Valid	BOOL	U-Get	N	none
06	0x06	Value	INT or REAL	U-Get	N	none
07	0x07	Status	Byte	U-Get	N	none
08	0x08	Alarm Enable	BOOL	U-Set	Y	0 (disable)
09	0x09	Warning Enable	BOOL	U-Set	Y	0 (disable)
10	0x0A	Full Scale	INT or REAL	U-Get	Y	23405
14	0x0E	Gain	REAL	U-Set/Get	Y	1.000
16	0x10	OffsetB Customer Offset	INT or REAL	U-Set/Get	Y	0
17	0x11	Alarm Trip Point High	INT or REAL	U-Set	Y	50% FS
18	0x12	Alarm Trip Point Low	INT or REAL	U-Set	Y	50% FS
19	0x13	Alarm Hysteresis	UINT or REAL	U-Set	Y	0
20	0x14	Alarm Settling Time	UINT	U-Set	Y	0
21	0x15	Warning Trip Point High	INT or REAL	U-Set	Y	50% FS
22	0x16	Warning Trip Point Low	INT or REAL	U-Set	Y	50% FS
23	0x17	Warning Hysteresis	UINT or REAL	U-Set	Y	0
24	0x18	Warning Settling Time	UINT	U-Set	Y	0

*(Continued on next page)*

**Table 35: S-Analog Sensor Class Specific Attributes (continued)**

Attribute ID #		Description	DeviceNet Data Type	Access Rule	Non-Volatile Memory	Factory Default Setting
(dec)	(hex)					
32	0x20	Overrange	INT or REAL	U-Get	Y	110% FS
33	0x21	Underrange	INT or REAL	U-Get	Y	-5% FS
94	0x5E	Sensor Warning	STRUCT of BYTE BYTE	U-Get	N	none
95	0x5F	Sensor Alarm	STRUCT of BYTE BYTE	U-Get	N	none
96	0x60	Status Extension	BYTE	U-Get	N	none
99	0x63	Sub Class	UINT	U-Get	Y	3
119	0x77	Pressure Fraction in Percentage Full Scale	REAL	U-Get	Y	none
147	0x93	Zero Offset	INT or REAL	U-Set/Get	Y	0
148	0x94	Target Offset	INT or REAL	U-Set/Get	Y	0

**Data Type**

Attribute ID # 03 determines the Data Type of Value and all related attributes. Integer and Real Data Types are supported. See below. Data Type is settable only in the *Idle* state. The default is INT.

**Table 36: Attribute ID # 03 Data Type**

Value (hex)	Data Type
0xC3	INT
0xCA	REAL

**Data Units**

Attribute ID # 04 determines the Units context of Pressure Value and all related attributes. Refer to Table 38, page 74. Data Units is settable only in the *Idle* state. The default is Counts.

**Reading Valid**

Attribute ID # 05 indicates that the Value attribute contains a valid value.

- 0 = Invalid
- 1 = Valid

**Value**

Attribute ID # 06 reports the measured pressure value.

$$\text{Value} = (\text{PressurePFS} * \text{Full Scale}) * \text{Gain} + \text{Offset B}$$



where:

PressurePFS = Attribute 0x77

Full Scale = Attribute 0x0A

Gain = Attribute 0x0E

OffsetB = Attribute 0x10

### **Status**

Attribute ID # 07 indicates the Alarm and Warning state of this object instance.

**Table 37: Status Attribute Values**

<b>Bit</b>	<b>Definition</b>
0	High Alarm Exception: 0 = cleared, 1 = set
1	Low Alarm Exception: 0 = cleared, 1 = set
2	High Warning Exception: 0 = cleared, 1 = set
3	Low Warning Exception: 0 = cleared, 1 = set
4	Reserved
5	Reserved
6	Reserved
7	Reserved

### **Alarm Enable**

Attribute ID # 08 enables the setting of the Alarm Status Bits in the S-Analog Sensor Object:

0 = Disable (default)

1 = Enable

### **Warning Enable**

Attribute ID # 09 enables the setting of the Warning Status Bits in the S-Analog Sensor Object:

0 = Disable (default)

1 = Enable

### **Full Scale**

Attribute ID # 10 indicates the Value of 100% Full Scale for the sensor. Full Scale and Value have the same Data Units.

### **Gain**

Attribute ID # 14 indicates an amount scaled to derive Value. This can be modify the calculated digital value. The default is 1. The gain attribute may range from 0.98 to 1.02.

***Offset-B Customer Offset***

Attribute ID # 16 indicates an amount added to derive Value. The acceptable value for Offset B is  $\pm 5\%$  of the Full Scale pressure value. This can be used to modify the calculated digital value. The default is 0.

***Alarm Trip Point High***

Attribute ID # 17 determines the Value above which an Alarm condition will occur. The default is 50% Full Scale.

***Alarm Trip Point Low***

Attribute ID # 18 determines the Value below which an Alarm condition will occur. The default is 50% Full Scale.

***Alarm Hysteresis***

Attribute ID # 19 determines the amount by which the Value must recover to clear an Alarm condition. The acceptable input range for Trip Point-Alarm hysteresis is 0 (default) to 20%.

Hysteresis is built into the operation of the trip points to help compensate for the noise inherent in all systems. Without hysteresis, the noise may cause the trip points to repeatedly switch states, a condition known as “chatter.”

Refer to *Trip Point Hysteresis*, page 46, for more information.

---

**Note**  Hysteresis can only be set using DeviceNet digital communications commands.

---

***Alarm Settling Time***

Attribute ID # 20 determines the time in milliseconds that the Value must exceed the Trip Point before the exception condition is generated. The default is 0.

***Warning Trip Point High***

Attribute ID # 21 determines the Value above which a Warning condition will occur. The default is 50% Full Scale.

***Warning Trip Point Low***

Attribute ID # 22 determines the Value below which a Warning condition will occur. The default is 50% Full Scale.

***Warning Hysteresis***

Attribute ID # 23 determines the amount by which the Value must recover to clear a Warning condition. The acceptable input range for Trip Point-Warning hysteresis is 0 (default) to 20%.

Hysteresis is built into the operation of the trip points to help compensate for the noise inherent in all systems. Without hysteresis, the noise may cause the trip points to repeatedly switch states, a condition known as “relay chatter.”

Refer to *Trip Point Hysteresis*, page 46, for more information.

---

**Note**  Hysteresis can only be set using DeviceNet digital communications commands.

---

### ***Warning Settling Time***

Attribute ID # 24 determines the time in milliseconds that the Value must exceed the Trip Point before the exception condition is generated. The default is 0.

### ***Overrange***

Attribute ID # 32 specifies the highest valid Value (110% of Full Scale). When Value > 110% Full Scale, the Reading Valid attribute is set to invalid. The default is 110% Full Scale.

### ***Underrange***

Attribute ID # 33 specifies the lowest valid Value (-5% of Full Scale). When Value < -5% Full Scale, the Reading Value Attribute is set to invalid. The default is -5% Full Scale.

### ***Sensor Warning***

Attribute ID # 94 indicates the bits definition of Sensor Warnings. Bytes 0 and 1 map, respectively, to Bytes 1 and 2 of the S-Device Supervisor Object Device Exception Detail Warning (Attribute 0x0E). Refer to Table 42, page 76.

### ***Sensor Alarm***

Attribute ID # 95 indicates the bits definition of Sensor Alarms. Bytes 0 and 1 map, respectively, to Bytes 1 and 2 of the S-Device Supervisor Object Device Exception Detail Alarm (Attribute 0x0D). Refer to Table 42, page 76.

### ***Status Extension***

Attribute ID # 96 indicates the bits definition of Sensor Warnings. Byte 0 maps to Byte 0 of the S-Device Supervisor Object Device Exception Detail Warning (Attribute 0x0E). Refer to Table 42, page 76.

### ***Sub Class***

Attribute ID # 99 contains Vacuum gauge sub class number 3 (Capacitance Manometer).

### ***Pressure as Fractional Percentage of Full Scale***

Attribute ID # 119 indicates the corrected and calibrated final value of pressure as a fractional percentage of Full Scale, where a 100% of Full Scale value is indicated as 1.00.

## Pressure Units Support

**Table 38: S-Analog Sensor Pressure Units Support**

Code	DEC	Symbol	Name	Conversion Factor
1001 <sub>hex</sub>	4097	Counts	Full Scale Counts	23405=100% Full Scale
1007 <sub>hex</sub>	4103	Percent	% Full Scale	100.00 (Base % Full Scale)
1300 <sub>hex</sub>	4864	Psi	(pound-force)/(inch) <sup>2</sup>	0.0193368 (Base Torr)
1301 <sub>hex</sub>	4865	Torr	mmHg (0° C)	1.0 (Base Torr)
1302 <sub>hex</sub>	4866	mTorr	mTorr	1000.0 (Base Torr)
1304 <sub>hex</sub>	4868	inHg (0° C)	inch of mercury (0° C)	0.0393701 (Base Torr)
1305 <sub>hex</sub>	4869	cmH <sub>2</sub> O (4° C)	centimeter of water (4° C)	1.35955 (Base Torr)
1306 <sub>hex</sub>	4870	inH <sub>2</sub> O (4° C)	inch of water (4° C)	0.535254 (Base Torr)
1307 <sub>hex</sub>	4871	bar	bar	0.00133322 (Base Torr)
1308 <sub>hex</sub>	4872	mbar	millibar	1.33322 (Base Torr)
1309 <sub>hex</sub>	4873	Pa	pascal N/(m) <sup>2</sup>	133.322 (Base Torr)
130A <sub>hex</sub>	4874	kPa	kilopascal	0.133322 (Base Torr)
130B <sub>hex</sub>	4875	atm	standard atmosphere	0.00131579 (Base Torr)
130C <sub>hex</sub>	4876	gram/cm <sup>2</sup>	gram-force per square centimeter	1.359510250028 (Base Torr)

## Specific Services

**Table 39: S-Analog Sensor Object Specific Services**

Service Code		Service Name/ Access Rule	Description of Service
(dec)	(hex)		
53	0x32	U-Coarse Zero Adjustment	Sends a Target pressure value, usually zero, to the device. Corrections to the digital zero are made to bring the pressure Value (Attribute 0x6) to the specified Target Value. The range of this service is -4 to +20% of Full Scale. This service is also initiated by depressing the Coarse Zero Push Button for at least 2 seconds.
75	0x4B	U-Fine Zero Adjust	Service no longer available
76	0x4C	U-Gain Adjust	Service no longer available

## **Device Configuration Object**

Support added in firmware version AF (1.009). Not valid for previous versions.

The Device Configuration Object (Class Code 6D<sub>hex</sub>) contains the attributes for selecting the poll response that is returned with I/O poll messaging connections. One instance of the Device Configuration Object is supported with three instance attributes (Table 40) and three DeviceNet common services (Table 41, page 75).

### **Device Configuration Object Instance Attributes**

**Table 40: Device Configuration Object Instance Attributes**

<b>Attribute ID # (hex)</b>	<b>Description</b>	<b>Data Type</b>	<b>User Mode Access</b>	<b>Cal Mode Access</b>	<b>Non-Volatile Memory</b>	<b>Data Variable</b>	<b>Factory Default Setting</b>
01	Produced Assembly Instance	USINT	RW*	RW*	Y	Assembly Instance	2
02	Consumed Assembly Instance	USINT	RW*	RW*	Y	0	0
03	Poll_Auto_Delete_Enable	BOOL	RW*	RW*	Y		1 (enabled)

*\* Attribute ID #01 cannot be set if the Allocate Master Slave service has been issued and the poll connection is in the established state.*

#### ***Poll\_Auto\_Delete\_Enable***

Setting this attribute determines the behavior implemented when the poll IO watchdog\_timeout\_action is set to a value of 0x00 (transition to timeout). The common practice is to allow the object to delete the poll connection upon the poll connection timing out. The factory default for this attribute is therefore 0x01, enabled. To utilize a more rigid enforcement of the connection, the attribute may be set to a value of 0x00, disabled. When this attribute is set to disabled and, upon the poll IO connection timing out, the device will transition to a timed out state (the red Network status LED will blink) and the connection must be reset or deleted over the network to clear the condition.

### **Device Configuration Object Supported Services**

The Device Configuration Object is supported by the two DeviceNet common services listed in Table 41. Refer to *Supported Service Summary*, page 107, for more information.

**Table 41: Device Configuration Object Supported Services**

<b>Service ID # (hex)</b>	<b>Service Name</b>	<b>Parameter Data Type(s)</b>	<b>Service Type</b>	<b>Description</b>
0E	Get_Attribute_Single	USINT	Request	Reads the object attribute.
10	Set_Attribute_Single	USINT, Attribute Data Type	Request	Modifies the object attribute.

## **S-Device Supervisor Object**

The S-Device Supervisor Object (Class Code 30<sub>hex</sub>) provides general information about the device.

The S-Device Supervisor Object includes most of the same information—in a different format—available in the Identity Object (refer to Table 20, page 57) in accordance with the ODVA DeviceNet Specification, Volume II [2]. In addition, the S-Device Supervisor Object includes attributes specific to the MKS transducer, in accordance with the SEMI Standards Common and Specific Device Models [3, 4, 5].

One instance of the S-Device Supervisor Object is supported with 14 instance attributes (refer to Table 42) and seven DeviceNet services (refer to Table 49, page 86).

### **Class Specific Attributes**

**Table 42: S-Device Supervisor Class Specific Attributes**

Attribute ID #		Description*	DeviceNet Data Type	Access Rule	Non-Volatile Memory	Factory Default Setting
(dec)	(hex)					
03	0x03	Device Type	SHORT STRING	U-Get	Y	VG
04	0x04	SEMI Standard Revision Level	SHORT STRING	U-Get	Y	E54-0997
05	0x05	Manufacturer's Name	SHORT STRING	U-Get	Y	MKS Instruments
06	0x06	Manufacturer's Model Number	SHORT STRING	U-Get	Y	DA01A
07	0x07	Software Revision Level	SHORT STRING	U-Get	Y	Current firmware revision
08	0x08	Hardware Revision Level	SHORT STRING	U-Get	Y	A
09	0x09	Manufacturer's Serial Number Identity Object	SHORT STRING	U-Get	Y	Serial Number
10	0x0A	Device Configuration	SHORT STRING	U-Get	Y	DA01AXXXXXXXXXXX
11	0x0B	Device Status	USINT	U-Get	Y	none
12	0x0C	Exception Status	BYTE	U-Get	Y	none
13	0x0D	Exception Detail Alarm	STRUCT	U-Get	N	none
14	0x0E	Exception Detail Warning	STRUCT	U-Get	N	none

*(Continued on next page)*

**Table 42: S-Device Supervisor Class Specific Attributes (continued)**

Attribute ID #		Description*	DeviceNet Data Type	Access Rule	Non-Volatile Memory	Factory Default Setting	
(dec)	(hex)						
15	0x0F	Alarm Enable	BOOL	U-Set/Get	Y	0 (disabled)	
16	0x10	Warning Enable	BOOL	U-Set/Get	Y	0 (disabled)	
Attribute ID # (dec)	Description	DeviecNet Data Type	Access Rule	Cal Mode Access	Non-Volatile Memory	Data Variable	Factory Default Setting
19	Last Maintenance Date	DATE*	R	RW	Y	none	0,0,0
20	Next Maintenance Date	DATE*	R	RW	Y	none	0,0,0
21	Scheduled Maintenance Expiration Timer	INT	R	RW	Y	-32,767 to +32,767 hours	0
22	Scheduled Maintenance Expiration Warning Enable	BOOL	RW	RW	Y	0 = Disable 1 = Enable	0
23	Run Hours	UINT	R	R	Y	0 to 65535	0
100	Factory Calibration Date	DATE*	R	R	Y	none	0,0,0

\* The DATE format does not conform to the ODVA definition. It is a structure of (1) a year of type USINT, (2) a month of type USINT, and a (3) a day of type USINT.

**Device Type**

Attribute ID #03 reports the type of device on the network using an ASCII string of up to 8 characters. In the response, the DA01A unit is defined as a capacitance manometer vacuum gauge with the ASCII string “VG.”

**SEMI Standard Revision Level**

Attribute ID #04 reports the most recent version of the Standards Device Model to which the unit adheres. The response is a 7-character (maximum) ASCII string “ENN-NNYY” where:

- E = SEMI assigned value
- NN-NN = Number of the standard
- YY = Year of the published standard

The default string is “E54-0997”

***Manufacturer' Name***

Attribute ID #05 reports the manufacturer of the DA01A capacitance manometer using an ASCII string of up to 20 characters. The manufacturer of the unit is always reported as MKS Instruments, identified with the ASCII string “MKS Instruments”

***Manufacturer's Model Number***

Attribute ID #06 reports the model number of the instrument with an ASCII string of up to 20 characters. The capacitance manometer is represented in the response with the ASCII string “DA01A”

***Software Revision Level***

Attribute ID #35 reports the version of microprocessor code in the instrument. The format of the attribute is “XXX”

The initial firmware revision level is “1.001”

***Hardware Revision Level***

Attribute ID #08 designates the hardware version of your device, with an ASCII string of up to 5 characters. The revision level is identified with the letters from “A” to “Z.” The initial hardware revision is “A”

***Manufacturer's Serial Number Identity Object***

Attribute ID #09 reports the serial number of the device with an ASCII string up to 30 characters.

***Device Configuration***

Attribute ID #10 reports the device configuration beyond the model number in the number:  
DA01AXXXXXXXXXXXXX

***Device Status***

Attribute ID #11 represents the current state of the device. Its value changes as the state of the device changes. The following values are defined:

**Table 43: Device Status Attribute Values**

<b>Attribute Value</b>	<b>Device State</b>
0	Undefined
1	Self Testing
2	Idle
3	Self Testing Exception
4	Executing
5	Self Testing
6	Critical Fault



### ***Exception Status***

Attribute ID #12 reports the type of alarm or warning condition detected by the instrument. The alarms and warnings are identified as:

- Device Common—specific to the DeviceNet network
- Device Specific—specific to capacitance manometers
- Manufacturer Specific—specific to the MKS unit

The response is a byte structured as a bit mapped variable [3]. The transducer supports the expanded method of reporting exceptions. The bit map format is:

7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---

Table 44 lists the bit map defining this variable.

**Table 44: Exception Status Bit Map**

<b>Bit</b>	<b>Definition</b>
0	(0/1) Alarm/device-common
1	(0/1) Alarm/device-specific
2	(0/1) Alarm/manufacturer-specific
3	0 (Reserved)
4	(0/1) Warning/device-common
5	(0/1) Warning/device-specific
6	(0/1) Warning/manufacturer-specific
7	1 (Expanded Method)

The response returns a binary value with the least significant bit (bit 0) as the last digit. The response values are additive; therefore, one hex value reports all alarm conditions. For example, if the unit detects a device-specific alarm condition, the unit reports:  $82_{\text{hex}} = 1000010$ . Refer also to Table , page 83.

### ***Exception Detail Alarm***

Attribute ID #13 identifies the specific alarm condition(s) detected by the DA01A transducer. This attribute is a Structure of three Structures containing a bit mapped representation of the alarm detail. This structure contains a total of 8 bytes. The first group contains 3 bytes representing Common Exception Detail Alarm Bytes. The second group contains 3 bytes representing Device Exception Detail Alarm Bytes. The third group contains 2 bytes representing Manufacturer Exception Detail Alarm Bytes.

The response is a byte with each bit representing a specific exception (alarm) condition, as listed in Table 46. The bit that is set indicates that the alarm assigned to that bit is active. The response returns a binary (hex) value with the least significant bit (bit 0) as the last digit. The response values are additive; therefore, one hex value reports all alarm conditions.

**Table 45: Exception Detail Alarm Bytes**

Byte	Description	
0	2	Number of Common Alarm Detail Bytes
1	XXXXXXXX	Common Alarm Detail Byte 0
2	XXXXXXXX	Common Alarm Detail Byte 1
3	2	Number of Device Alarm Detail Bytes
4	XXXXXXXX	Device Alarm Detail Byte 0
5	XXXXXXXX	Device Alarm Detail Byte 1
6	1	Number of Manufacturer Alarm Detail Bytes
7	XXXXXXXX	Manufacturer Alarm Detail Byte 0

Refer also to Table 47, page 83.

### ***Exception Detail Warning***

Attribute ID #14 identifies the specific warning condition(s) detected by the DA01A transducer. This attribute is a Structure of three Structures containing a bit mapped representation of the warning detail. This structure contains a total of 9 bytes. The first group contains 3 bytes representing Common Exception Detail Warning Bytes. The second group contains 4 bytes representing Device Exception Detail Warning Bytes. The third group contains 2 bytes representing Manufacturer Exception Detail Warning Bytes.

The response is a byte with each bit representing a specific exception (alarm) condition, as listed in Table 46. The bit that is set indicates that the alarm assigned to that bit is active. The response returns a binary (hex) value with the least significant bit (bit 0) as the last digit. The response values are additive; therefore, one hex value reports all alarm conditions.

**Table 46: Exception Detail Warning Bytes**

Byte	Description	
0	2	Number of Common Warning Detail Bytes
1	XXXXXXXX	Common Warning Detail Byte 0
2	XXXXXXXX	Common Warning Detail Byte 1
3	3	Number of Device Warning Detail Bytes
4	XXXXXXXX	Device Warning Detail Byte 0
5	XXXXXXXX	Device Warning Detail Byte 1
6	XXXXXXXX	Device Warning Detail Byte 2
7	1	Number of Device Warning Detail Bytes
8	XXXXXXXX	Manufacturer Warning Detail Byte 0

Refer also to Table 47, page 83.

***Alarm Enable***

This Boolean attribute (Attribute ID #15) is used to enable (1) or disable (0) the S-Device Supervisor object's process of setting Alarm Exception bits.

- 0 = Disabled (default)
- 1 = Enabled

When disabled, corresponding bits are never set; and, if they were set, disabling clears them. Also, alarm bit states are not retained; when enabled, bits will be set only if the corresponding condition is true.

***Warning Enable***

This Boolean attribute (Attribute ID #15) is used to enable (1) or disable (0) the S-Device Supervisor object's process of setting Warning Exception bits.

- 0 = Disabled (default)
- 1 = Enabled

When disabled, corresponding bits are never set; and, if they were set, disabling clears them. Also, warning bit states are not retained; when enabled, bits will be set only if the corresponding condition is true.

***Visual Indicator***

Attribute ID Attribute IDAAA#64 controls the behavior of the visual indicator (the wink function) on the device. This attribute controls the flashing of the Module Status LED, which is useful for visually identifying a particular device on the network, where:

- 0 = Off (initial)
- 1 = On

When the visual indicator is On, the Module Status LED flashes green approximately once a second. When the visual indicator is Off, the Module Status LED returns to its normal operation. Refer to *DeviceNet Status LEDs*, page 42, for more information on the LED status indicators.

***User Tag***

Attribute ID #65 enables you to assign a label (user tag) to the DA01A transducer. The tag can be any user-defined string (including spaces) of up to 30 ASCII characters.

***Operating Mode***

Attribute #66 defines the operating mode of the device, where:

- 0 = User Mode (initial)
- 1 = Calibration Mode

The User Mode is the normal, default power-up mode. The Calibration Mode enables you to recalibrate your device and modify certain attributes that are read-only in the User Mode. Only field or service personnel should use the Calibration Mode.

Apart from restricting access to certain parameters, the device operation is identical in either mode. Access rights to specific attributes are defined in the various object attribute tables throughout this manual.

**Note**

---

To switch between the two operating modes, you must use the Lock and Unlock services.

Use the Lock service to place your device into the User Mode (refer to *Lock*, page 112). Use the password protected (1234<sub>hex</sub>) Unlock service to place your device into the Calibration Mode (refer to *Unlock*, page 113).

---

**Table 47: Exception Detail Alarm Map**

Byte	Bit	Description	Object Model
Common Alarm Size	0 to 7	Least significant byte of Common Alarm Size (byte length) always 01 hex. Byte length always 02 hex	Single Byte 2
Common [Byte 0]	0	Internal Diagnostic Exception	S-Device Supervisor
	1	Microprocessor Exception	S-Device Supervisor
	2-3	EEPROM Exception	S-Device Supervisor
	4	RAM Exception	S-Device Supervisor
	5,7	Reserved	
	6	Internal Real Time Exception	S-Device Supervisor
Common [Byte 1]	0	Power Supply Overcurrent	S-Device Supervisor
	1	Reserved Power Supply	S-Device Supervisor
	2	Power Supply Output Voltage	S-Device Supervisor
	3	Power Supply Input Voltage	S-Device Supervisor
	4	Scheduled Maintenance	S-Device Supervisor
	5	Notify Manufacturer	S-Device Supervisor
	6	Reset Exception	S-Device Supervisor
	7	Reserved	
Device Specific Alarm Size	0 to 7	Byte length always 02 hex	Single Byte 2
Device Specific Alarm Size [Byte 0]	0	Diaphragm Failure	S-Analog Sensor Object
	1 to 7	Reserved	
Device Specific Alarm Size [Byte 1]	0	Reserved	
	1	Electronics Failure	S-Analog Sensor Object
	2	Over Temperature of Electronics	S-Analog Sensor Object
	3 to 7	Reserved	
Manufacturing Alarm Size	0 to 7	Byte length always 01 hex	Single Byte 1
Manufacturing Specific Alarm [Byte 0]	0	ADC High Rail	S-Device Supervisor
	1	ADC Low Rail	S-Device Supervisor
	2 to 3	Reserved	
	4	Device Not Configured	S-Device Supervisor
	5 to 7	Reserved	

*(Continued on next page)*

**Table 47: Exception Detail Warning Map (continued)**

<b>Byte</b>	<b>Bit</b>	<b>Description</b>	<b>Object Model</b>
Common Warning Size	0 to 7	Byte length always 01 hex	Single Byte 2
Common [Byte 0]	0	Internal Diagnostic Exception	S-Device Supervisor
	1	Microprocessor Exception	S-Device Supervisor
	2-3	EEPROM Exception	S-Device Supervisor
	4	RAM Exception	S-Device Supervisor
	5,7	Reserved	
	6	Internal Real Time Exception	S-Device Supervisor
Common [Byte 1]	0	Power Supply Overcurrent	S-Device Supervisor
	1	Reserved Power Supply	S-Device Supervisor
	2	Power Supply Output Voltage	S-Device Supervisor
	3	Power Supply Input Voltage	S-Device Supervisor
	4	Scheduled Maintenance	S-Device Supervisor
	5	Notify Manufacturer	S-Device Supervisor
	6	Reset Exception	S-Device Supervisor
	7	Reserved	
Device Specific Warning Size	0 to 7	Byte length always 01 hex	Single Byte 3
Device Specific Warning Size [Byte 0]	0	Reading Invalid	S-Analog Sensor Object
	1	Over-range Exceeded	S-Analog Sensor Object
	2	Under-range Exceeded	S-Analog Sensor Object
	3 to 7	Reserved	
Device Specific Warning Size [Byte 1]	0	Not at Temperature	S-Analog Sensor Object
	1 to 7	Reserved	
Device Specific Warning Size [Byte 2]	0	Reserved	
	1	Reserved	
	2 to 7	Reserved	
Manufacturing Specific Warning Size	0 to 7	Byte length always 01 hex	Single Byte 1
Manufacturing Specific Warning [Byte 0]	0	Reserved	S-Analog Sensor Object
	1	824 Status	S-Analog Sensor Object
	2	Analog Output Invalid	S-Analog Sensor Object
	3	Electronics Temperature Alert	S-Analog Sensor Object
	4 to 5	Reserved	
	6	Pressure Below 0% Full Scale	S-Analog Sensor Object
	7	Pressure Above 100% Full Scale	S-Analog Sensor Object

***Last Calibration Date***

Attribute ID # 0x13 reports the date the device was last calibrated by the user. The response is formatted as a data structure of four bytes used to represent a calendar date, as listed in Table 48.

**Table 48: Calibration Date Format**

Byte #	Description	Data Type	Range
0-1	Year	UINT	1997 to 2100
2	Month	USINT	1 to 12
3	Day	USINT	1 to 31

***Next Calibration Date***

Attribute ID # 0x14 identifies the date the device is scheduled for the next calibration. The date is formatted as a data structure of four bytes used to represent a calendar date, as listed in Table 48.

***Calibration Expiration Timer***

Attribute ID # 0x15 specifies the time remaining until the next recommended calibration. The acceptable input range is -32767 to +32767 hours. The initial setting is 0. The attribute has a resolution of 1 hour.

***Calibration Expiration Warning Enable***

Attribute ID # 0x16 specifies whether or not the Calibration Timer (Attribute ID #03 in this object) will set the “Calibration Recommended” warning status bit in the exception status attribute in the S-Device Supervisor Object (refer to Table 47, page 83), where:

- 0 = Disable (initial)
- 1 = Enable

***Run Hours***

Attribute ID # 0x17 reports the number of hours the device has been powered on. The response has a resolution of 1 hour and a range of 0 to 65535. This value does not reset to zero when the unit is powered down.

***Factory Calibration Date***

Attribute ID #64 reports the date the device was last calibrated at the factory. The response is formatted as a data structure of four bytes used to represent a calendar date, as listed in Table 48, page 85.

### S-Device Supervisor Object Supported Services

The S-Device Supervisor Object is supported by the seven DeviceNet services listed in Table 49. Refer to *Supported Service Summary*, page 107, for more information.

**Table 49: S-Device Supervisor Object Supported Services**

Service ID # (hex)	Service Name	Parameter Data Type(s)	Service Type	Description
05	Reset*	USINT	Request	Places the object into its Initializing state.
06	Recover* (start)	none	Request	Causes the device to transition from the Abort state to the Operating state.
07	Abort* (stop)	none	Request	Places the device in its Abort state.
0E	Get_Attribute_Single*	USINT	Request	Reads the object attribute.
10	Set_Attribute_Single*	USINT, Attribute Data Type	Request	Modifies the object attribute.
4D	Lock	none	Request	Restricts access to Read-Only attributes. Places the device into the User Mode.
4E	Unlock (Password Protected)	UINT	Request	Makes Read-Only attributes modifiable and places the device into Calibration Mode.

\* *DeviceNet common services.*



## Chapter Five: Maintenance and Troubleshooting

### General Information

In general, the DA01A transducer requires no maintenance other than proper installation and operation, and an occasional zero adjustment. If the transducer fails to operate properly upon receipt, check for shipping damage and check the cables for correct continuity. Immediately report any damage to the carrier and MKS Instruments.

If there is no obvious damage and the cable continuity is correct, check your instrument using the *Troubleshooting Chart* (Table 50, page 88). If the transducer performance does not improve and it is necessary to return the unit to MKS for service, obtain an ERA Number (Equipment Return Authorization Number) from any MKS Calibration and Service Center (listed on the inside back cover of this manual) before shipping.

### Maintenance

#### **Zero Adjustment**

All pressure transducers require initial and periodic zero adjustments. Prior to initial operation and during periodic maintenance you must check the transducer zero to verify the proper output.

The transducer's pressure signal can be zeroed by manually pressing the OneTouch Zero Push Button on the top of the DA01A unit (Figure 6, page 42). The unit's zero can also be adjusted with the Coarse Zero Adjustment Service in the S-Analog Sensor Object (refer to *Reporting the Pressure Value*, page 32).

Refer to *Adjusting the Zero*, page 33, for complete instructions on adjusting the transducer zeros.

---

#### **Note**



In production operations such as semiconductor manufacturing, verify the transducer zero (and adjust if necessary) each time the equipment is shut down for routine maintenance.

---

## **Troubleshooting**

**Table 50: Troubleshooting Chart**

<b>Symptom</b>	<b>Possible Cause</b>	<b>Solution</b>
Overrange positive or negative signal.	A shorted transducer or a damaged interconnect cable (transducer to electronics module).	Measure supply voltages at the connector. Inspect cable and transducer. Replace, if necessary.
Measurement slowly goes positive over time.	Overpressure and/or a build-up of contamination in the measurement cavity.	Return to MKS for servicing or transducer replacement.
Unstable zero output.	The ambient temperature may be too high.  <i>or</i> The ambient temperature is varying over a wide range.	Refer to <i>Startup</i> , page 30 to ensure the ambient temperature is within product requirements. (Refer also to <i>Appendix A: Product Specifications</i> , page 89).

## Appendix A: Product Specifications

### Digital Communication Specifications

Bus Addressing	Master/slave information flow
Data Rate Switch/Network Length Software Override 125 Kb 250 Kb 500 Kb	One, 4-position user-adjustable switch: PGM (Programmable over the network) 500 m (1,640 ft) 250 m (820 ft) 100 m (328 ft)
DeviceNet V 2.0 Device Group 2	Explicit and Polled Messaging
Digital Functions/Capabilities	Read pressure Set trip points and hysteresis Select units: Torr, Pa, mBar, inH <sub>2</sub> O, psi Set digital and analog zeroes Reset factory defaults Report run time hours Monitor transducer status—trip points Change user tags and device address
Node Address Switches 0/0 to 6/3 6/4 to 9/9	Two, 10-position user-adjustable switches: Hardware ID numbers (no software override) Software ID numbers (software selectable)
Network Size	Up to 64 nodes
Visual Communication Indicators (standard bi-color)	LED Module Status (green/red) LED Network Status (green/red)

**Electrical Specifications**

	DA01A (Ambient)	DA01A (45° C)	DA01A (80° C)
CE Compliance Electromagnetic Compatibility <sup>1</sup>	Pending Specification EN61326 EMC Directive 2004/108/EEC		
Input Power Requirements			
Voltage	+11 to +25 VDC *	+11 to +25 VDC *	+11 to +25 VDC *
Current at Warm Up	200 mAmps (max)	700 mAmps (max)	1.0 amps
Isolation	500 [1] V	500 [1] V	500 [1] V
	* Communicate within +11 to +25 VDC range. Operation within performance specifications from +18 to +25 VDC.		
Power Consumption	≤ 7 Watts	≤ 14 Watts	≤ 22 Watts
Protection			
Fuses	Current limiting provided on DeviceNet power supply inputs.		
Tantalum Capacitors	Target use restricted.		
Mis-wiring	Protection against on DeviceNet Connector.		
Transients	Protection against per CE.		
Signal Output—Analog	-0.5 to +11 V (0 to 10 VDC for 0 to 100% Full Scale)		
Supply Voltage Coefficient			
Span	0.02% Reading for 18 VDC to 25 VDC		
Zero	0.01% Full Scale for 18 VDC to 25 VDC		

<sup>1</sup> Overall metal braided shielded cable, properly grounded at both ends, for use of J2 9-pin “D” connector.

**Environmental Specifications**

		DA01A (Ambient)	DA01A (45° C)	DA01A (80° C and 100° C)
Maximum External Case Temperature		50° C (122° F)	50° C (122° F)	65° C (149° F)
Temperature Range	Operating	0° to 50° C (32° to 122° F)	15° to 40° C (59° to 104° F)	15° to 50° C (59° to 122° F)
	Storage	-20° to 80° C (68° to 176° F)		
	Maximum External Case	In operation at 20° C ambient: 60° C		
Storage Humidity Range		25% RH to 95% RH (relative humidity), non-condensing		
Warm Up Time		½ hour all ranges	4 hours ranges less than 1 Torr 2 hours ranges 1 Torr and higher	4 hours ranges less than 1 Torr 2 hours ranges 1 Torr and higher

**Performance Specifications**

Accuracy (nonlinearity, hysteresis, and non-repeatability)	Range (Torr) (% of Reading)	Standard Accuracy (% of Reading)	Optional (% of Reading)
DA01A (Ambient)	1, 2, 5	0.25%	0.15%
	10, 20, 50, 100, 200, 500, 1000	0.25%	
DA01A (45° C)	0.02	0.25%	N/A
	0.05, 0.1, 0.25, 0.5	0.15%	
	1, 2, 5, 10, 20, 50, 100, 200, 500, 1000	0.12%	
DA01A (80° C)	0.05, 0.1, 0.25, 0.5	0.5%	N/A
	1, 2, 5, 10, 20, 50, 100, 200, 500, 1000		
DA01A (100°C)	0.05, 0.1, 0.25, 0.5	0.25%	N/A
	1, 2, 5, 10, 20, 50, 100, 200, 500, 1000		
Temperature Coefficients	Range	Zero (% Full Scale/°C)	Span (% Reading/°C)
DA01A (Ambient)	1 Torr	0.015%	0.04%
	2 and 5 Torr	0.01%	0.04%
	10 Torr and up	0.005%	0.04%
DA01A (45° C)	0.02 Torr	0.03%	0.02%
	0.05 Torr	0.015%	0.02%
	0.1, 0.25, 0.5 Torr	0.005%	0.02%
DA01A (80° C)	1 Torr and up	0.002%	0.02%
	0.05 Torr	0.020%	0.02%
	0.1, 0.25, 0.5 Torr	0.01%	0.02%
DA01A (100° C)	1 Torr and up	0.002%	0.02%
	0.05 Torr	0.020%	0.02%
	0.1, 0.25, 0.5 Torr	0.01%	0.02%
	1 Torr and up	0.002%	0.02%
Burst Pressure	5 times Full Scale or 90 psia, whichever is greater		
Leak Integrity	Internal to external <math>10^{-9}</math> scc/sec He 100 million cycles to FS without leakage—1 million cycles for <math>\leq 1</math> Torr		
Overpressure Limit Without Damage	45 psia (310 kPa)		
Resolution	0.001% Full Scale		
Time Constant	<math>< 20</math> msec (<math>< 40</math> msec $\leq 1$ Torr units)		

(Continued on next page)

Time Response Pressure Measurement Response Polled Communication Response	Less than 30 ms with no digital filtering.  1 ms, maximum
RoHS (Restriction of Hazardous Substances) Compliance	Fully compliant to Directive 2002-95-EC
Media Compatibility	Any gas compatible with Inconel <sup>®</sup> and 316 stainless steel

**Physical Specifications**

Dimensions  Diameter Length	3.13" outside diameter 3.875" overall not including port tube or DeviceNet connector
Fittings  Standard Optional	½ inch (12.7 mm) tubulation 8-VCR <sup>®</sup> (female), Mini-CF (rotatable), NW16-KF, Swagelok 8-VCO <sup>®</sup> (female)
Internal Volume	<7 CC
I/O Connectors  Analog Digital	9-pin female Type DE-9S Interface 5-pin male DeviceNet Micro-Style
Weight	1.5 lbs (0.68 kg)
Wetted Materials	Inconel. Some fittings may be constructed from 316 stainless steel.

Due to continuing research and development activities, these product specifications are subject to change without notice.

This page intentionally left blank.



## Appendix B: Model Code Explanation

	DA01A	XX	X	XX	X	X	X	X	X	X	X
<b>MODEL NO.:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
<b>RANGE:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
.10-----1	-----1										
.25-----RE	-----RE										
.50-----5	-----5										
1-----01	-----01										
2-----02	-----02										
5-----05	-----05										
10-----11	-----11										
20-----21	-----21										
50-----51	-----51										
100-----12	-----12										
200-----22	-----22										
500-----52	-----52										
1000-----13	-----13										
<b>ENGINEERING UNITS:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
TORR/mmHg-----T	-----T										
mBAR-----M	-----M										
KILOPASCAL-----K	-----K										
<b>FITTINGS:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
*0.50 O.D. TUBE (1K mmHg MAX)-----BA	-----BA										
**4 VCR FEMALE-----CD	-----CD										
8 VCR FEMALE-----CE	-----CE										
8 VCR MALE-----CF	-----CF										
8 VCR FEM, SHORT TUBE & GLAND-----CR	-----CR										
KF-16-----GA	-----GA										
KF-25-----GC	-----GC										
KF-16, SHORT TUBE & GLAD-----GD	-----GD										
8 VCO FEMALE-----DA	-----DA										
MINI-CONFLAT-----HA	-----HA										
<b>SENSOR TYPE:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
STANDARD-----S	-----S										
ETCH BAFFLE SENSOR (<= 100 TORR)-----E	-----E										
<b>*ANALOG OUTPUT VOLTAGE:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
0-10VDC-----2	-----2										
0-5VDC-----3	-----3										
<b>SENSOR TEMPERATURE:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
100°C-----1	-----1										
80°C-----8	-----8										
45°C-----4	-----4										
AMBIENT-----0	-----0										
<b>ELECTRICAL CONNECTOR:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
DEVICENET 5-PIN WITH 9 POS D-SUB-----A	-----A										
<b>CALIBRATION TYPE:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
STANDARD (RANGES > 1 TORR)-----0	-----0										
HORIZONTAL (< 1 TORR)-----H	-----H										
VERTICAL (< 1 TORR)-----V	-----V										
<b>*ACCURACY:</b> _____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
0.12% OF READING-----C	-----C										
0.15% OF READING-----D	-----D										
0.25% OF READING-----E	-----E										
0.50% OF READING-----F	-----F										
STANDARD-----0	-----0										

**Range (XX)**

The full scale range is indicated by a 2-character code. It is expressed in the selected engineering unit.

<b>Full Scale Range (mmHg/Torr)</b>	<b>Ordering Code</b>
0.10	.1
0.25	RE
0.5	.5
1	01
2	02
5	05
10	11
20	21
50	51
100	12
200	22
500	52
1000	13

**Engineering Units (X)**

The engineering units are indicated by a single letter code.

<b>Units</b>	<b>Ordering Code</b>
Torr/mmHg	T
mBar	M
kiloPascal	K
Pascal	L

***Fittings (XX)***

Several types of fittings are available, designated by a 2-character code. No additional parts are required.

<b>Fittings</b>	<b>Ordering Code</b>
Straight Tube 50 O.D. (1 K mmHg max)	BA
Swagelok 8-VCR (female)	CE
Mini-CF (rotatable)	HA
NW-16-KF (5 K mmHg max)	GA
Swagelok 8-VCO (female)	DA
NW-25-KF (5 K mmHg max)	GC
2¾-CF (rotatable)	HC
Swagelok 4-VCR (female)	CD

***Sensor Type***

The options are designated by a single letter code.

<b>Options</b>	<b>Ordering Code</b>
Standard	N
Etch Baffle Sensor	E
¼-in tube for 4VCR ftg	V

***Analog Output Voltage***

The options are designated by a single number.

<b>Output Voltage</b>	<b>Ordering Code</b>
0 to 10 vdc	0
0 to 5 vdc	4

***Sensor Control Temperature***

The sensor control temperature is designated by a single letter code.

<b>Sensor Control Temperature</b>	<b>Ordering Code</b>
Ambient	0
45° C	4
80° C	8
100° C	1

***Electrical Connector***

<b>Connector</b>	<b>Ordering Code</b>
5 pin DeviceNet Micro Connector with 9 pin D	A

***Calibration Type***

The calibration type is designated by a single letter code.

<b>Calibration Type</b>	<b>Ordering Code</b>
No Special Requirement, 1 Torr and Above	N
Horizontal Calibration, <1 Torr	H
Vertical Calibration, <1 Torr	V

***Accuracy***

<b>Accuracy</b>	<b>Ordering Code</b>
Standard	0
0.12% Reading	C
0.15% Reading	D
0.25% Reading	E
0.5% Reading	F

## Appendix C: Command Summary

### Attribute Summary

Table 51 lists the attributes for the Object Models in your transducer by Class Code. For more information on each Object Model, refer to *Chapter Four: Operation*, page 49.

**Table 51: Attribute Summary**

Class Code (hex) Object Model	Instance ID # (hex)	Attribute ID # (hex)	Description	Data Type	User Mode Access	Cal Mode Access	Factory Default Setting
01 Identity	01	01	Vendor	UINT	R	R	36
		02	Device Type	UINT	R	R	0
		03	Product Code	UINT	R	R	27
		04	Revision	Struct of: USINT USINT	R	R	current firmware revision
		05	Status	WORD	R	R	0
		06	Serial Number	UDINT	R	R	0
		07	Product Name	SHORT- STRING	R	R	CM
03 DeviceNet	01	01	Node Address	USINT	RW <sup>1</sup>	RW <sup>1</sup>	63
		02	Data Rate	USINT	RW <sup>1</sup>	RW <sup>1</sup>	0 = 125 Kb
		03	Bus-Off Interrupt	BOOL	R	R	0
		05	Allocation Information	Struct of: USINT USINT	R	R	0, 255
04 Assembly	01	03	Trip Point Assembly	ARRAY	R	R	none
	02	03	Poll Request (No Data)	none	R	R	none
	03	03	Poll Response #1	ARRAY	R	R	none
	04	03	Poll Response #2	ARRAY	R	R	none

(Continued on next page)

Table 51: Attribute Summary (continued)

Class Code (hex) Object Model	Instance ID # (hex)	Attribute ID # (dec)	Attribute Name	Default Value	Description	Factory Default Setting
05 Connection	01	1	state	03	Indicates the Explicit Messaging is in the <i>Established</i> state.	none
		2	instance_type	00	Indicates this is an Explicit Messaging Connection.	none
		3	transportClass_trigger	83 <sub>hex</sub>	Server/Transport Class 3	none
		4	produced_connection_id	—	Refer to the Slave's Explicit Response Message in Table 17, page 52.	none
		5	consumed_connection_id	—	Refer to the Master's Explicit Request Message in Table 17, page 52.	none
		6	initial_comm_characteristics	21 <sub>hex</sub>	Indicates that (1) the Slave's Explicit Messaging Connection produces and consumes across Message Group 2, and (2) the Slave's Node Address appears in the CAN Identifier Fields of the Group 2 Messages that the Slave consumes and produces. Refer to Table 17, page 52.	none
		7	produced_connection_size	3C <sub>hex</sub>	—	none
		8	consumed_connection_size	3C <sub>hex</sub>	—	none
		9	expected_packet_rate	09C4 <sub>hex</sub>	2500 milliseconds. Refer to [1].	none
12	watchdog_timeout_action	1	Auto_Delete as described in [1]. This attribute is settable to Deferred Delete as described in [1].	none		

(Continued on next page)

**Table 51: Attribute Summary (continued)**

<b>Class Code (hex) Object Model</b>	<b>Instance ID # (hex)</b>	<b>Attribute ID # (dec)</b>	<b>Attribute Name</b>	<b>Default Value</b>	<b>Description</b>	<b>Factory Default Setting</b>
05 Connection	01	13	produced_ connection_path_ length	0	Refer to [1].	
		14	produced_ connection_path	Empty	Refer to [1].	
		15	consumed_ connection_path_ length	0	Refer to [1].	
		16	consumed_ connection_path	Empty	Refer to [1].	
		17	production_ inhibit_time	0	Default is no inhibit time.	
* Refer to the ODVA "DeviceNet Specification," Volume II [2], for information on User and Calibration Mode access.						

*(Continued on next page)*

Table 51: Attribute Summary (continued)

Class Code (hex) Object Model	Instance ID # (hex)	Attribute ID # (dec)	Attribute Name	Default Value	Description	Factory Default Setting
05 Connection	02	1	state	01	Indicates the Poll Connection Object is in the <i>Configuring</i> state.	none
		2	instance_type	01	Indicates this is an I/O Connection.	none
		3	transportClass_trigger	83 <sub>hex</sub>	Server/Transport Class 3. Implementations can choose Transport Class 3 as the default.	none
		4	produced_connection_id	—	See the Slave's I/O Poll Response Message in Table 17, page 52.	none
		5	consumed_connection_id	—	See the Master's I/O Poll Command Message in Table 17, page 52.	none
		6	initial_comm_characteristics	01	Indicates (1) the Slave's I/O Poll Connection produces across Message Group 1 and consumes across Message Group 2 and (2) the Slave's Node Address appears in the CAN Identifier Field of the Group 2 Message that the Slave consumes. Refer to Table 17, page 52.	none
		7	produced_connection_size	3*	—	none
		8	consumed_connection_size	0	—	none
		9	expected_packet_rate	0	Expected packet rate must be configured.	none

\* For INT data assembly.

(Continued on next page)



**Table 51: Attribute Summary (continued)**

Class Code (hex) Object Model	Instance ID # (hex)	Attribute ID # (dec)	Attribute Name	Default Value	Description	Factory Default Setting
05 Connection	02	12	watchdog_ timeout_action	0	Transition to the <i>Timed Out</i> state.	none
		13	produced_ connection_path_ length	6	—	none
		14	produced_ connection_path	ARRAY of hex USINTS	Default value is specified by the Poll Response Setup Attribute (ID #6) in the Device Configuration Object (see page 75). See Table 31, page 67.	none
		15	consumed_ connection_path_ length	0	—	none
		16	consumed_ connection_path	Empty	No specified default. An implementation <i>must</i> choose an Application Object to reference by default and initialize this attribute accordingly.	none
		17	production_ inhibit_time	0	Default is no inhibit time.	none
* Refer to the ODVA “DeviceNet Specification,” Volume II [2], for information on User and Calibration Mode access.						

(Continued on next page)

Table 51: Attribute Summary (continued)

Class Code (hex) Object Model	Attribute ID #		Description	DeviceNet Data Type	Access Rule	Non-Volatile Memory	Factory Default Setting	
	(dec)	(hex)						
0x31 S-Analog Sensor	03	0x03	Data Type	USINT	U-Set/Get	Y	0xC3 (INT)	
	04	0x04	Data Units	ENGUNITS	U-Set/Get	Y	0x1001 (Counts)	
	05	0x05	Reading Valid	BOOL	U-Get	N	none	
	06	0x06	Value	INT or REAL	U-Get	N	none	
	07	0x07	Status	Byte	U-Get	N	none	
	08	0x08	Alarm Enable	BOOL	U-Set	Y	0 (disable)	
	09	0x09	Warning Enable	BOOL	U-Set	Y	0 (disable)	
	10	0x0A	Full Scale	INT or REAL	U-Get	Y	23405	
	14	0x0E	Gain	REAL	U-Set/Get	Y	1.000	
	16	0x10	OffsetB Customer Offset	INT or REAL	U-Set/Get	Y	0	
	17	0x11	Alarm Trip Point High	INT or REAL	U-Set	Y	50% FS	
	18	0x12	Alarm Trip Point Low	INT or REAL	U-Set	Y	50% FS	
	19	0x13	Alarm Hysteresis	UINT or REAL	U-Set	Y	0	
	20	0x14	Alarm Settling Time	UINT	U-Set	Y	0	
	21	0x15	Warning Trip Point High	INT or REAL	U-Set	Y	50% FS	
	22	0x16	Warning Trip Point Low	INT or REAL	U-Set	Y	50% FS	
	23	0x17	Warning Hysteresis	UINT or REAL	U-Set	Y	0	
	24	0x18	Warning Settling Time	UINT	U-Set	Y	0	
	32	0x20	Overrange	INT or REAL	U-Get	Y	110% FS	
	33	0x21	Underrange	INT or REAL	U-Get	Y	-5% FS	
	94	0x5E	Sensor Warning	STRUCT of BYTE BYTE	U-Get	N	none	
	95	0x5F	Sensor Alarm	STRUCT of BYTE BYTE	U-Get	N	none	
96	0x60	Status Extension	BYTE	U-Get	N	none		
99	0x63	Sub Class	UINT	U-Get	Y	3		
119	0x77	Pressure Fraction in Percentage Full Scale	REAL	U-Get	Y	none		
147	0x93	Zero Offset	INT or REAL	U-Set/Get	Y	0		
148	0x94	Target Offset	INT or REAL	U-Set/Get	Y	0		

Table 51: Attribute Summary (continued)

Class Code (hex) Object Model	Attribute ID #		Description*	DeviceNet Data Type	Access Rule	Non- Volatile Memory	Factory Default Setting			
	(dec)	(hex)								
S-Device Supervisor	03	0x03	Device Type	SHORT STRING	U-Get	Y	VG			
	04	0x04	SEMI Standard Revision Level	SHORT STRING	U-Get	Y	E54-0997			
	05	0x05	Manufacturer's Name	SHORT STRING	U-Get	Y	MKS Instruments			
	06	0x06	Manufacturer's Model Number	SHORT STRING	U-Get	Y	DA01A			
	07	0x07	Software Revision Level	SHORT STRING	U-Get	Y	Current firmware revision			
	08	0x08	Hardware Revision Level	SHORT STRING	U-Get	Y	A			
	09	0x09	Manufacturer's Serial Number Identity Object	SHORT STRING	U-Get	Y	Serial Number			
	10	0x0A	Device Configuration	SHORT STRING	U-Get	Y	DA01AXXXXXXXXXX X			
	11	0x0B	Device Status	USINT	U-Get	Y	none			
	12	0x0C	Exception Status	BYTE	U-Get	Y	none			
	13	0x0D	Exception Detail Alarm	STRUCT	U-Get	N	none			
	14	0x0E	Exception Detail Warning	STRUCT	U-Get	N	none			
	15	0x0F	Alarm Enable	BOOL	U-Set/Get	Y	0 (disabled)			
	16	0x10	Warning Enable	BOOL	U-Set/Get	Y	0 (disabled)			
		<b>Attribute ID # (dec)</b>		<b>Description</b>	<b>DeviecNet Data Type</b>	<b>Access Rule</b>	<b>Cal Mode Access</b>	<b>Non- Volatile Memory</b>	<b>Data Variable</b>	<b>Factory Default Setting</b>
		19		Last Maintenance Date	DATE*	R	RW	Y	none	0,0,0
	20		Next Maintenance Date	DATE*	R	RW	Y	none	0,0,0	

(Continued on next page)

**Table 51: Attribute Summary (continued)**

Class Code (hex) Object Model	Attribute ID # (dec)	Description	DeviecNet Data Type	Access Rule	Cal Mode Access	Non- Volatile Memory	Data Variable	Factory Default Setting
S-Device Supervisor	21	Scheduled Maintenance Expiration Timer	INT	R	RW	Y	-32,767 to +32,767 hours	0
	22	Scheduled Maintenance Expiration Warning Enable	BOOL	RW	RW	Y	0 = Disable 1 = Enable	0
	23	Run Hours	UINT	R	R	Y	0 to 65535	0
	100	Factory Calibration Date	DATE*	R	R	Y	none	0,0,0
0x6D	03	Poll_Auto_ Delete_Enable	BOOL	RW	RW	Y		1 (enabled)

<sup>1</sup> These attributes can be written only if their corresponding hardware switches, located on top of the device, are in the network (PGM) position. Refer to Data Rate and Node Address Switches, page 43, for more information.

<sup>2</sup> The DATE format does not conform to the ODVA definition. It is a structure of (1) a year of type UINT, (2) a month of type USINT, and (3) a day of type USINT.

## **Supported Service Summary**

Table 52 lists the services supported by the Object Models in your transducer by their ID number. It also lists the Object Models that support each service. The service parameters are defined on pages 110 to 113. For more information on each Object Model, refer to *Chapter Four: Operation*, page 49.

Refer to the ODVA “DeviceNet Specification,” Volume I [1] for complete descriptions of the common services. Refer to the SEMI Standard Specific Device Models [3, 4, 5] for complete descriptions of all other services.

**Table 52: Supported Service Summary**

<b>Service ID # (hex)</b>	<b>Service Name</b>	<b>Parameter Data Type(s)</b>	<b>Service Type</b>	<b>Description</b>	<b>Object Models</b>
05	Reset*	USINT	Request	Places the object into its Initializing state.	Identity Connection Device Manager
06	Recover* (start)	None	Request	Causes the device to transition from the Abort state to the Operating state.	Device Manager
07	Abort* (stop)	None	Request	Places the device in its Abort state.	Device Manager
0E	Get_Attribute_Single*	USINT	Request	Reads the object attribute.	Identity DeviceNet Assembly Connection Analog Input Output Pressure Device Config. Trip Point Device Manager SAC

*(Continued on next page)*

Table 52: Supported Service Summary (continued)

Service ID # (hex)	Service Name	Parameter Data Type(s)	Service Type	Description	Object Models
10	Set_Attribute_Single*	USINT, Attribute Data Type	Request	Modifies the object attribute.	Identity DeviceNet Connection Analog Input Output Pressure Device Config. Trip Point Device Manager SAC
15	Restore_Default*	USINT	Request	Restores object attributes to their default values.	Analog Input Output Pressure Device Config. Trip Point SAC
4B	Allocate_Master_Slave	BYTE, USINT	Request	Allocates the Predefined Master/Slave Connection Set.	DeviceNet
4C	Release_Master_Slave	BYTE	Request	Releases the Predefined Master/Slave Connection Set.	DeviceNet
4D	Lock	None	Request	Restricts access to Read-Only attributes. Places the device into the <i>User Mode</i> .	Device Manager
4E	Unlock (Password "1234hex" Protected)	UINT	Request	Makes Read-Only attributes modifiable and places the device into <i>Cal Mode</i> .	Device Manager

(Continued on next page)

Table 52: Supported Service Summary (continued)

Service ID # (hex)	Service Name	Parameter Data Type(s)	Service Type	Description	Object Models
05	Reset	USINT	Request	Places the object into its Initializing state.	
0E	Get_Attribute_Single	USINT	Request	Reads the object attribute.	
10	Set_Attribute_Single	USINT, Attribute Data Type	Request	Modifies the object attribute.	
* DeviceNet common services.					

### Reset

The *Reset* service (ID #05) places the object instance into its *Initializing* state. This service is valid for the Identity, Connection, and S-Device Supervisor Objects. The parameter for the Reset service indicates the type of reset. The device supports a parameter value of zero, which causes the device to emulate a power cycle as closely as possible [2].

### Recover

The *Recover* service (ID #06)—valid for the S-Device Supervisor Object—moves the object instance from its *Abort* state to its *Recovering* state. There are no parameters specified for this service.

### Abort

The *Abort* service (ID #07)—valid for the S-Device Supervisor Object—places the object instance into its *Abort* state. There are no parameters specified for this service.

### Get Attribute Single

The *Get\_Attribute\_Single* service (ID #0E) reads the value of an object instance attribute. This service is valid for every object in your device. Table 53 lists the parameters for this DeviceNet common service.

**Table 53: Get Attribute Single Parameters**

Parameter	Request	Response	Service Data Type	Description
Attribute ID	Mandatory	Conditional	Network Specific	Attribute Identifier of the attribute whose value is being requested.
Attribute Value	—	Mandatory	Context Specific	Value of the attribute being requested.

### Set Attribute Single

The *Set\_Attribute\_Single* service (ID #10) modifies the value of an object instance attribute. If necessary, the attribute value also is saved to nonvolatile memory. This service is valid for every object in your device, *except* the Assembly Object. Table 54 lists the parameters for this DeviceNet common service.

**Table 54: Set Attribute Single Parameters**

Parameter	Request	Response	Service Data Type	Description
Attribute ID	Mandatory	Conditional	Network Specific	Attribute Identifier of the attribute whose value is being requested.
Attribute Value	Mandatory	Conditional	Context Specific	Value of the attribute being modified.



## Restore Default

The *Restore\_Default* service (ID #15) restores attributes in the specified object to their factory default values. This service is valid for the Analog Input, Output Pressure, Device Configuration, Trip Point, and SAC Objects. Table 55 lists the parameters for this DeviceNet common service.

**Table 55: Restore Default Service Parameters**

Parameter	Request	Response	Service Data Type	Description
Restore Conditions	Mandatory	Conditional	USINT	0 = Restore <i>specific</i> attribute of the object. 1 = Restore <i>all</i> attributes of the object. 2 = Restore all S, A, and C objects*.
Attribute Value	Conditional	Conditional	Network Specific	Attribute ID of the attribute whose value is being restored.
* The S, A, and C Objects include the Analog Input, Output Pressure, Trip Point, and Device Configuration Objects.				

## Allocate Master/Slave

The *Allocate\_Master\_Slave* service (ID #4B)—valid only for the DeviceNet Object—supports and allocates the explicit and I/O poll messaging connections of the Predefined Master/Slave Connection Set [1]. Table 56 lists the parameters for this DeviceNet common service. For complete information on this service, refer to the ODVA “DeviceNet Specification,” Volume I [1].

**Table 56: Allocate Master/Slave Parameters**

Parameter	Data Type	Description
Allocation Choice	BYTE	Indicates which connections from the Predefined Master/Slave Connection Set are to be allocated/configured for use by the Master.
Allocator’s <i>Node Address</i>	USINT	Contains the <i>Node Address</i> associated with the module requesting the allocation.

**Allocation Choice Parameter**

The *Allocation Choice* parameter is specified within a single byte (Table 57). Each bit denotes an explicit and/or I/O poll connection(s) from the Predefined Master/Slave Connection Set that is to be allocated. If the bit is set to one (1), a request is being made to allocate that particular connection. If the bit is set to zero (0), the connection is not allocated.

**Table 57: Allocation Choice Byte Contents**

7	6	5	4	3	2	1	0
Reserved	Not Supported	Not Supported	Not Supported	Reserved	Not Supported	Polled	Explicit Message

**Release Master/Slave**

The *Release\_Master\_Slave* service (ID #4C)—valid only for the DeviceNet Object—releases the Predefined Master/Slave Connection Set within a Slave. There are no parameters specified for this service (Table 58). This service can be transmitted only across the Group 2 Only Unconnected Explicit Request Message Port as well as an Explicit Messaging Connection [1].

**Table 58: Release Master/Slave Parameter**

Parameter	Data Type	Description
Release Choice	BYTE	Indicates which connections from the Predefined Master/Slave Connection Set are to be released. The process of releasing the connection returns the connection to its initial state, where it can be allocated again.

**Release Choice Parameter**

The *Release Choice* parameter is specified within a single byte (Table 59). Each bit denotes an explicit and/or I/O poll connection(s) from the Predefined Master/Slave Connection Set that is to be released. If the bit is set to one (1), a request is being made to release that particular connection. If the bit is set to zero (0), the connection is not released.

**Table 59: Release Choice Byte Contents**

7	6	5	4	3	2	1	0
Reserved	0	Not Supported	Not Supported	Reserved	Not Supported	Polled	Explicit Message

**Lock**

The *Lock* service (ID #4D)—valid only for the S-Device Supervisor Object—places the device into the User Mode, which restricts access to all of the read-only attributes *in all of the objects*. This service guarantees the read-only attributes cannot be modified over the network. There are no parameters specified for this service.

## Unlock

The password protected *Unlock* service (ID #4E)—valid only for the S-Device Supervisor Object—places the device into the Calibration Mode, which enables you to modify certain *read-only* attributes of the device. Table 60 lists the parameters for this service.

**Table 60: Unlock Service Parameters**

Parameter	Request	Response	Service Data Type	Description
Password Key	Mandatory	Mandatory	UINT	1243 <sub>hex</sub> = Calibration Mode

### Note



The Perform Fine Zero Offset (0x4B) used in the DMA/DMB is no longer available in the DA01A.

## Perform Coarse Zero Offset (0x32)

The *Perform\_Coarse\_Zero* service (ID #0x32)—valid only for the S-Analog Sensor Object—remotely zeros the device. Specifically, this service instructs the S-Analog Sensor Object to modify the pressure calculations so the current pressure reading in the Corrected Pressure Value attribute (Attribute ID #06) is 0.0. Two other types of zeroing are supported. The first type, zeroing with a Zero Offset (Attribute ID #147), the pressure calculations are adjusted so that the Zero Offset value is added to the pressure calculation value. The second type, zeroing with Target Offset (Attribute #148), the pressure calculations are adjusted such that the current pressure is set to the Target Offset value. This is one additional parameter for this service which determines the type of zeroing (see table 61 below).

The method to issue the *Coarse\_Zero\_Offset* service request is shown below.

**Table 61: Method to Issue the Coarse\_Zero\_Offset Service Request**

Service Code	Class	Instance	Service Data
0x32	0x31	0x01	None, a target of zero will be assumed.
0x32	0x31	0x01	00, normal zeroing and a target of zero will be assumed
0x32	0x31	0x01	01, Zero value unchanged, but Zero Offset (attribute ID #147) is applied to the reported value
0x32	0x31	0x01	02, zeroing and a target of Target Offset (attribute ID #148) will be used.

This service is valid only when the Raw Pressure Value is within  $-4$  to  $+20\%$  of the full scale range of the device. Refer to *S-Analog Sensor Object*, page 69, for more information.



## Appendix D: Example Messages

### General Information

The DeviceNet messaging protocol is based on hexadecimal (base 16) math, rather than decimal (base 10) math. The examples in this appendix, designed to illustrate how DeviceNet messages are generated and interpreted, assume a basic understanding of hexadecimal math.

In the actual application of DeviceNet communications, the messaging process is typically automated using an interface software program; therefore, manual calculation or interpretation of the messages is not required. Typical interface programs require only the input of specific class codes, instance IDs, attribute IDs, and any required data variable(s).

### Explicit Messaging

Explicit messaging connections utilize a direct request/response format that enables you to access any attribute data. Explicit messaging typically is used for the setup, configuration, and calibration of your device. Refer to *Explicit Messaging Connections*, page 50, for more information.

Three examples of explicit messages are described on pages 116 to 121. These messages illustrate how to request information on the Vendor ID and interpret the network's response. The following information applies for each example:


- The examples depict *explicit* messaging.
- The examples are all nonfragmented message strings.
- The node address of the MKS device (the Slave) is 05.
- The node address of the master device is 01.
- Spaces are shown for clarity only. Do not enter spaces in the actual message string.

### Example 1: Sending an Explicit Request Message

To query the Vendor ID for your transducer, enter the command:

42C 01 0E 01 01 01

where:



**Figure 11: Explicit Request Message**

To calculate the request message components shown in Figure 12:

1. Calculate the hexadecimal value of the CAN Identifier Field.

Refer to Figure 12, step 1, page 117. This 11-bit field represents the fixed Group 2 Message ID (bits 10 and 9), the *destination* node address (the MKS device) as a hexadecimal number (bits 8 to 3), and the fixed Message Type ID for an explicit request (bits 2 to 0). The hexadecimal value of the CAN Identifier Field components is 42C<sub>hex</sub>.

2. Calculate the hexadecimal value of the message header in the CAN Data Field.

Refer to Figure 12, step 2, page 117. This 8-bit field represents the fragment bit (bit 7, set to 0), the XID bit (bit 6, set to 0), and the *source* node address (the Master device) as a hexadecimal number (bits 5 to 0). The hexadecimal value of the Message Header is 01<sub>hex</sub>.


3. Calculate the hexadecimal value of the Service Code in the message body of the CAN Data Field.

Refer to Figure 12, step 3, page 117. This 8-bit field represents the request bit (bit 7, set to 0) and the assigned Service ID (bits 6 to 0) as a hexadecimal number. The assigned hex value for the Get\_Attribute\_Single service is 0E<sub>hex</sub>. The hexadecimal value of the Service Code is 0E<sub>hex</sub>.

4. Confirm the assigned Class Code, Instance ID, and Attribute ID for the desired parameter.

Refer to Figure 12, step 4, page 117. The requested Vendor ID information is part of the Identity Object (Class Code 01<sub>hex</sub>). Its Instance ID is 01<sub>hex</sub> and its Attribute ID is 01<sub>hex</sub>.

Tables listing the Class Codes, Instance IDs, and Attribute IDs for each parameter are provided throughout this document. This information is summarized for easy reference in Table 51, page 99.




**Figure 12: Explicit Request Message Components**

## Example 2: Interpreting a Successful Explicit Message Response

If the request message sent in *Example 1*, page 116, is properly sent and received, the device returns the following response message:

42B 01 8E 36 00

where:



**Figure 13: Successful Explicit Message Response**

To interpret the response message components shown in Figure **Error! Bookmark not defined.**:

1. Interpret the reported hexadecimal value (42B<sub>hex</sub>) of the CAN Identifier Field components.

Refer to Figure 14 step 1, page 119. This 11-bit field represents the fixed Group 2 Message ID (bits 10 & 9), the *source Node Address* (the MKS device) as a hexadecimal number (bits 8 to 3), and the fixed Message Type ID for an explicit response (bits 2 to 0).

2. Interpret the reported hexadecimal value (01<sub>hex</sub>) of the message header in the CAN Data Field.

Refer to Figure 14, step 2, page 119. This 8-bit field represents the fragment bit (bit 7, set to 0), the XID bit (bit 6, set to 0), and the *destination Node Address* (the Master device) as a hexadecimal number (bits 5 to 0).

3. Interpret the reported hexadecimal value (8E<sub>hex</sub>) of the Service Code in the message body of the CAN Data Field.

Refer to Figure 14, step 3, page 119. This 8-bit field represents the response bit (bit 7, set to 1), and the assigned Service ID (bits 6 to 0) as a hexadecimal number. The assigned hex value for the Get\_Attribute\_Single service is 0E<sub>hex</sub>; the response to this service is always 8E<sub>hex</sub>.

### Note




The Class Code, Instance ID, and Attribute ID are not returned in a response message.

4. Interpret the reported data response (36 00).

Refer to Figure 14, step 4, page 119. The assigned data type for the Vendor ID is an unsigned 16-bit integer value (Table 20, page 57). The assigned Vendor ID for all MKS devices is 36.






**Figure 14: Successful Explicit Message Response Components**

### Example 3: Interpreting an Explicit Message Error Response

If the request message sent in *Example 1*, page 116, is not sent or received properly, the device returns an error response message. An example of an error response is:

42B 01 94 08 FF

where:



**Figure 15: Explicit Message Error Response**


To interpret the error response message components shown in Figure **Error! Bookmark not defined.**:

- Interpret the reported hexadecimal value (42B<sub>hex</sub>) for the CAN Identifier Field.
 

Refer to Figure **Error! Bookmark not defined.**, step 1, page 121. This 11-bit field represents the fixed Group 2 Message ID (bits 10 and 9), the *source* node address (the MKS device) as a hexadecimal number (bits 8 to 3), and the fixed Message Type ID for an explicit response (bits 2 to 0).
- Interpret the reported hexadecimal value (01<sub>hex</sub>) for the message header in the CAN Data Field.
 


Refer to Figure 16, step 2, page 121. This 8-bit field represents the fragment bit (bit 7, set to 0), the XID bit (bit 6, set to 0), and the *destination* node address (the Master device) as a hexadecimal number (bits 5 to 0).
- Interpret the reported hexadecimal value (94<sub>hex</sub>) for the CAN Data Field service code.
 

Refer to Figure **Error! Bookmark not defined.**, step 3, page 121. This 8-bit field represents the response bit (bit 7, set to 1) and the assigned Service ID (bits 6 to 0) as a hexadecimal number. The Service ID for an error response is *always* 14<sub>hex</sub>.

**Note**  The Class Code, Instance ID, and Attribute ID are not returned in a response message.

- Interpret the reported error codes (08 FF).
 

Refer to Figure 16, step 4, page 121. The first 8-bit value reports the General Error Code, assigned by ODVA, which reports the type of error. (Refer to [1] for a complete listing.) The second 8-bit value reports an additional, Object Class specific error message, particular to your MKS transducer. If an additional error code is not applicable, an “FF” is returned.



**Figure 16: Explicit Message Error Response Components**

## **I/O Poll Messaging**

I/O poll messaging connections utilize an assembly format to group and report data from multiple objects using a single communications commands. These connections typically are used for quick reporting of information (run-time). Although I/O poll messaging connections typically report data faster than explicit messaging connections, they limit your access to the set of attributes (the exception status and the pressure value) listed in Tables 32 and 33, page 68. The data in I/O poll messaging connections is defined by the Predefined Master/Slave Connection Set [1] and cannot be altered. Refer to *I/O Poll Messaging Connections*, page 50, for more information.

One example of I/O poll messaging is described on pages 122 to 124. This message describes how to request the poll response for your transducer and interpret the network's response. The following information applies for the example:


- The example depicts *I/O poll* messaging.
- The example is a nonfragmented message string.
- The node address of the MKS device (the Slave) is 05.
- The node address of the master device is 01.
- Spaces are shown for clarity only. Do not enter spaces in the actual message string.

### **Example 1: Sending an I/O Poll Request Message**

To send a I/O poll request message, enter the command:

42D

where:




**Figure 17: I/O Poll Request Message**

To calculate the request message components shown in Figure **Error! Bookmark not defined.:**

1. Calculate the hexadecimal value of the CAN Identifier Field.

Refer to Figure 18. This 11-bit field represents the fixed Group 2 Message ID (bits 10 and 9), the *destination* node address (the MKS device) as a hexadecimal number (bits 8 to 3), and the fixed Message Type ID for an I/O request (bits 2 to 0). The hexadecimal value of the CAN Identifier Field components is 42D<sub>hex</sub>.

I/O poll *request* messages consist of a single segment: the *CAN Identifier Field* which defines the type of connection. When your device receives an I/O poll request, it automatically knows what information is being requested, based on the Predefined Master/Slave Connection Set. Additional descriptive information is not required.




**Figure 18: I/O Poll Request Message Components**

**Example 2: Interpreting an I/O Poll Response Message**

If the request message sent in *Example 1*, page 122, is properly sent and received, the device returns the following response message:

42B 80 FF 3F

where:



**Figure 19: Successful I/O Poll Response Message**

To interpret the response message components shown in Figure 20:

1. Interpret the reported hexadecimal value (42B<sub>hex</sub>) of the CAN Identifier Field components.  
 Refer to Figure 20, step 1, page 124. This 11-bit field represents the fixed Group 2 Message ID (bits 10 & 9), the *source* node address (the MKS device) as a hexadecimal number (bits 8 to 3), and the fixed Message Type ID for an explicit response (bits 2 to 0).


2. Interpret the reported value of poll response #1.

Refer to Figure 20, step 2, page 124. The reported value for the Status Byte ( $80_{\text{hex}}$ ) indicates that no exceptions are set. The Status Byte Bit map is shown in Table 44, page 79. The reported value for the 16-bit pressure value ( $\text{FF } 3\text{F}$ ) indicates that the pressure is measured at 50% FS.

**Note**



The poll response that is returned is defined in the Device Configuration Object (see page 75).



**Figure 20: Successful I/O Poll Response Message Components**

## Index

### A

- Alarms
  - calibration expiration, 85
- Allocation information, 61, 64, 111
- Assembly
  - data format, 63
  - poll messaging, 62
- Assembly object, 62–63
- Attribute summary, 99–106

### B

- Band label, 47
- Baud rate
  - attribute, 60
  - rotary switch, 44, 61
- Bus-off interrupt, 61

### C

- Cables
  - generic shielded, 24
  - interface, 24
- Cal Mode, 49, 55, 57, 59, 62, 63, 65, 67, 75, 77, 81, 86, 99, 101, 103, 105, 106, 108, 113
- Calibration dates, 85
- CAN data field, description of, 52–54
- CAN identifier field, description of, 50–52
- Command summaries
  - attributes, 99–106
  - supported services, 107–9
- Connection object, 64–68
- Connectors
  - DMA, 29
  - DMA unit, 29–30

- Customer support, 21

### D

- Data format, 63
- Device configuration object, 70–75
- Device manager object, 77–86
- Device type, 57, 75, 77
- DeviceNet messaging
  - description of, 49
  - examples of, 115–24
- Digital operation, 49–86
- Digital zero, 34

### E

- Ethernet, 35
- Example messages, 115–24
- Exception
  - detail alarm, 80
- Explicit messaging connections, 50

### F

- Fault conditions, 45
- Firmware revision level, 78
- Fittings, 27, 93, 97, 98
- full scale range, 47, 96, 113
- Full scale range, 19, 32, 34, 96

### G

- Grounding, 29

### H

- Hardware revision level, 78
- Hysteresis, definition of, 46

**I**

I/O poll messaging connections, 50

Identity object, 57–58

Installation Category, 25

**L**

Labels

band label, 47

serial number label, 47

LED Indicators, 27

LEDs

module status, 42

network status, 43

power up sequence, 30

Lock service, 82

**M**

MAC ID

attribute, 60

rotary switch, 44, 60

Maintenance, 87

Manual organization, 20

Manufacturer, 78

Manufacturer model number, 78

Message connections, 49

Message formats, 50

Mode

cal, 49, 55, 57, 59, 62, 63, 65, 67, 75, 77, 81, 82, 86, 99, 101, 103, 105, 106, 108, 113

user, 49, 57, 59, 62, 63, 75, 81, 82, 86, 99, 108, 112

Model code, 47

Mounting instructions

DMA unit, 28

**N**

Network manager object, 59–61

Non-volatile RAM, 55

**O**

Object model

description of, 18, 55

Operating modes, 49, 81

Output pressure object, 69

**P**

Perform\_Remote\_Zero, 113

Poll response, 62

Pollution Degree, 25

Power requirements, 90

Power up, 30

Pressure

lowest for control, 32

lowest for reading, 32

value, unzeroed, 113

Pressure measurement, description of, 40

Product

code, 57

name, 58

revision, 57

**R**

Remote zero, 113

Returning the product, 21, 23, 87

Revision class attribute

network manager object, 59

RoHS (Restriction of Hazardous Substances), 17, 93

Run hours, 85



## **S**

- Safety information, 1–16
- Sensor, description of, 39
- Serial number
  - ASCII string, 78
  - label, 47
  - ODVA format, 58
- Signal Conditioner/Electronics, 39
- Standard revision level, 77
- Startup
  - LED sequence, 30
  - pressures for reading and control, 32
  - reporting the pressure value, 32
  - warm up time, 31
  - zero adjustment, 31
- Status
  - device, 58

## **T**

- Temperature, 25
- Trip point
  - delay, 46
  - hysteresis, 46

## **U**

- User Mode, 49, 57, 59, 62, 63, 75, 81, 86, 99, 108, 112
- User Switch, 27
- User tag, 81

## **V**

- Vendor, 57
- Visual indicator, 81

## **W**

- Warm up time, 31

## **Z**

- Zero adjustment, 31, 87
  - digital (zero offset), 34
  - Perform\_Remote\_Zero, 113
- Zero Adjustments Modes, 35
- Zero Pushbutton, 28
- Zeros, description of, 33