DATA SHEET

HTRC110

Hitag Reader Chip

Product Specification Revision 3.0 Public Information July 2006 037030





Table of Contents

1.	Feat	ures	4										
2.	Intro	oduction	4										
3.	Orde	ering Information	4										
4.	Bloc	k Diagram	5										
5.	Key	Data	5										
6.	Pinn	ing Information	6										
	6.1.	Pinning Diagram	6										
	6.2.	Pin Description	6										
7.	Minii	mum Application Circuitry	7										
8.	Fund	Functional Description											
	8.1.	Power Supply	7										
	8.2.	Antenna Driver, Data Input	8										
	8.3.	Diagnosis 8											
	8.4.	Oscillator / Programmable Divider / Clock	8										
	8.5.	Adaptive Sampling Time Demodulator	8										
	8.6.	Idle and Power-down Mode	9										
	8.7.	Serial Interface	9										
	8.8.	Glitch Filter for Increased Noise/Interference Immunity	10										
9.	Com	nmands	11										
	9.1.	READ_TAG	11										
	9.2.	WRITE_TAG_N	11										
	9.3.	WRITE_TAG	12										
	9.4.	READ_PHASE	12										
	9.5.	SET_SAMPLING_TIME	12										
	9.6.	GET_SAMPLING_TIME	12										
	9.7.	SET_CONFIG_PAGE	13										
	9.8.	GET_CONFIG_PAGE	14										
10.	Abso	olute Maximum Ratings	15										
11.	DC C	Characteristics	16										
12.	AC C	Characteristics	17										
13.	Pack	kage	18										
14.	Abre	eviations	19										
15	Revi	sion History	19										

Definitions

Data sheet status											
Objective specification	This data sheet contains target or goal specifications for product development.										
Preliminary specification	This data sheet contains preliminary data; supplementary data may be published later.										
Product specification	This data sheet contains final product specifications.										
Limiting values											

Limiting values given are in accordance with the Absolute Maximum Rating System (IEC 134). Stress above one or more of the limiting values may cause permanent damage to the device. These are stress ratings only and operation of the device at these or at any other conditions above those given in the Characteristics section of the specification is not implied. Exposure to limiting values for extended periods may affect device reliability.

Application information

Where application information is given, it is advisory and does not form part of the specification.

Disclaimer

Field of Use - Philips owns a worldwide perpetual license for patents US 5,214,409, US 5,499,017, US 5,235,326, and for any foreign counterparts or equivalents of these patents. The license is granted for the Philips Field. The Philips Field covers:

- (a) all non-animal applications and
- (b) any application for animals raised for human consumption (including but not limited to dairy animals), including without limitation livestock and fish.

Please note that the license does not include rights outside the Philips Field, and that Philips does not provide indemnity for the foregoing patents outside the Philips Field. In case you intend to use the product related to this data sheet outside the "Philips Field" we recommend that you consult a Philips representative for further clarification.

Life support applications - These products are not designed for use in life support appliances, devices, or systems where malfunction of these products can reasonably be expected to result in personal injury. Philips Semiconductors customers using or selling these products for use in such applications do so at their own risk and agree to fully indemnify Philips Semiconductors for any damages resulting from such application.

Right to make changes - Philips Semiconductors reserves the right to make changes in the products - including circuits, standard cells, and/or software - described or contained herein in order to improve design and/or performance. When the product is in full production (status 'Production'), relevant changes will be communicated via a Customer Product/Process Change Notification (CPCN). Philips Semiconductors assumes no responsibility or liability for the use of any of these products, conveys no licence or title under any patent, copyright, or mask work right to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified.

1. Features

Combines all analogue RFID reader hardware in a single chip:

- Optimized for HITAG transponder family
- Robust antenna coil power driver stage with modulator
- High performance adaptive sampling time AM/PM demodulator (patent pending)
- Read and write function
- On-chip clock oscillator
- Antenna rupture and short circuit detection
- Low power consumption
- Very low power stand-by mode
- Low external component count
- Small package (SO14)

2. Introduction

The Hitag Reader Chip HTRC110 is intended for use with transponders, which are based on the HITAG silicon (HT1ICS30 02x or HT2ICS20 02x). (E.g. the HITAG 2 stick HT2DC20 S20 may be operated with the use of the Reader Chip). In addition the IC supports other 125kHz transponder types using amplitude modulation for the write operation and AM/PM for the read operation. The receiver parameters (gain factors, filter cutoff frequencies) can be optimized to system and transponder requirements. The HTRC110 is designed for easy integration into RF-identification readers. State-of-the-art technology allows almost complete integration of the necessary building blocks. A powerful antenna driver/modulator together with a low-noise adaptive sampling time demodulator, programmable filters/amplifier and digitizer build the complete transceiver unit, required to design high-performance readers. A three-pin microcontroller interface is employed for programming the HTRC110 as well as for the bidirectional communication with the transponders. The three-wire interface can be changed into a two-wire interface by connecting the data input and the data output.

Tolerance dependent zero amplitude modulation caused severe problems in envelope detector systems, resulting in the need of very low tolerance reader antennas. These problems are solved by the new Adaptive Sampling Time technique (AST).

3. Ordering Information

TYPE NAME	DESCRIPTION	ORDERING NUMBER
HTRC110 01T/02EE	Hitag Reader IC, Tube	9352 600 91112
HTRC110 01T/03EE	Hitag Reader IC, Reel	9352 600 92118

July 2006 HTRC110 Hitag Reader Chip Rev. 3.0

4. Block Diagram




Figure 1: Block diagram Hitag Reader Chip HTRC110

5. Key Data

Supply VDD $5 V \pm 10\%$

Clock/Osc. frequency 4,8,12,16 MHz programmable

(antenna carrier frequency 125 kHz)

Antenna driver current 200 mAp continuous Serial interface CMOS compatible

Package SO14

Operation temperature range -40°C to $+85^{\circ}\text{C}$

6. Pinning Information

6.1. Pinning Diagram




Figure 2: Pinning Diagram

6.2. Pin Description

Number	Symbol	Description
1	VSS	GND, negative supply input
2	TX2	Coil driver output
3	VDD	Stabilized 5 V supply input
4	TX1	Coil driver output
5	MODE	To enable filtering of SCLK and DIN (for active antenna applications)
6	XTAL1	Oscillator interface, input
7	XTAL2	Oscillator interface, output
8	SCLK	Microcontroller interface: serial clock input
9	DIN	Microcontroller interface: serial data in
10	DOUT	Microcontroller interface: serial data out
11	n.c.	Not connected
12	CEXT	High pass filter coupling
13	QGND	Analog ground bias
14	RX	Demodulator input

7. Minimum Application Circuitry

The following figure shows a minimal application circuitry for the HTRC110. The reader coil L_a together with the capacitor C_a forms a series resonant LC circuit (f = 125 kHz). The high voltages in the LC circuit are divided to safe operating levels by R_v and the chip internal resistor $R_{\text{dem_in}}$ behind the RX-pin. The two capacitors connected to XTAL1 and XTAL2 shall be the recommended values and types from the crystal's data sheet. Alternatively to a crystal a ceramic resonator can be used or an external clock source can be connected to XTAL1.




Figure 3: Minimum application circuitry

8. Functional Description

8.1. Power Supply

The HTRC110 works with an external $5V\pm10\%$ power supply at VDD. The maximum DC-current is $10\text{mA}+\hat{I}_{ant}*2/\pi=137\text{mA}$. For optimum performance, the power supply connection should be bypassed to ground with a 100nF capacitor close to the IC.

8.2. Antenna Driver, Data Input

The drivers deliver a square shaped voltage to the series resonant antenna circuit. Due to the full bridge configuration of the drivers this voltage U_{drvpp} is approximately 10V (peak-peak) corresponding to \hat{U}_{drv} =5V. The current flowing through the antenna is sine shaped. It's amplitude is approximately:

$$\hat{I}_{ant} = \frac{4}{\pi} \frac{\hat{U}_{drv}}{R_{ant}} \Leftrightarrow I_{ant_{rms}} = \frac{\hat{I}_{ant}}{\sqrt{2}}$$

8.3. Diagnosis

In order to detect an antenna short or open condition the antenna tap voltage is monitored. An antenna fail condition is reported in the status bit ANTFAIL (see Table 14), if the antenna tap voltage does not go more negative than the diagnosis level DLEV (see Table 16). This condition is checked for every coil driver cycle.

8.4. Oscillator / Programmable Divider / Clock

The crystal oscillator at XTAL1/2 works with either crystal or ceramic resonators. It delivers the input clock frequency of 4,8,12 or 16 MHz. The oscillator frequency is divided by a programmable divider to obtain the carrier frequency of 125 kHz (see Table 10). Alternatively, an external clock signal (CMOS compatible) may be fed into the IC via XTAL1. For example, this signal can be derived from the microcontroller clock.

8.5. Adaptive Sampling Time Demodulator

The demodulator senses the absorption modulation applied by a transponder when inserted into the field. The signal is picked up at the antenna tap point between L_a and C_a . It is divided by R_v and the internal resistor $R_{\text{dem_in}}$ to a level below 8V (peak) with respect to QGND at the RX-pin (see Figure 3). Internally the signal is filtered with a second order low pass filter.

The antenna current and therefore the tap voltage is modulated by the transponder in amplitude and/or phase. This signal is fed into a synchronous demodulator recovering the baseband signal. The amplification and the bandpass filter edge frequencies of the demodulator can be adapted to different transponders via settings in the configuration pages.

The phase between the driver excitation signal and the antenna tap voltage depends on the antenna tuning. With optimum tuning, the phase of the antenna tap voltage is 90 degrees off the antenna driver signal. Detuning of the antenna resonant circuit results in a change of this phase relationship.

The HTRC110's built-in phase measurement unit allows the measurement of this phase relationship with a resolution of 360°/64=5.625°. This can be used to compute a sampling time that compensates the mistuning of the reader antenna. The phase measurement procedure can be carried out:

- either once before the first communication starts, if the position of the transponder does not change with the respect to the reader antenna

- or during the communication (after sending the write pulses and before receiving the answer of the transponder), if the tag is moving.

Before the system is switched into WRITE_TAG-mode, the demodulator has to be frozen. This is internally done by clamping the input of the amplifier/filter unit to QGND. Doing so avoids large transients in the amplifier and the digitizer, which could affect settling times. In addition to the clamping, there exist other means in the HTRC110, which allow further reduction of the settling times. All the parts of the circuitry, which are associated with these functions, are controlled by the FREEZE0, FREEZE1 and THRESET bits, which are located in configuration page 2.

For more details concerning WRITE Timing, Demodulator Setting, Power Up Sequence, etc. please refer to the HTRC110 application note.

8.6. Idle and Power-down Mode

The HTRC110 can be switched into idle mode via setting the PD-bit and resetting the PD_MODE-bit. In this idle mode, only the oscillator and a few other system components are active.

It is also possible to switch the IC completely off. This is achieved by the power-down mode (PD=1, PD_MODE=1). Within this mode also the clock oscillator is switched off. This reduces the supply current of the HTRC110 to less than $20\mu A$.

8.7. Serial Interface

The communication between the HTRC110 and the microcontroller is done via a three wire digital interface. The interface is operated by the following signals:

SCLK Clock
DIN Data Input
DOUT Data Output

SCLK and DIN are realized as Schmitt-Trigger inputs. DOUT is an open drain output with internal pullup resistor.

Every communication between HTRC110 and microcontroller begins with an initialization of the serial interface. The interface initialization condition is a low-to-high transition of the signal DIN while SCLK is high.




Figure 4: Serial Signaling

All commands are transmitted to the HTRC110 serial interface starting with Most Significant Bit (MSB). DIN and DOUT are valid when SCLK is high.

8.8. Glitch Filter for Increased Noise/Interference Immunity

Connecting Pin 5 (MODE) to VDD enables digital filtering of the SCLK and the DIN input signals. This mode offers improved immunity against glitches on these interface signals. It is intended to be used in the so called "Active Antenna Applications" where the microcontroller and the reader communicate via long signal lines (e.g. 1 meter).

In other applications Pin 5 (MODE) has to be connected to GND.

Please refer to the HTRC110 application note for a detailed description of this feature.

9. Commands

Table 1 depicts the HTRC110 command set summary.

Bit No. 7 6 5 3 2 1 0 Remark **Command Name MSB** LSB 8 bit resp. (0 0 D5-D0) 0 0 0 1 0 **GET SAMPLING TIME** 0 0 0 8 bit resp. (X3-X0 D3-D0) GET_CONFIG_PAGE 0 0 0 0 0 1 Р1 P0 8 bit resp. (0 0 D5 - D0) 0 READ_PHASE 0 0 0 0 0 0 1 READ_TAG-mode 1 READ_TAG 1 1 WRITE_TAG-mode with pulse WRITE_TAG_N 0 0 0 1 N3 N2 N1 N0 width programming WRITE TAG-mode 1 WRITE_TAG 1 0 4*4 config bits available 1 Ρ1 P0 D3 D2 D1 SET_CONFIG_PAGE 0 D0 0 SET_SAMPLING_TIME D5 D4 D3 D2 D1 D0

Table 1: HTRC110 Commands

9.1. READ_TAG

This command is used to read the demodulated bit stream from a transponder: After the assertion of the three command bits the HTRC110 instantaneously switches to READ_TAG-mode and transmits the demodulated, filtered and digitized data from the transponder. Data comes out and should be decoded by the microcontroller. READ_TAG-mode is terminated by a low to high transition at SCLK.

Table 2: READ_TAG Command

Bit No.	7	6	5	4	3	2	1	0	Remark
Command	1	1	1	-	-	received data available at D		received data available at DOUT	

9.2. WRITE TAG N

This command is used to write data to a transponder.

If N3-N0 are set to zero, the signal from DIN is transparently switched to the drivers. A high level at DIN corresponds to antenna drivers witched off, a low level corresponds to antenna drivers switched on.

If any binary number between 1 and 1111 is loaded into N3-N0 the drivers are switched off at the next positive transition of DIN. This state is held for a time interval equal to N * T_0 (T_0 =8 μ s). This method relaxes the timing resolution requirements to the microcontroller and to the software implementation while providing exact, selectable write pulse timing. WRITE_TAG-mode is terminated immediately by a low to high transition at SCLK.

Table 3: WRITE_TAG_N Command

Bit No.	7	6	5	4	3	2	1	0	Remark
Command	0	0	0	1	N3	N2	N1	NO	no response

9.3. WRITE TAG

This is the 3 bit short form of the previously described command WRITE_TAG_N. It allows to switch into WRITE_TAG-mode with a minimum communication time.

The behaviour of the WRITE_TAG command is identical to WRITE_TAG_N with two exceptions:

- WRITE_TAG-mode is entered after assertion of the 3rd command bit.
- No N parameter is specified with this command; instead the N value, which was programmed with the most recent WRITE_TAG_N command, is used. If no WRITE_TAG_N was issued so far, a default N=0 (transparent mode) will be assumed.

Table 4: WRITE_TAG Command

Bit No.	7	6	5	4	3	2	1	0	Remark
Command	1	1	0	-	-	-	-	-	no response

9.4. READ_PHASE

This command is used to read the antenna's phase, which is measured at every carrier cycle. The phase is coded binary in D5-D0.

Table 5: READ_PHASE Command

Bit No.	7	6	5	4	3	2	1	0	Remark
Command	0	0	0	0	1	0	0	0	
Response	0	0	D5	D4	D3	D2	D1	D0	

9.5. SET_SAMPLING_TIME

This command specifies the demodulator sampling time t_s . The sampling time is coded binary in D5-D0.

Table 6: SET_SAMPLING_TIME Command

Bit No.	7	6	5	4	3	2	1	0	Remark
Command	1	0	D5	D4	D3	D2	D1	D0	no response

9.6. GET_SAMPLING_TIME

This command is used to read back the sampling time to set with SET_SAMPLING_TIME. The sampling time is coded binary in D5-D0.

Table 7: GET_SAMPLING_TIME Command

Bit No.	7	6	5	4	3	2	1	0	Remark
Command	0	0	0	0	0	0	1	0	
Response	0	0	D5	D4	D3	D2	D1	D0	

9.7. SET_CONFIG_PAGE

This command is used to set the amplifier and filter parameters (cutoff frequencies, gain factors) and the different operation modes. P1 and P0 select one of four configuration pages.

Table 8: SET_CONFIG_PAGE Command

Bit No.	7	6	5	4	3	2	1	0	Remark
Command	0	1	P1	P0	D3	D2	D1	D0	no response

Table 9: Config Pages

	Bit No.	P1	P0	D3	D2	D1	D0
Command/Page No.							
SET_CONFIG_PAGE 0		0	0	GAIN1	GAIN0	FILTERH	FILTERL
SET_CONFIG_PAGE 1		0	1	PD_MODE	PD	HYSTERESIS	TXDIS
SET_CONFIG_PAGE 2		1	0	THRESET	ACQAMP	FREEZE1	FREEZE0
SET_CONFIG_PAGE 3		1	1	DISLP1	DISSMART-	FSEL1	FSEL0
					COMP		

Table 10: Bit Initial Conditions

Bit name	Description	Initial condition	
FILTERL	main low pass cutoff frequency	0	0: fL = 3 kHz
			1: fL = 6 kHz
FILTERH	main high pass cutoff frequency	0	0: fH = 40 Hz
			1: fH = 160 Hz
GAIN0	amplifier_0 gain factor	0	0: gain ₀ = 16; 1: gain ₀ = 32
GAIN1	amplifier_1 gain factor	1	0: gain₁ = 6.22; 1: gain₁ = 31.5
TXDIS	disable coil driver	0	0: coil driver active
			1: coil driver inactive
HYSTERESIS	data comparator hysteresis	0	0: hysteresis OFF
			1: hysteresis ON
PD	power down mode enable	0	0: device active
			1: device power down
PD_MODE	select power down mode	0	0: idle mode
			1: power down
FREEZE0	facility to achieve fast settling times	0	see table 11
FREEZE1	facility to achieve fast settling times	0	see table 11
ACQAMP	store signal amplitude as reference	0	see status bit AMPCOMP
	for later amplitude comparison		
THRESET	reset threshold generation of	0	
	digitizer		
FSEL0	clock frequency select LSB	0	00: 4MHz, 01: 12MHz
FSEL1	clock frequency select MSB	0	10: 8MHz, 11: 16MHz
DISSMARTCOMP	disable smart comparator	0	0: smart comparator = ON
			1: smart comparator = OFF
DISLP1	disable low pass 1	0	0: low pass = ON
			1: low pass = OFF

Table 11: Freeze Bit Description

FREEZE1	FREEZE0	Meaning
0	0	normal operation
0	1	main low pass is frozen; main high pass is precharged to QGND
1	0	main low pass is frozen; time constant of main high pass is reduced by a factor of 16 for FILTERH=0 and by a factor of 8 for FILTERH=1
1	1	time constant for main high pass is reduced by a factor of 16 for FILTERH=0 and by a factor of 8 for FILTERH=1; second high pass is precharged

9.8. GET_CONFIG_PAGE

This command has three functions:

- 1. Reading back the configuration parameters set by SET_CONFIG_PAGE command
- 2. Reading back the transmit pulse width programmed with WRITE_TAG_N
- 3. Reading the system status information

P1 and P0 select one of four configuration pages. The response (X3 X2 X1 X0 D3 D2 D1 D0) contains the contents of the selected configuration page in its lower nibble. For P=0 or P=1 the higher nibble reflects the current setting of N (the transmit pulse width). For P=2 or P=3 the system status information is returned in the higher nibble.

Table 12: GET_CONFIG_PAGE Command

Bit No.	7	6	5	4	3	2	1	0	Remark
Command	0	0	0	0	0	1	P1	P0	
Response	Х3	X2	X1	X0	D3	D2	D1	D0	

Table 13: Config Pages

Bit No.	7	6	5	4	3	2	1	0
Command/Page No.								
GET_CONFIG_PAGE 0	N3	N2	N1	N0	D3	D2	D1	D0
GET_CONFIG_PAGE 1	N3	N2	N1	N0	D3	D2	D1	D0
GET_CONFIG_PAGE 2	0 (RFU)	0 (RFU)	AMPCOMP	ANTFAIL	D3	D2	D1	D0
GET_CONFIG_PAGE 3	0 (RFU)	0 (RFU)	AMPCOMP	ANTFAIL	D3	D2	D1	D0

Table 14: Status Bit Description

Bit name	Meaning	
ANTFAIL	antenna failure	0: antenna ok
		1: antenna failure
AMPCOMP	amplitude comparison result	When ACQAMP is set, the actual amplitude of the data signal is stored as reference. After resetting ACQAMP status bit AMP-COMP is set when the actual data signal amplitude is higher than the stored reference.

10. Absolute Maximum Ratings

Table 15 lists the limiting values. Stress above one or more of the limiting values may cause permanent damage to the device. These are stress ratings only and operation of the device at these or at any other conditions above those given in the characteristics sections of this specification is not implied. Exposure to limiting values for extended periods may affect device reliability.

Table 15: Limiting Values

Parameter	Symbol	Min.	Max.	Unit
Voltage at any pin except RX		-0.3	+6.5	V
Voltage at any pin except RX		-0.3	VDD+0.3	V
Voltage at RX pin		-10	+12	V
Maximum junction temperature	T_{j}		140	ů
Storage temperature range	T _{store}	-65	+125	Ŝ

11. DC Characteristics

Table 16 lists the DC characteristics. All voltages are measured to V_{ss} , T_{amb} = -40°C to +85°C.

Table 16: DC Characteristics

Parameter	Conditions	Symbol	Min.	Тур.	Max.	Unit				
	Supply									
Supply voltage		VDD	4.5	5.0	5.5	٧				
Operating supply current	VDD=5.5V, I _{TX1} =I _{TX2} =0	I _{On}		4	10	mΑ				
Idle current ⁽¹⁾	VDD=5.5V	I _{id}		0.2	0.4	mΑ				
Power down current	VDD=5.5V	I _{pd}		7	20	μΑ				
Drivers (TX1, TX2)										
Output peak-current	permanent	I _{ant}			200	mΑ _p				
Output peak-current	1:4 On/off-ratio t _{on} <400ms	I _{antPulse}			400	mΑ _p				
Output resistance	both drivers together			2.5	7	Ω				
Demodulator Input										
Voltage range	U _{RX} with respect to QGND		-8		8	V				
QGND Potential			0.35 VDD	0.42 VDD	0.5 VDD	V				
Impedance		R _{dem_in}	17	25	33	kΩ				
Diagnosis Level (DLEV)										
	U _{RX} with respect to QGND, VDD=5V	DLEV	-1.5	-1.15	-0.8	V				
Digital Inputs		·								
Data input high voltage		V _{IH}	0.7 VDD		VDD+0.3 V	V				
Data input low voltage		V _{IL}	- 0.3 V		0.3 VDD	V				
Digital Outputs										
Output low	$I_{OL max} = +1mA$	VoL			0.4	V				
Output drive capability	$V_{OL} \leq 0.4V$		1			mA				

^{1.} Power consumption of external quartz or any other external component is not included

12. AC Characteristics


Table 17 lists the AC characteristics. Tamb = -40° C to $+85^{\circ}$ C.


Table 17: AC Characteristics


Parameter	Conditions	Symbol	Min.	Тур.	Max.	Unit		
XTAL Oscillator (XTAL1/XTAL2)								
Frequency range	depending on FSEL	f _{osc}	4		16	MHz		
Start-up time				4	10	ms		
Input capacitance	XTAL1			5		рF		
Input resistance	XTAL1 to XTAL 2		0.9	1.3	3.0	$M\Omega$		
External Clock (XTAL1)								
Frequency range	depending on FSEL		4		16	MHz		
Duty cycle			40		60	%		
Serial Interface								
Setup time	MODE pin at V _{ss}	Ts	50			ns		
Hold time	MODE pin at V _{ss}	T _H	50			ns		
Receiver								
Sensitivity	at RX input	U_{RX}	2	1		mV_{pp}		
Receiver delay	FILTERL=0	T _{RCV0}	290	310	340	μs		
Receiver delay	FILTERL=1	T _{RCV1}	160	175	190	μs		
Recovery from Clock Stable to D	emodulator Valid							
Recovery time demodulator ⁽¹⁾		T _{RPD}			5	ms		
Recovery from WRITE-pulse								
Recovery of demodulator ⁽¹⁾		T _{RWD}			500	μs		
Recovery from AST-step	Recovery from AST-step							
Recovery of demodulator		T _{RAST}		0.7	1.5	ms		
Phase measurement error					±5.7	deg		

^{1.} These short times require special command sequences. Please refer to the application note "AN97070 Read/Write Devices based on the HITAG Read/Write IC HTRC110".

13. Package







14. Abreviations

 $\begin{array}{lll} \text{Amplitudes of sine shaped signals:} & \hat{U}, \hat{I} \\ \text{Peak-to-peak of arbitrary shaped signals:} & U_{pp}, I_{pp} \\ \text{Zero-to peak of arbitrary shaped signals:} & U_{p}, I_{p} \end{array}$

15. Revision History

Revision	Date	CPCN	Page	Description
2.2	Jan 1999			Initial Version
3.0	July 2006		3	Add Disclaimer Section:
				- Philips Field of Use
				- Philips Right to make changes

Philips Semiconductors - a worldwide company

Argentina: see South America

Australia: 34 Waterloo Road, NORTHRYDE, NSW 2113,

Tel. +612 9805 4455, Fax. +612 9805 4466

Austria: Computerstraße 6, A-1101 WIEN, P.O.Box 213,

Tel. +431 60 101. Fax. +431 30 101 1210

Belarus: Hotel Minsk Business Centre, Bld. 3, r.1211, Volodarski Str. 6, 220050 MINSK, Tel. +375172 200 733, Fax. +375172 200 773

Belgium: see The Netherlands Brazil: see South America

Bulgaria: Philips Bulgaria Ltd., Energoproject, 15th floor,

51 James Bourchier Blvd., 1407 SOFIA Tel. +3592 689 211, Fax. +3592 689 102 Canada: Philips Semiconductors/Components,

Tel. +1800 234 7381

China/Hong Kong: 501 Hong Kong Industrial Technology Centre,

72 Tat Chee Avenue, Kowloon Tong, HONG KONG,

Tel. +85223 19 7888, Fax. +85223 19 7700

Colombia: see South America Czech Republic: see Austria

Denmark: Prags Boulevard 80, PB 1919, DK-2300 COPENHAGEN S,

Tel. +4532 88 2636, Fax. +4531 57 1949 Finland: Sinikalliontie 3, FIN-02630 ESPOO, Tel. +3589 61 5800, Fax. +3589 61 580/xxx

France: 4 Rue du Port-aux-Vins, BP 317, 92156 SURESNES Cedex, Tel. +331 40 99 6161, Fax. +331 40 99 6427

Germany: Hammerbrookstraße 69, D-20097 HAMBURG,

Tel. +4940 23 53 60, Fax. +4940 23 536 300 Greece: No. 15, 25th March Street, GR 17778 TAVROS/ATHENS,

Tel. +301 4894 339/239, Fax. +301 4814 240

Hungary: see Austria

India: Philips INDIA Ltd., Shivsagar Estate, A Block, Dr. Annie Besant Rd.

Worli, MUMBAI 400018, Tel. +9122 4938 541, Fax. +9122 4938 722

Indonesia: see Singapore

Ireland: Newstead, Clonskeagh, DUBLIN 14,

Tel. +3531 7640 000, Fax. +3531 7640 200

Israel: RAPAC Electronics, 7 Kehilat Saloniki St., TEL AVIV 61180,

Tel. +9723 645 0444, Fax. +9723 649 1007 Italy: Philips Semiconductors, Piazza IV Novembre 3

20124 MILANO, Tel. +392 6752 2531, Fax. +392 6752 2557

Japan: Philips Bldg. 13-37, Kohnan 2-chome, Minato-ku, TOKYO 108,

Tel. +813 3740 5130,Fax. +813 3740 5077

Korea: Philips House, 260-199, Itaewon-dong, Yonsan-ku, SEOUL,

Tel. +822 709 1412, Fax. +822 709 1415

Malaysia: No. 76 Jalan Universiti, 46200 PETALING JAYA, Selangor,

Tel. +60 3750 5214, Fax. +603 757 4880

Mexico: 5900 Gateway East, Suite 200, EL PASO, Texas 79905, Tel. +9 5800 234 7381

Middle East: see Italy

Netherlands: Postbus 90050, 5600 PB EINDHOVEN, Bldg. VB,

Tel. +3140 27 82785, Fax +3140 27 88399

New Zealand: 2 Wagener Place, C.P.O. Box 1041, AUCKLAND,

Tel. +649 849 4160, Fax. +649 849 7811

Norway: Box 1, Manglerud 0612, OSLO, Tel. +4722 74 8000, Fax. +4722 74 8341

Philippines: Philips Semiconductors Philippines Inc. 106 Valero St. Salcedo Village, P.O.Box 2108 MCC, MAKATI,

Metro MANILA, Tel. +632 816 6380, Fax. +632 817 3474 Poland: UI. Lukiska 10, PL 04-123 WARSZWA,

Tel. +4822 612 2831, Fax. +4822 612 2327

Portugal: see Spain Romania: see Italy

Russia: Philips Russia, Ul. Usatcheva 35A, 119048 MOSCOW,

Tel. +7095 247 9145, Fax. +7095 247 9144

Singapore: Lorong 1, Toa Payoh, SINGAPORE 1231, Tel. +65350 2538, Fax. +65251 6500

Slovakia: see Austria Slovenia: see Italy

South Africa: S.A. Philips Pty Ltd., 195-215 Main Road Martindale, 2092 JOHANNESBURG, P.O.Box 7430 Johannesburg 2000,

Tel. +2711 470 5911, Fax. +2711 470 5494

South America: Rua do Rocio 220, 5th floor, Suite 51, 04552-903 Sao Paulo, SAO PAULO - SP, Brazil, Tel. +5511 821 2333, Fax. +5511 829 1849 Spain: Balmes 22, 08007 BARCELONA,

Tel. +343 301 6312, Fax. +343 301 4107

Sweden: Kottbygatan 7, Akalla, S-16485 STOCKHOLM, Tel. +468 632 2000, Fax. +468 632 2745

Switzerland: Allmendstraße 140, CH-8027 ZÜRICH,

Tel. +411 488 2686, Fax. +411 481 7730 Taiwan: Philips Taiwan Ltd., 2330F, 66

Chung Hsiao West Road, Sec. 1, P.O.Box 22978

TAIPEI 100, Tel. +8862 382 4443, Fax. +8862 382 4444

Thailand: Philips Electronics (Thailand) Ltd.,

209/2 Sanpavuth-Bangna Road Prakanong, BANGKOK 10260,

Tel. +662 745 4090, Fax. +662 398 0793

Turkey: Talapasa Cad. No. 5, 80640 GÜLTEPE/ISTANBUL,

Tel. +90212 279 2770, Fax. +90212 282 6707

Ukraine: Philips Ukraine, 4 Patrice Lumumba Str., Building B, Floor 7,

252042 KIEV, Tel. +38044 264 2776, Fax. +38044 268 0461 United Kingdom: Philips Semiconductors Ltd., 276 Bath Road, Hayes, MIDDLESEX UM3 5BX, Tel. +44181 730 5000, Fax. +44181 754 8421

United States: 811 Argues Avenue, SUNNYVALE, CA94088-3409, Tel. +1800 234 7381

Uruguay: see South America

Vietnam: see Singapore

Yugoslavia: Philips, Trg N. Pasica 5/v, 11000 BEOGRAD,

Tel. +38111 625 344, Fax. +38111 635 777

Philips Semiconductors Gratkorn GmbH, Mikron-Weg 1, A-8101 Gratkorn, Austria Fax: +43 3124 299 - 270

For all other countries apply to: Philips Semiconductors, Marketing & Sales Communications, Building BE-p, P.O.Box 218, 5600 MD EINDHOVEN, The Netherlands, Fax: +3140 27 24825

Internet: http://www.semiconductors.philips.com

SCR52 © Philips Electronics N.V. 1997

All rights are reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner.

The information presented in this document does not form part of any quotation or contract, is believed to be accurate and reliable and may be changed without any notice. No liability will be accepted by the publisher for any consequence of its use. Publication thereof does not convey nor imply any license under patent- or other industrial or intellectual property rights.





