The Thermo Fisher Scientific wireless telemetry system represents the next generation of wireless monitoring, which builds upon the foundation of the original Thermo Scientific system.

# TeleDosimetry System<sup>™</sup>

Wireless telemetry system



- Dose and dose rate reporting
- Alarm conditions reporting
- Audible and visual local alarm via EPD
- Easily replaced, separate standard AAA alkaline battery in dosimeter transmitter
- Pocket mounting
- Uses a standard Thermo Scientific Mk 2 EPD
- Two way communication hardware allows dynamic changes to alarm set points and notification to targeted field units





Specifically designed for the new Mk 2 EPD, the major enhancements of the telemetry system is its smaller and lighter design, automatic roaming feature, as well as approx. +30%range as compared to other commercially available systems.The teleDosimetry System is a family of products that can be used individually, or integrated together in a "modular" configuration to build monitoring networks.

- Real time dosimetry control
- Compatible with other manufacturers' devices



- Integration with non-radiological data sources
- Graphical data trending
- Logging and analysis

# Benefits

- Reduces exposure to achieve ALARA goals
- Saves manpower on real time control
- Reduce surveys through continuous area monitoring
- Quick, easy, lower cost deployment without the need for engineering approvals
- Extended range coverage without complex wiring



### System and Components

The Base Station is the heart of the system, providing total area coverage for the radio data transmission network. Physically it is a low profile, environmentally ruggedized unit. Standard connections to the unit include a high performance 9dB gain antenna, RS 232 computer interface cable, and an AC power adapter. The system is a modular monitoring system that can easily integrate sources of data throughout a plant or field location and organize it into logical display and historical presentations. In this case, remote monitoring stations can be set up throughout the location via the site's IT network, allowing personnel in office environments to have access to real-time monitoring.

# **EPD Transmitter**

The EPD Personal Transmitter for the Mk 2 EPD is the solution for personal teledosimetry. Using the proven performance and reliability of the Thermo Scientific EPD as the system's foundation, the Personal Transmitter provides a smart wireless interface in the industry's most compact and durable design.

#### **Base Station**

The Base Station is the heart of the system, providing total area coverage for the radio data transmission network. Physically it is a low profile, environmentally ruggedized unit. Standard connections to the unit include a high performance 9dB gain antenna, RS 232 computer interface cable, and an AC power adapter.

## **Universal Transmitter**

The Universal Transmitter (UTX) allows for most any digital input to be added to the telemetry system.

#### Repeater

The Repeater is a full duplex, spread spectrum wireless data repeater for use in the system. The Repeater can be placed at strategic points to extend or 'fill in' radio coverage in hard to monitor areas. The unit may be permanently installed (AC power with 9dB antennas), or temporarily configured using the rechargeable internal batteries and portable antennas.

The Repeater is unique in its simplicity of deployment. No special configuration, no complex wiring or antenna arrangements are needed. The unit comes complete with antenna set, antenna stands and AC power supply. The unit's indicator lights verify communications to both base and mobiles, allowing quick optimization of system deployment around buildings.

## **TeleDosimetry Monitoring Software**

The software is required to provide real time supervision of large numbers of remote telemetry monitor devices used for radiation monitoring.

Module	Dimensions	Weight	Power	Mounting	Interfaces	Part Number
Personal	125 x 63 x 23 mm	120 gms	1 x AAA alkaline	Pocket	Accepts	611/1/43800/00
Transmitter	5″ x 2.5″ x 1″	4 oz. (without EPD)	10-15 hours use		MK2 EPD	
			(depends on cfg)			
Base Station	185 x 145 x 50 mm	760 ams	AC Power	Free Standing	RS232 serial for PC	611/5/43826/000
	7.5" x 6" x 2"	1.75 lbs	via adaptor	or 4 hole wall	TNC antenna	includes AC adapter: one
				mount	9VDC inlet	9dB antenna and RS232
						computer cable (3 m, 9.5')
Panastar	200 v 145 v 90 mm	1490 ame	Internal NiCd	Fron Standing	2 x TNC antonna	611/5///262/000
nepeater	200 x 145 x 00 mm	2 25 lbc	hattony ontional	or 4 bolo wall		includes 2 x 0 dB antenna
	0 X 0.0 X 0 III.	3.23 108	operation			and AC adapter
			via AC adapter	mount	9 v uc iniet	anu AC auaptei
	202	050	N		N	054/4/04400/000
9dB Antenna*	600 mm long	250 gms	None	Use clamp or	N type coax	654/4/01102/000
	(24")	9 oz.		table type stand		
*15 dB Yagi anter	na also available					
Antenna stand	Base diameter	Approx. 2 kgs	-	Table top	-	617/4/08442/000
& clamn	150 mm (6")	4.5 lbs				

©2007 Thermo Fisher Scientific Inc. All rights reserved. Kapton is a registered trademark of of E.I. du Pont de Nemours and Company. All other trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries. Results may vary under different operating conditions. Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representatives for details. Literature Code LITEPDTELEDOSIMETRY 0407

Worldwide Frauenauracher Strasse 96 D 91056 Erlangen, Germany	+49 (0) 9131 909-0 +49 (0) 9131 909-205 fax		
United Kingdom Bath Road, Beenham, Reading RG7 5PR United Kingdom	+44 (0) 118 971 2121 +44 (0) 118 971 2835 fax		
United States	+1 (508) 520-2815		

27 Forge Parkway Franklin, MA 02038 USA +1 (508) 520-2815 +1 (800) 274-4212 toll-free +1 (508) 428-3535 fax www.thermo.com/rmp

