

585 置 TECPAK OEM TEMPERATURE CONTROLLER



The 585 TECPak OEM temperature controller is a compact, high-power temperature controller that can be used independently or with a LaserPak to form a complete system. The TECPak offers the same quality instrumentation as our bench top units, but in a smaller and lower cost solution for custom systems.



EXCELLENT STABILITY

The 585 offers \pm 0.004°C temperature stability over 1 hour, and only \pm 0.01°C fluctuation over 24 hours.



AUTO-TUNE AUTOMATIC PID CALCULATION

The 585 series automatically calculates PID parameters for your mount.



FULLY ADJUSTABLE PID VALUES

Every TECPak has eight factory-set gain settings, along with the option to choose your own.



ROBUST ANALOG INTERFACE

Provides on/off control, status, and analog control and monitor of temperature.



INTEGRATED FAN POWER SUPPLY

Provides integrated supply to power a laser mount cooling fan.

AT-A-GLANCE

Power Ranges

- ▶ 32 Watt / 4 Amp / 8 Volt
- ▶ 55 Watt / 5 Amp / 12 Volt

Works With

- ▶ Thermistors
- ▶ RTD (2- or 4-wire)

Heat & Cool

► TEC Modules & Resistive Heaters

Save Space

▶ Compact Enclosure

Remote Operation via PC

- Use your existing control code.
 Our command set is compatible with other manufacturers.
- ▶ USB / RS-232 Connections



DRIVE ANY ARROYO LASERMOUNT.

The 585 Series TECPak will drive any Arroyo Instruments laser fixture and many compatible fixtures. Connections are easy, and we offer purpose-built cables.

Plug and play compatibility.

| | | 585-04-08 | 585-05-12 |
|----------------------|---|-------------------|-----------|
| | Current | , | |
| | Range (A) | 4 | 5 |
| | Compliance Voltage (V) | 8 | 12 |
| | Max Power (W) | 32 | 55 |
| Drive Channel | Resolution (A) | 0.01 | |
| | Accuracy (+/- [% set point + mA]) | 0+30 | |
| | Noise/Ripple (mA, rms) | < 5 | |
| | Temperature Control | | |
| | Range (°C)¹ | -99 to 250 | |
| | Resolution (°C) | 0.01 | |
| | Thermistor Accuracy (± °C) ² | 0.05 ³ | |
| | Short Term Stability (1hr) (± °C)⁴ | 0.004 | |
| | Short Term Stability (24hr) (± °C)⁴ | 0.0 | 01 |

585 SERIES TECPAK SPECIFICATIONS

| | Current | | |
|----------------------|--|--|--|
| | Resolution (mA) | 10 | |
| | Accuracy (+/- [% reading + mA]) | 0+30 | |
| | Voltage | | |
| | Resolution (mV) | 10 | |
| | Accuracy (+/- [% reading + mV]) | 0 + 50 | |
| | Sensor | | |
| els | 10μA Thermistor | | |
| Measurement Channels | Range (kΩ) | 0.1 - 450 | |
| Cha | Resolution (Ω) | 10 | |
| t | Accuracy (+/- [% reading + Ω]) | 0.05 + 50 | |
| me | 100μA Thermistor | | |
| ure | Range (kΩ) | 0.05 - 45 | |
| eas | Resolution (Ω) | 1 | |
| ž | Accuracy (+/- [% reading + Ω]) | 0.05 + 5 | |
| | RTD | | |
| | Range (Ω) | 20 – 192 | |
| | Resolution (Ω) | 0.01 | |
| | Accuracy (+/- [% reading + Ω]) | 0.03 + 0.1 | |
| | Current Limit | | |
| | Resolution (mA) | 10 | |
| | Accuracy (+/- mA) | 50 | |
| | TEC Connector | DB-15, female | |
| | Fan Supply | 4 – 8.5V, 350mA max | |
| | Computer Interface | USB 2.0 Full Speed (Type B), RS-232 (DB-9, male) | |
| <u></u> | Power | Universal, 90V to 240V, 50/60 Hz | |
| General | Size (H x W x D) [inches (mm)] | 3.0 (77) x 4.5 (115) x 8.5 (216) | |
| წ —— | Size (LLV AN V D) [ILICHEZ (IIIII)] | 3.0 (/// X 4.3 (113) X 0.3 (210) | |

Weight [lbs (kg)]

Operating Temperature

Storage Temperature

- 1. Software limits. Actual range dependent on sensor type and system dynamics.
- Accuracy figures are the additional error the 585 TECPak adds to the measurement, and does not include the sensor uncertainties.
- 3. 25°C, 100 μA thermistor.
- 4. Stability measurements done at 25°C using a 10 k Ω thermistor on the 100 μ A setting. The number is ½ the peak-topeak deviation from the average over the measurement period.


www.arroyoinstruments.com




4.0 (1.8)

+10°C to +40°C

-20°C to +60°C



ARROYO CONTROL



Control any Arroyo laser driver or temperature controller directly from your PC. Simply connect to your Arroyo device via USB or RS-232 and gain direct access to settings, device limits, and adjustments from an easy-to-use Windows interface. You can even connect to multiple instruments at the same time.

Download ArroyoControl for free from www.arroyoinstruments.com.

LabView drivers available.



ACCESSORIES

1402-RM

PAK SERIES RACK MOUNT KIT, 3 OR 5 UNITS

This rack mount kit will mount any 485 LaserPak or 585 TECPak controller. When positioned flat, the 1402-RM can hold three units in a 2U space.



Mount the controllers on their sides, and the 1402-RM can hold five units in a $5\mathrm{U}$ space.



There is also mounting support for a 7-port USB hub as well as holes for securing and dressing wiring to the tray with cable ties.

www.arroyoinstruments.com

