



WARNING: To avoid electrical shock, always connect this instrument to earth ground.

Replace fuse with specified type:
T 250V, 1.0A IEC 60127-2

Analog Input

Fig. 4 Definition

Pin #	Definition
1	On/Off Control (In)
2	On Status (Out)
3	Stable (Out)
4	Temperature (Out)
5	Temp Set (In)
7	+5V
8	GND

Refer to qualified personnel.

No operator serviceable components inside.

RS-232

USB

Power

On

Error

Arroyo Instruments

TECPak

Temperature Controller

Consult manual for operating instructions.
Do not block fan or ventilation holes.

Made in USA
San Luis Obispo, CA
www.arroyoinstruments.com

CE

TEC Output

Pin #	Definition
1, 2, 9	TE-
11	Fan+
3, 4, 10	TE+
12	Fan-
5, 6	Earth Ground
7	Sensor+
8	Sensor-

WARNING: To avoid electrical shock, always connect this instrument to earth ground.

Replace fuse with specified type:
T 250V, 1.0A IEC 60127-2

Analog Input

Fig. 4 Definition

Pin #	Definition
1	On/Off Control (In)
2	On Status (Out)
3	Stable (Out)
4	Temperature (Out)
5	Temp Set (In)
7	+5V
8	GND

Refer to qualified personnel.

No operator serviceable components inside.

RS-232

USB

Power

On

Error

Arroyo Instruments

TECPak

Temperature Controller

Consult manual for operating instructions.
Do not block fan or ventilation holes.

Made in USA
San Luis Obispo, CA
www.arroyoinstruments.com

CE

TEC Output

Pin #	Definition
1, 2, 9	TE-
11	Fan+
3, 4, 10	TE+
12	Fan-
5, 6	Earth Ground
7	Sensor+
8	Sensor-

WARNING: To avoid electrical shock, always connect this instrument to earth ground.

Replace fuse with specified type:
T 250V, 1.0A IEC 60127-2

Analog Input

Fig. 4 Definition

Pin #	Definition
1	On/Off Control (In)
2	On Status (Out)
3	Stable (Out)
4	Temperature (Out)
5	Temp Set (In)
7	+5V
8	GND

Refer to qualified personnel.

No operator serviceable components inside.

RS-232

USB

Power

On

Error

Arroyo Instruments

TECPak

Temperature Controller

Consult manual for operating instructions.
Do not block fan or ventilation holes.

Made in USA
San Luis Obispo, CA
www.arroyoinstruments.com

CE

TEC Output

Pin #	Definition
1, 2, 9	TE-
11	Fan+
3, 4, 10	TE+
12	Fan-
5, 6	Earth Ground
7	Sensor+
8	Sensor-